

Only if Battery already includes Battery Protection: Cut JP1, Bridge JP2, DNP: R1:4, Q1:2, C1, U1

[illegible][illegible]

Interface not used by default

Includes: I2C Pins, UART (or 2 ESP32 GPIOs), 3 free GPIOs, 1 free TCAB418 GPIO (only slower signals recommended), ESP_ON for powerup

Always check I2C Address compatibility when connecting new I2C devices

[illegible]

Note: Data Pins are denoted so they match with the Espressif Camera Component, where "D0" is D2, "D1" equals D3 etc.

Hotplugging not recommended
Disable 3.3V rail with SW1 before unplugging

Side Display 12C
Address: 0x3D
Main Display 12C
Address: 0x3C

J5 FPC 24P P0.5

[illegible]

SW1 can be used to:

- 1) Boot ESP32 in programming mode
- 2) Disable the 3V3 rail (e.g. for soldering)

Rev: 0
Id: 1/1