Help for the smartcard activation to vote

To start this process you need to:

- have installed at least one voting machine.
- have a smartcard reader connected to the president machine.
- have smartcards to be activated and thus allow votes to be cast.

To activate an official smartcard you need to:

- 1. Click on the nationality of the voter.
- 2. Insert the card into the smartcard reader.
- 3. Wait for the message indicating the card is activated.
- 4. Give the card to the voter.
- 5. Repeat this procedure for each voter who presents himself.
- 6. When you are ready, click on the red cross in the upper right part of the screen.