
BeagleBoard_XM Adapter


Page	Description	
1	Title Page	
2	Block Diagram	
3	Parallel Data & I2C	
4	Power, Clock & Reset	

Rev	Who	Date	Description
Rev 0.0	Joe KK	11/22/2010	Initial
Rev 0.1	Joe KK	11/30/2010	Add P6 and R11 for CAM_RST control selection



Block Diagram









Parallel Data & I2C







Parallel Data Level Shifter

I2C Level Shifter






BeagleBoard-XM Camera I/F








Power, Clock & Reset




Adjustable Power Supply for Headboard 3.3V Level-shifting



(Mount LED on bottom side of PC

Adjustable Power Supply for BeagleBoard-XM 1.8V Level-shifting



Clock & Reset Level Shifter

