

BOEING 737NG SERIESSUMMARISED CHECKLIST



PRE-FLIGHT / BEFORE START

PRE-FLIGHT / BEFORE S	TART
Parking Brake	SET
Gear Lever	Down
Battery/STBY Power	On/Auto – Guard Closed
Emergency Exit Lights	Auto/Guard Closed
Cockpit Voice Recorder	Set MAN ON
Ground Power	Confirm Connected
External Lights	As Required
IRS	Set to NAV
Warning Systems	Tested
Pax Signs	AUTO
Elec Hydraulic Pumps	ON
Yaw Damper	ON
Window Heat	ON
SET FMC / Obt	tain Clearance
Altimeter	SET
Transponder	SET
Fuelling/Loading/Boarding	J Completed
Take Off Data	SET
Cruise Altitude Press. Pane	l SET
Landing Altitude Press. Par	nelSET
MCP	SET
DEPARTURE BRIE	FED & CHE <mark>CKED</mark>
L AFT Fuel Pump	ON
APU	Sta <mark>rt &</mark> Monitor
APU Gens	. ON & Generating Power
APU Bleed	After 1 Minute – Set ON
Packs	AUTO
Isolation Valve	OPEN
Radios Frequencies Set	
Flight Directors	ON
Check:	vinment Clear
Doors Closed / EquChocks Removed	iipineni Cieai
REQUEST PUSH & .	START CLEARANCE
Anti-Collision Lights	ON
CHECK CLEAR	R BOTH SIDES

BEGIN PUSHBACK & ENGINE START

ENGINE START

ENGINE STAKT	
Fuel Pumps	On - As Required
Packs	OFF
Ignition Mode Selector	Set BOTH
ENG 2 Start Switch	GND
At N2 20-25% - ENG 2 Fuel Cor	ntrol Lever RUN
REPEAT FOR ENGINE 1 – THE	EN WHEN STABLE:
GENs 1 & 2	ON & Check
ENG 1 & 2 Start Switches	AUTO / CONT
Probe Heat	ON
Wing / Engine Anti-Ice	As Required
ENG 1 & 2 Bleeds	ON
Packs	Set AUTO
Recirc Fans	Set AUTO
Isolation Valve	Set AUTO
APU Bleed & APU	OFF
Flaps	As Required
Elevator Trim	
Flight Controls	Full & Free
Engine Instruments	Checked
LNAV + VNAV	Armed / As Req'd
Autothrottle	ARM
Warning Recall	Check & Consider
Lower ECAM Screen	
REQUEST TAXI	
TAXI	
TANCELLA	ON

TAXI Lights	ON
Autobrake	Set RTO
CHECK BRAKES / COMPASS / GYRO	

PRE-DEPARTURE

Fuel FlowRese	t -> Rate
Vspeeds	. Checked
MCP / Nav Data / Radios	Check
OBTAIN TAKEOFF CLEARANCE	

TAKEOFF

POS Lights	SET Strobe & Steady
Taxi Lights	OFF
Landing + Runway Turnoff Light	ts ON
Transponder	Set TA/RA
TFC	Press ON
Clock	START
Runway	Confirm



BOEING 737NG SERIESSUMMARISED CHECKLIST



AFTER TAKEOFF

Positive Rate	Gear UP	
	TUDE / WINGS LEVEL	
	CMD A - Engage	
·	OFF	
Gear Lever	Set OFF	
ENG Start Switches	Set AUTO/OFF	
Runway Turnoff Lights	OFF	
Flaps	Retract as Appropriate	
	Pressurising Normally	
PASSING TRAI	NSITION ALTITUDE	
Altimeter	Set STD	
PASSIN	NG 10,000ft	
	OFF	
Seatbelt Signs	As Required	
DESCENT		
	Obtained	
Arrival Data Set & Checked		
	itude SET	
	SET	
•	SET	
	As Required	
	SET for Transition Level	
	SET	
	SET CHECK & Consider	
-		
MCPReset Altitude **BELOW TRANSITION LEVEL**		
	Set Local QNH/QFE	
	Depressurising Normally	
BELOW 10,000ft		
Landing Lights	ON	
	ON	
	As Required	
CONFIRM ATIS ,	APPROACH IN USE	

During the Arrival Brief, plan a suitable runway exit to facilitate minimum runway occupancy where appropriate

Be prepared to enter any Holding Pattern if advised by ATC

APPROACH

NAV Course / Frequency	CHECK
Speeds	In Limits
Flaps	Extend As Required
Speedbrake	ARM
APP Mode	ARM if Required
Glideslope Alive	GEAR DOWN
Flaps	Check Speed – SET 15
ENG 1 & 2 Start Modes	Set AUTO/CONT
Landing Gear	CONFIRM DOWN
Autopilot	Engage CMD B (ILS)
Flaps	. Confirm SET for Landing
Go Around Altitude	
Autopilot / Auto Throttle	As Required
MONITOR – BE PREPA	ARED TO GO AROUND

AFTER LANDING

Flaps	UP
Speedbrake	RETRACT
Transponder	As Required
POS Lights	Set STEADY
Landing & Runway Turnoff Lights	OFF
Taxi Lights	ON
APU	Start & Bleed
Anti-Ice	As Required
Probe Heat	AUTO/OFF
ENG Start Switches	AUTO/OFF
Autobrake	OFF
UPON ARRIVAL AT STAND,	<i>PARKING</i>
APU GEN	Set ON & Check
Taxi Lights	OFF
When Parked – Parking Brake	

SHUTDOWN

SHUTDOWN	
Fuel Control Levers	OFF
Anti Collision Lights	OFF
Seatbelt Signs	OFF
Ground Equipment + Chocks (FMC)	In Position
Fuel Pumps	As Required
Isolation Valve	Open
Flight Directors	OFF

MONITOR DISEMBARKATION

CONSIDER SWITCHING TO GPU AND TURNING APU OFF