microSOM Connectivty

The microSOM has 3 board to board headers; but CuBox-i uses only two of those

- General Notes 1. Components marked with DNP means Do Not Place. Those are optional components added for refinement.
 2. Components marked with Base and Pro means assembly options for the lower end models and the higher models









