

McHenry County Emergency Services Volunteers

Table of Contents

1	Introduction & System Overview	
2	Getting Started — Connecting to FieldComms	http://192.168.50.1/
3	The Main Dashboard	http://192.168.50.1/
4	Member Roster	http://192.168.50.1/roster.html
5	Operator Identity System	
6	Amateur Net Control Logger	http://192.168.50.1/netcontrol.html
7	Starcom Net Logger	http://192.168.50.1/starcom.html
8	Observer Mode — Read-Only Net View	http://192.168.50.1/observer.html
9	FCC Callsign Lookup	http://192.168.50.1/callsign.html
10	Tactical APRS Map	http://192.168.50.1/tactical.html
11	Starcom Resource Tracking Map	http://192.168.50.1/resmap.html
12	Resource Board	http://192.168.50.1/resources.html
13	Dead Man's Switch — Net Inactivity Monitor	http://192.168.50.1/deadmans.html
14	Pre-Flight Deployment Checklist	http://192.168.50.1/preflight.html
15	ICS Platform — Overview	http://192.168.50.1/ics/
16	ICS Command Section	http://192.168.50.1/ics/command.html
17	ICS Operations Section	http://192.168.50.1/ics/operations.html
18	ICS Planning Section	http://192.168.50.1/ics/planning.html
19	ICS Logistics Section	http://192.168.50.1/ics/logistics.html
20	ICS Finance / Admin Section	http://192.168.50.1/ics/finance.html
21	NTS Radiogram Generator	http://192.168.50.1/nts.html
22	ICS-213 General Message	http://192.168.50.1/ics213.html
23	ICS-214 Activity Log & ICS-309	http://192.168.50.1/ics214.html
24	Winlink Form Import & Incident Archiving	http://192.168.50.1/winlink-import.html
25	HF Propagation	http://192.168.50.1/propagation.html
26	Repeater Database	http://192.168.50.1/repeaters.html
27	Facilities Directory	http://192.168.50.1/facilities.html
28	Grid Square Calculator	http://192.168.50.1/grid.html
29	Radio Cheat Sheets	http://192.168.50.1/cheatsheets.html
30	Print Center	http://192.168.50.1/printcenter.html
31	Reference Library	http://192.168.50.1/refs.html
32	Kiwix Offline Library	http://192.168.50.1:8081/
33	Offline Maps, GPS & Health Monitor	
34	Network Hardware — ASUS RT-BE58 Go & UniFi Switch	
35	JS8Call — HF Digital Keyboard Messaging (Windows)	
36	ICS Planning P — Operational Planning Cycle	http://192.168.50.1/ics/planningp.html

34 Appendix — Administration & Quick Reference

1 Introduction & System Overview

Incident Management is a self-contained emergency communications server that runs on a Raspberry Pi. It provides a complete suite of EmComm tools — net control logging, an ICS incident management platform, mapping, reference libraries, and form generation — all accessible through a standard web browser with no internet connection required. It is built for McHenry County Emergency Services Volunteers and McHenry County Emergency Management Agency operating under the RACES / ARES / Starcom framework.

How It Works

The Pi broadcasts its own Wi-Fi network named **EMCOMM-NET**. Any smartphone, tablet, or laptop connects to that network and opens the dashboard in a browser at **<http://192.168.50.1>**. The server hosts every tool locally. No app needs to be installed on any device.

WHAT IT IS	DETAIL
A web server	nginx serves the dashboard and all 30 tool pages
A database	SQLite stores members, nets, incidents, resources, forms
An API layer	Python Flask services on ports 5050–5056 serve live data
An offline library	Kiwix serves WikiMed, Wikipedia, and reference docs at port 8081
An APRS receiver	Graywolf and YAAC receive RF APRS packets at ports 8080 and 8082
A map tile server	Offline USGS tiles served at port 8083 — no internet needed

Key Principles

- 1. Offline-first** — every feature works without internet. Optional WAN connection enables FCC database refresh, NWS alerts, and propagation data.
- 2. Browser-based** — no app installs. Any device with a modern browser works.
- 3. Identity-aware** — each operator identifies once and their callsign, Radio ID, or name appears on all log entries.
- 4. Multi-user** — many operators on many devices simultaneously, all seeing the same live data.
- 5. Three dashboard modes** — Amateur Radio, Starcom / Public Safety, and ICS Incident Command keep tools organized for the task at hand.

2

Getting Started — Connecting to FieldComms <http://192.168.50.1/>

Getting on FieldComms takes three steps: connect to the Wi-Fi, open the dashboard, and identify yourself. The whole process takes under a minute.

Step 1 — Connect to the EMCOMM-NET Wi-Fi

On your phone, tablet, or laptop, open Wi-Fi settings and connect to:

SETTING	VALUE
Network Name (SSID)	EMCOMM-NET
Password	Provided by your net manager (default: fieldcomms2026)
Security	WPA2-PSK
Wi-Fi Channel	6 (2.4 GHz)
Your device receives IP	192.168.50.100 – 192.168.50.200 (automatic)

- The Wi-Fi password is the only access control on FieldComms. Anyone with the password can use every tool — there is no separate login screen. Keep the password posted at the EOC for arriving operators and treat it as an operational credential.

Step 2 — Open the Dashboard

1. Open any web browser (Chrome, Safari, Firefox, Edge — all work).
2. Type **http://192.168.50.1** in the address bar and press Enter.
3. The FieldComms dashboard loads. You do not need to install anything.

Step 3 — Identify Yourself

On first visit, a prompt appears asking for your identity. Enter your **callsign, Radio ID, or name** and optionally your ICS position. This information is saved in your browser and remembered between sessions.

- You do not need to re-enter your identity every time you visit. Your browser remembers it until you clear browser storage or tap the identity badge to change it.

3 The Main Dashboard <http://192.168.50.1/>

The dashboard is your central hub. It shows live system status, active weather alerts, a live APRS station table, and quick-launch cards for every tool. At the very top is the organization header with the MCESV/MCEMA logo and your operator identity badge.

Three Dashboard Modes

Directly below the header is a three-button mode switcher. It reorganizes the tool cards to match what you are doing. Your choice is saved on your device and remembered between sessions.

MODE	BUTTON	WHAT IT EMPHASIZES	WHEN TO USE
■ Amateur Radio	■	Net Control, APRS, Winlink, Callsign Lookup, Resource Board, Roster, DMS, Pre-Flight, NTS/ICS forms, Propagation, Repeaters, Kiwix, Cheat Sheets	ARES/RACES nets, NTS traffic, weekly nets, exercises
■ Starcom / Public Safety	■	Starcom Net Logger, Weather Net, SAR Net, Observer Mode, Resource Tracking Map, Resource Board, Member Roster, Facilities, ICS Platform, ICS-213, ICS-214	Starcom activations, public safety nets, weather spotters, SAR operations
■ ICS / Incident Command	■	ICS Platform (all five sections + Planning P), Tactical Map, Resource Map, Resource Board, Roster, Facilities, ICS forms, Winlink Import, Repeaters, Cheat Sheets	Formal ICS activations, EOC operations, multi-agency incidents

Dashboard Elements

ELEMENT	DESCRIPTION
Hero bar	Station callsign badge, system name, live UTC clock and local 24-hour clock updated every second
Mode switcher	Three mode buttons — ■ Amateur Radio / ■ Starcom / ■ ICS — click to reorganize tool cards
NWS Weather Alerts	Live National Weather Service alerts color-coded by severity. Click any alert to expand full details, onset time, expiry countdown, and protective action instructions
Operation cards	Quick-launch tiles for every tool in the current mode — click to open
APRS station table	Live APRS stations heard by Graywolf, with callsign, distance, course/speed, comment, and last heard time. Updates every 30 seconds
Status sidebar	CPU/memory/disk/temperature, all service status dots (green=running, red=stopped), GPS status, Dead Man's Switch state

■ The URL parameter **?mode=starcom** loads the dashboard directly in Starcom mode — useful for bookmarking on Starcom-dedicated devices.

4

Member Roster <http://192.168.50.1/roster.html>

The Member Roster is the authoritative directory for all MCEMV/MCEMA personnel. It tracks every member's identifiers, contact information, certifications, equipment, and deployment activations. It supports both amateur radio operators and non-ham members.

Member Identifiers

Every member is tracked by up to three identifiers:

IDENTIFIER	WHO HAS IT	EXAMPLE
ESV Member ID	All ESV members	ESV-042
Starcom Radio ID	All ESV members	1042
Amateur Callsign	Licensed hams only (blank for non-hams)	K9ESV

Non-ham members are full members of the roster. Leave the Callsign field blank for them — the system uses their Radio ID or Member ID as their primary identifier automatically.

The Roster Tabs

TAB	CONTENTS
Directory	Full searchable member list with all identifiers, contact info, and role badges
Certifications	Check off ICS-100/200/300/400/700/800, EmComm I/II, CERT, First Aid, FEMA IS courses
Equipment	Check off capabilities: HF/VHF/UHF radio, Winlink, JS8Call, APRS, generator, antenna, laptop, go-kit
Activations	Check-in log for the current activation. Click + Check In to mark a member as activated. Walk-in check-ins are added here
Import/Export	Export roster to CSV for backup or sharing. Import from a CSV to bulk-load members

Role Definitions

ROLE	DESCRIPTION
Net Control (NCS)	Primary net controller — manages check-ins and traffic flow
Operator	Standard ARES/RACES field operator
Liaison	Agency liaison — interface between operators and the served agency
Emergency Coordinator (EC)	Oversees ARES/RACES operations for the county

Importing & Exporting (CSV)

1. To export: click **Export CSV**. A file downloads with all members and all columns.

2. To import: prepare a CSV with these column headers, then click **Import CSV** and choose the file.

member_id, callsign, radio_id, first_name, last_name, role, phone, email, grid, license_class

- The net manager can print wallet-sized access cards for every member, generated from the roster. Each card shows the Wi-Fi network and password, the dashboard URL, and the member's identifiers. Run: `python3 /opt/fieldcomms/scripts/gen_operator_cards.py --ssid EMCOMM-NET --password YOUR-PASSWORD`. Output is a print-ready PDF, 10 cards per Avery 5371 sheet.

5 Operator Identity System

Every FieldComms page tracks who is operating at each device so your check-ins, log entries, and form signatures are attributed correctly. There is no password — your identity is stored in your device's browser and remembered between sessions. The system handles all four kinds of people who show up at an activation.

The Four Identity Types

TYPE	IDENTIFIERS USED	BADGE
ESV Member + Ham	Member ID + Callsign + Starcom Radio ID	■ K9ESV
ESV Member, Non-Ham	Member ID + Starcom Radio ID (no callsign)	■ ESV-042
Visitor / Mutual Aid, Ham	Callsign + Agency name	■ W9XYZ
Visitor / Mutual Aid, Non-Ham	Name + Agency (+ optional Radio ID)	■ VISITOR

The system always displays the most useful identifier for radio work. The priority is: callsign first, then Starcom Radio ID, then member ID, then name.

Setting Your Identity

1. On first visit, a prompt appears automatically. Enter your callsign, Radio ID, or name, and optionally your ICS position.
2. Click **Set Identity**. Your badge appears in the header.
3. To change your identity later: click your callsign/name badge in the header and update the fields.

■ Observer Mode (<http://192.168.50.1/observer.html>) intentionally does NOT prompt for identity — it is read-only and requires no identification.

6

Amateur Net Control Logger <http://192.168.50.1/netcontrol.html>

The Net Control logger is the primary tool for running ARES/RACES amateur radio nets. It supports multiple simultaneous nets, automatically looks up FCC callsign data, tracks traffic, and exports logs in ICS-309 format.

Starting a Net

1. Click **+ New Net** in the net tabs bar at the top.
2. Enter a **Net Name** — for example "McHenry County ARES Thursday Evening Net".
3. Enter the **Frequency** — for example "147.015 MHz / 107.2 Hz".
4. Enter **Net Control** — your callsign (auto-filled from your identity if set).
5. Click **Activate Net**. The net goes live and appears as a tab.

The Net Selector Tabs

Each active net appears as a tab in the NET TABS bar at the top of the page. The active net is highlighted. Tap any tab to switch to that net's log. Each net has its own independent check-in log, traffic log, and export.

Logging a Check-In

1. Type a callsign in the **Callsign** field and press **Enter**. The FCC database fills in the operator's name and license class automatically.
2. Add **Location** and **Remarks** if needed.
3. Click **+ Check In** or press Enter. The entry appears with a UTC timestamp.
4. To add a non-licensed or non-US operator: type their name or identifier directly.

■ The **+ Roster** button only appears for stations not already in the roster, so you will not create duplicates. Click it to add any new station to the Member Roster directly from the net log.

Logging Traffic

1. Switch to the **Traffic** tab.
2. Enter the From callsign, To callsign or address, traffic type, and a note.
3. Click **Log Traffic**. The traffic item is timestamped and recorded with the net.

The Roster Chips (Quick Check-In)

The Roster tab shows quick-tap chips for known stations. Tap a chip to instantly log that station's check-in without retyping the callsign — useful for regulars on a weekly net.

Sharing & Exporting

BUTTON	WHAT IT DOES
■ Observer Link	Copies a read-only URL for the currently selected net. Share it with served-agency staff or EOC viewers — see Chapter 8.
ICS-309	Exports the selected net's log as a formatted ICS-309 Communications Log, ready to print.

Export JSON	Downloads the full net data as a JSON backup file.
Close Net	Marks the net closed and archives it. The log is preserved and viewable.

- Precedence levels — ROUTINE / WELFARE / PRIORITY / EMERGENCY — can be set per check-in or traffic entry. Use EMERGENCY only for life-safety traffic. PRIORITY for time-sensitive but non-emergency messages.

7

Starcom Net Logger <http://192.168.50.1/starcom.html>

The Starcom Net Logger is its own dedicated module with a dedicated dashboard mode — separate from the Amateur Radio section. Select ■ **Starcom / Public Safety** from the mode bar on the main dashboard to access it. The module is purpose-built for public-safety Starcom radio net logging. It identifies units by Radio ID and unit number rather than amateur callsigns, includes a dispatch center field, and uses the **sc-** prefix convention for net names.

Running Multiple Simultaneous Nets

The Starcom Net Logger supports multiple simultaneous nets — identical to the Amateur Net Control Logger. This is particularly useful during large activations where you may need to run a **Starcom General Net**, a **Weather Net**, and a **SAR Net** all at the same time, each with its own independent check-in log and traffic log.

1. Click **+ New Net** to open the first net.
2. Click **+ New Net** again for each additional net — Weather Net, SAR Net, etc.
3. Each open net appears as a clickable badge in the **active nets panel** on the left sidebar.
4. Click any net badge to switch to that net. The check-in log and traffic log update to show that net's data.
5. Nets run independently — logging a check-in on one net does not affect the others.
6. Close each net individually when it is no longer needed.

■ Typical multi-activation scenario: Starcom General Net (command channel) + Weather Net (storm spotters) + SAR Net (field teams) all open simultaneously. Net Control switches between them as radio traffic comes in on each channel.

Opening a Starcom Net

1. Click **+ New Net**.
2. Enter the **Net Name**.
3. Choose the **Net Type**: Starcom General / Weather Net / SAR Net / Observer Net.
4. Enter the **Talkgroup** and **Channel/Frequency**.
5. Enter the **Dispatch Center** (e.g. MCECC, IDOT). It appears in the net header and stays set for the whole net session.
6. Click **Activate Net**.

Logging a Unit Check-In

1. Enter the **Radio ID / Unit #** (e.g. 1234).
2. Enter the **Unit Name / Callsign** (e.g. "MCHENRY CO ARES" or a callsign).
3. Choose the status: Check-In, Traffic, Priority Traffic, Emergency, Dispatch, Check-Out, En Route, On Scene, Available, or Out of Service.
4. Select the talkgroup type and enter the channel/frequency.
5. Add location and remarks, then click **LOG ENTRY**. The time is stamped automatically.

Exporting & Sharing

The Starcom logger shares the same Observer Link, ICS-309 export, and JSON backup tools as the amateur logger (see Chapter 6). Exports carry a Starcom header and keep the sc- prefix.

FIELD	DESCRIPTION
Radio ID	Starcom unit number (e.g. 2301, 4710). Required for every check-in.
Unit Name	Agency and unit description (e.g. "McHenry SO — Unit 12")
Dispatch Ctr	Dispatching agency or center (e.g. MCECC, IDOT)
Net Type	Starcom General / Weather Net / SAR Net / Observer Net
Talkgroup	Radio talkgroup identifier for the net channel

8

Observer Mode — Read-Only Net View <http://192.168.50.1/observer.html>

Observer Mode provides a read-only, auto-refreshing view of any active net. It is designed for served-agency personnel, EOC staff, emergency managers, and section leaders who need to monitor radio traffic without touching the net control interface. No login, no identity prompt, no setup required.

What Observer Mode Shows

ELEMENT	DESCRIPTION
Net name & status	Active net name, type (Amateur/Starcom), and open/closed indicator
Live check-in log	All stations or units checked in, with timestamp, location, and remarks
Traffic log	Formal message traffic passed during the net
Station count	Live count of checked-in stations at the top of the page
Auto-refresh	Page refreshes automatically every 15 seconds — no manual reload needed

How to Open Observer Mode

1. On the Net Control Logger or Starcom Logger page, click ■ **Observer Link** to copy the URL to your clipboard.
2. Send the link by email, Winlink, JS8Call, or read it over the air to any operator who needs to monitor.
3. The recipient opens the link in any browser on EMCOMM-NET — phones, tablets, and laptops all work.
4. Observer Mode shows the net immediately with no identity prompt and no login.
5. The net name is encoded in the URL so the link can be bookmarked for recurring nets.

■ Observer Mode is completely passive — observers cannot add check-ins, log traffic, or close the net. If an observer needs to interact, they must switch to the Net Control Logger or Starcom Logger and identify themselves first.

9

FCC Callsign Lookup <http://192.168.50.1/callsign.html>

The Callsign Lookup page provides instant offline access to the full FCC Amateur Radio ULS database — approximately 800,000 active licensees. No internet connection is required. Lookups are answered in milliseconds from the local SQLite database on the Pi.

Quick Callsign Lookup

1. Type a callsign (e.g. K9ESV) in the search box at the top of the page.
2. Press **Enter** or click **■ Look Up**.
3. The result shows: full name, license class, expiration date, mailing address, grid square, and FRN.
4. Click **+ Add to Roster** to add the licensee directly to the Member Roster.
5. Recent lookups are saved automatically and shown below the search box for quick re-access.

Advanced Search

1. Click the **Advanced Search** tab.
2. Enter any combination of: First Name, Last Name, City, State, License Class, or Grid Square.
3. Click **Search**. Results show up to 100 matching licensees.
4. Click any result row to see the full record.
5. Click **+ Roster** on any result to add them to the Member Roster.

■ The FCC database is refreshed automatically every Sunday at 03:00 via the **fcc-refresh.timer** systemd timer (requires internet connection). The database status — record count and last update date — is shown at the bottom of the page.

10

Tactical APRS Map <http://192.168.50.1/tactical.html>

The Tactical Map is a full-screen Leaflet.js mapping tool that combines live APRS station tracking, offline map tiles, manual tactical overlays, and GPS position tracking. It supports both Graywolf and YAAC as APRS back-ends and works completely offline once map tiles have been downloaded.

Map Layout

ELEMENT	DESCRIPTION
Left sidebar	Station list — all APRS stations received, with callsign, comment, distance, and last heard time
Map area	Interactive Leaflet map with APRS symbols, custom overlays, and drawing tools
Top toolbar	Layer toggles, tile selector, auto-refresh interval, range ring, and drawing tools
Station labels	Callsign labels on the map — toggleable in settings
Status bar	Station count, GPS status, last refresh time

APRS Sources — Graywolf and YAAC

SOURCE	PORT	DESCRIPTION
Graywolf	8080	Primary APRS client — receives RF APRS via connected TNC or soundcard interface
YAAC	8082	Secondary APRS client — backup receive and alternate TNC support

Station Tracking

1. Click any station in the left sidebar to center the map on that station.
2. Click **Track** to lock the map view on a specific station as it moves.
3. Use the **Station age threshold** setting to hide stations older than N minutes.
4. The search box filters the station list by callsign or comment text.

Drawing Tactical Overlays

1. Click a drawing tool in the toolbar: **Marker**, **Polygon**, **Circle**, or **Route**.
2. Click on the map to place the shape. For polygons and routes, click multiple points and double-click to finish.
3. Click a placed marker or shape to add a label or delete it.
4. Overlays are saved to the server automatically and persist across browser sessions.
5. Click **KML Export** to download the current overlay set as a KML file.

GPS Position

If a USB GPS receiver is connected to the Pi, your current position appears on the map as a blue dot and is used to calculate distances in the station list. The GPS status indicator in the status bar shows the fix quality.

Range Rings

Enter a radius in km in the **Range ring** field and click **Draw Ring** to place a circle on the map centered on your GPS position or the station default coordinates. Useful for visualizing coverage areas.

1 1

Starcom Resource Tracking Map <http://192.168.50.1/resmap.html>

The Resource Tracking Map is a purpose-built situational awareness tool for Starcom public safety net operations. It shows unit positions on an offline map with status color coding, supports manual placement and drag-and-drop repositioning, and synchronizes with the Member Roster for unit information. Access it from the Starcom / Public Safety dashboard mode.

Placing a Unit on the Map

1. Click **+ Add Unit** in the left panel.
2. Enter the **Radio ID**, **Unit Name**, and **Type** (Law Enforcement, Fire, EMS, Search & Rescue, Communications, EOC, Shelter, Other).
3. Enter a **Latitude** and **Longitude** directly, or click **■ Pick on Map** to click the map and set the position.
4. Set the **Status** (Available, Deployed, Staging, Out of Service).
5. Click **Save**. The unit appears on the map with its status color.

Status Colors

STATUS	COLOR	MEANING
Available	Green	Unit is on scene and available for assignment
Deployed	Blue	Unit is actively assigned and in the field
Staging	Amber	Unit is staging or en route
Out of Service	Red	Unit is unavailable

Moving Units

1. Click and drag a unit marker on the map to a new position.
2. The unit's coordinates update automatically when you release.
3. Alternatively, click the unit marker, click **Edit**, and update the coordinates manually.

Drawing Zones

1. Click **Draw Zone** to enter zone-drawing mode.
2. Click multiple points on the map to define the zone boundary.
3. Double-click to finish. Enter a zone name and color when prompted.
4. Zones persist across browser sessions and appear on the map for all connected devices.
5. Click **Clear Zones** to remove all zones.

1 2

Resource Board <http://192.168.50.1/resources.html>

The Resource Board tracks all personnel, vehicles, equipment, and facilities assigned to an activation. Each resource is displayed as a card showing its current status. A stats strip at the top of the page shows live counts by status across all resource types.

The Five Status States

STATUS	COLOR	MEANING
Available	Green	On scene and available for assignment
Assigned	Amber	Actively tasked with a specific assignment
Staging	Blue	En route or at the staging area, not yet deployed
Out of Service	Red	Unavailable — mechanical, medical, or administrative hold
Demobilized	Gray	Released from the incident and departed

Adding a Resource

1. Click **+ Add Resource**.
2. Enter the **Name/Description** (e.g. "IC-7300 HF Radio", "Unit 12 — Medic", "Generator — 5kW Honda").
3. Select the **Type**: Personnel, Vehicle, Radio, Generator, Antenna, Computer/Tablet, Medical, Shelter/Tent, Repeater, or Other.
4. Set the **Status** and optionally fill in Owner/Callsign, Quantity, Location, Assigned To, Contact, and Notes.
5. Click **Save Resource**. The card appears immediately.

Changing a Resource Status

1. Click the colored **status badge** on any resource card.
2. Each click cycles through the five states in order: Available → Assigned → Staging → Out of Service → Demobilized → Available.
3. The stats strip at the top updates instantly.

Filtering the Board

1. Use the **Type** filter dropdown to show only Personnel, Vehicles, Equipment, etc.
2. Use the **Status** filter to show only Available or only Assigned resources.
3. Filters can be combined — e.g. show all Assigned Personnel only.
4. The stats strip always reflects all resources regardless of the active filter.

1 3

Dead Man's Switch — Net Inactivity Monitor

<http://192.168.50.1/deadmans.html>

The Dead Man's Switch (DMS) monitors active radio nets for inactivity. If no check-in or traffic is logged within a configurable threshold, it triggers an audible alert and visual warning. This ensures net control operators don't miss a silent net or a dropped connection during a real activation.

Arming the DMS for a Net

1. Open the Dead Man's Switch page from the Amateur Radio or Starcom dashboard.
2. Active nets appear automatically in the panel.
3. Click **■ Arm** next to the net you want to monitor.
4. The DMS is now active. Any check-in or traffic logged in the Net Control Logger or Starcom Logger will automatically reset the timer.
5. The countdown timer is displayed on the page, showing time remaining before the alert fires.

Configuration

SETTING	DEFAULT	DESCRIPTION
Threshold	30 min	Time of inactivity before the alert fires
Warning at	80%	Percentage of threshold at which a yellow warning appears
Poll interval	30 sec	How often the DMS checks the server for net activity
Alert sound	On	Audible alarm when the threshold is exceeded

Resetting and Disarming

1. Click **■ Reset** to manually reset the timer without disarming.
2. Click **Disarm** to turn off monitoring for that net.
3. The DMS disarms automatically when the net is closed.

■ The DMS runs in the browser tab where you opened it. If you close the tab or navigate away, the audible alert will not sound. Keep the DMS page open in a dedicated tab during activations.

14

Pre-Flight Deployment Checklist <http://192.168.50.1/preflight.html>

The Pre-Flight Checklist is a structured GO / CAUTION / NO-GO deployment readiness assessment. Before any activation, run through the checklist to verify that all critical systems are operational.

Checklist Sections

SECTION	ITEMS COVERED
Power Systems	Shore/generator power, battery backup/UPS, solar panels, fuel supply, power distribution
Communications Equipment	HF radio, VHF/UHF radio, go-kit radios, HF antenna, VHF antenna, repeater access, Winlink, JS8Call
Computing & Software	Pi server boot, FCC database, nginx, API server, health monitor, paper backup forms
Networking	ASUS router, EMCOMM-NET Wi-Fi, DHCP, field device connectivity, UniFi switch
Field Supplies	Operator cards, printed forms, batteries, cables, tools, maps, personal PPE
Coordination	Net frequency confirmed, EOC contact established, served agency notified, ICS structure assigned

Deployment Verdicts

VERDICT	MEANING
■ GO	All required items passed — system is ready for deployment
■ CAUTION	Some optional items failed — review before deploying
■ NO-GO	One or more required items failed — do not deploy until resolved

Exporting the Report

1. Click **Export Report** to generate a printable PDF summary of the checklist.
2. The report includes the verdict, timestamp, and notes for all items.
3. File the report with the incident documentation.

■ Run the Pre-Flight Checklist before every activation — even for exercises. It takes less than five minutes and catches configuration issues before they become problems during a real emergency.

1 5

ICS Platform — Overview <http://192.168.50.1/ics/>

The ICS Platform is the full incident command and documentation system built into FieldComms. It covers all five ICS sections — Command, Operations, Planning, Logistics, and Finance/Admin — plus the ICS Planning P cycle guide. Access it by selecting ICS from the mode bar on the main dashboard, or directly at <http://192.168.50.1/ics/>.

Creating a New Incident

1. From the main dashboard (ICS mode), click **■ New Incident**.
2. Enter the Incident Name (required), Type, Location, Jurisdiction, Incident Commander, Op Period Duration, and an optional Situation Summary.
3. Click **Create Incident**. The incident becomes the active incident for all ICS platform pages.

ICS Navigation Tabs

TAB	SECTION	PRIMARY USE
■ Command	Command Section	Incident objectives, safety, weather, situation
■ Operations	Operations Section	T-card board, resource assignments
■ Planning	Planning Section	IAP documents, resource status table, period tracking
■ Logistics	Logistics Section	Comms plan, supply tracking, meals
■ Finance	Finance / Admin Section	Cost accounting, time tracking, procurement
■ Planning P	Planning Cycle Guide	Step-by-step ICS planning cycle with forms and attendees

Supported Incident Types

TYPE	TYPICAL USE
Natural Disaster	Severe weather, flooding, earthquake, tornado response
HazMat	Chemical spill, gas leak, radiological incident
Search & Rescue	Lost person, overdue hiker, water rescue
Mass Casualty Incident	Multi-patient medical emergency, transportation accident
Weather Net	Starcom/SKYWARN weather spotter activation
Public Health	Disease outbreak, mass vaccination, shelter-in-place
Other	Any incident not covered by the above types

1 6

ICS Command Section <http://192.168.50.1/ics/command.html>

The Command Section captures the strategic-level information for the incident: incident objectives, safety hazards, weather summary, current situation, accomplishments, and planned actions. This content forms the core of the Incident Action Plan (IAP).

Incident Objectives (ICS-202)

1. To add a pre-defined objective: click the **Select a common objective** dropdown. Choose from 100 common ICS objectives organized in 13 groups.
2. The selected objective populates the text field below. Edit it if needed — fill in any bracketed placeholders such as [frequency], [location], or [time].
3. If no edits are needed, click **+ Add** or press Enter.
4. To add a completely custom objective: type it directly in the text field and click **+ Add**.
5. Objectives are listed above the input field. Click the X next to any objective to delete it.

- The 100-item objectives dropdown is organized into 13 groups: Life Safety, Communications, Resource Management, Incident Command, Search & Rescue, Shelter & Mass Care, Weather & Natural Disaster, HazMat, Mass Casualty, Public Information, Finance & Administration, Demobilization, and MCEMV/MCEMA Specific.

Situation Report Fields

FIELD	WHAT TO ENTER
Safety Message	Safety message for this operational period (ICS-208)
Current Situation	Brief description of current incident status and key facts
Accomplishments	What has been achieved so far this operational period
Planned Actions	What operations are planned for the next operational period
Weather Summary	Current and forecast weather affecting operations

17

ICS Operations Section <http://192.168.50.1/ics/operations.html>

The Operations Section manages the tactical resources assigned to the incident. It uses a T-card style status board where resource cards can be dragged between status columns, mirroring a traditional ICS T-card board.

The T-Card Board

COLUMN	MEANING
Available	Resource is checked in and available for assignment
Assigned	Resource has been given a tactical assignment
Out of Service	Resource is unavailable — mechanical, medical, or other
Staging	Resource is at the staging area awaiting assignment
Released	Resource has been demobilized from the incident

Adding a Resource to the Board

1. Click **+ Add Resource** or **+ Assignment**.
2. Enter the resource name, type, callsign/Radio ID, and initial assignment.
3. Click **Save**. The resource appears in the Available column.

Moving Resources Between Columns

1. Drag a resource card from one column to another to update its status.
2. Alternatively, click the resource card to open its detail view, then change the status in the dropdown.
3. All status changes are saved to the server immediately.

Assignment Details

1. Click any resource card to open the detail panel.
2. Enter or update the **Assignment** (Division/Group), **Supervisor**, **Work Location**, and notes.
3. This information feeds the ICS-204 Assignment List.
4. Click **Save** to commit the changes.

18

ICS Planning Section <http://192.168.50.1/ics/planning.html>

The Planning Section manages the Incident Action Plan documents, resource status summary table, and operational period tracking. It is where the PSC assembles all the pieces of the IAP before each operational period briefing.

IAP Tracker Tab

1. Click the **IAP Tracker** tab.
2. Each required form (ICS-202 through ICS-208) is listed with a completion checkbox.
3. Check off each form as it is completed and added to the IAP package.
4. The tracker shows the percentage of IAP completion at the top.

Resource Status Summary

1. Click the **Resource Status** tab.
2. The table shows all resources by type with current status counts.
3. Click **+ Add Row** to manually add a resource category.
4. Counts update from the Operations Section T-card board automatically.

Incident Documents

1. Click the **Documents** tab to manage IAP-associated documents.
2. Click **+ Add Document** to link an uploaded reference document to this incident.
3. Enter the document title, form number, and notes.
4. Documents are linked to the incident for archival purposes.

■ The ICS-309 Communications Log (<http://192.168.50.1/ics309.html>) can be linked to any active incident from its own page. See Chapter 22 for details on the ICS-309 form.

19

ICS Logistics Section <http://192.168.50.1/ics/logistics.html>

Logistics provides all facilities, services, and materials that support the incident. It owns the communications plan and tracks supplies, food, medical, facilities, and check-in.

TAB	HOW TO USE IT
Comms Plan (ICS-205)	Build the radio communications plan. Each row is a channel: function, channel name, frequency, CTCSS tone, mode, remarks. Click Add Comms Row to add a channel. Pre-filled with McHenry County Starcom channels.
Supply	Log supply requests: item, category, quantity needed, quantity on hand, priority. A progress bar shows the fill rate. Use Add Supply .
Facilities	ICP location, base/camp details, staging area manager, and medical aid station info.
Food / Medical (ICS-206)	Meal service log (meal type, count served, menu) plus medical unit leader, ambulance status, hospital contacts.
Check-In (ICS-211)	Personnel check-in list. Records name, ICS position, agency, and arrival time. Links to the Member Roster for pre-populated entries.

20

ICS Finance / Admin Section <http://192.168.50.1/ics/finance.html>

Finance/Admin manages all financial aspects of the incident: cost accounting, time tracking, procurement, and administrative records for reimbursement.

TAB	HOW TO USE IT
Cost	Log expenditures: category (personnel, equipment, supply, food, transport), amount, description, vendor, and approver. A running total is shown. Use Add Cost .
Time	Log person-hours per operator: name, position, agency, hours worked, hourly rate (0 = volunteer). Used for reimbursement claims. Use Add Time .
Procurement	Track purchase orders: item, vendor, PO number, amount, status (Requested, Ordered, Delivered, Closed). Use Add Procurement .
Admin	Finance/Admin Section Chief info, billing agency, cost-share type, claim deadline, and supporting documentation notes.

- All finance data can be exported to CSV for submission to the agency finance officer or FEMA reimbursement process. Click **Export CSV** on any Finance tab.

2 1

NTS Radiogram Generator <http://192.168.50.1/nts.html>

Generate properly formatted ARRL National Traffic System radiograms. The form produces the standard preamble, address block, and text section, and keeps a traffic log.

Creating a Radiogram

1. Click **Auto-fill Number** for the next sequential message number, or enter one.
2. Set the **Precedence**: EMERGENCY, PRIORITY, WELFARE, or ROUTINE.
3. Choose **Handling Instructions** (HX codes) if needed — HXA through HXF.
4. Enter **Station of Origin**, **Place of Origin**, and click **Auto-fill Date/Time**.
5. Enter the addressee name, address, and phone.
6. Type the message **Text** in ARRL all-caps style. The Check (word count) calculates automatically.
7. Enter the **Signature**, then click **Generate Radiogram**.
8. Click **Save to Log** to keep a copy, then **Print** for the paper record.

Handling Instruction (HX) Codes

CODE	MEANING
HXA	Collect landline delivery authorized up to \$ amount
HXB	Cancel message if not delivered within X hours
HXC	Report date and time of delivery to originating station
HXD	Report to originating station the identity of station from which received
HXE	Delivering station get reply from addressee
HXF	Hold delivery until (date)
HXG	Delivery by mail or landline toll call not required

2 2

ICS-213 General Message <http://192.168.50.1/ics213.html>

The ICS-213 is the standard written message form for inter- and intra-agency communications on an incident. Use it when you need a written record of a request, situation update, or resource order.

Completing an ICS-213

1. Fill in the header: incident name, To, From, position/agency, date/time, and subject.
2. Click **Auto-fill** to populate the current date and time.
3. Type the message in the body.
4. Click **Generate Form** to render a print-formatted version.
5. Use the **Print** button to produce a field-ready paper copy.
6. Click **Save to Log** to keep a copy in the form log.

■ Use the ICS-213 for formal written traffic. For routine spoken radio traffic, use the Net Control log instead.

2 3

ICS-214 Activity Log & ICS-309 <http://192.168.50.1/ics214.html>

The ICS-214 is a unit-level activity log required for every ICS section and unit. It records personnel assigned and a timestamped log of activities through the operational period.

Completing an ICS-214

1. Enter the incident name, operational period, unit name, and unit leader.
2. Click **Add Personnel** to list each person assigned to the unit (name, position, agency).
3. For each activity, click **Add Entry**, then **Auto Timestamp** for the current time, and type what happened.
4. Entries accumulate in time order throughout the period.
5. Click **Generate Form** and **Print** for the incident record. **Save Local** keeps a copy on the device.

ICS-309 Communications Log

The companion ICS-309 page (Dashboard → ICS mode → ICS-309 Comms Log) records a formal communications log for the operational period. Each entry has a timestamp, from, to, and message subject. Click **Save to Incident** to file it with the active incident for after-action review.

1. Click **Add (timestamp now)** to add a row with the current UTC time.
2. Fill in From, To, and the message Subject for each entry.
3. Click **Generate Form** to render the printable ICS-309.
4. Click **Save to Incident** to file it in the incident record.

2 4

Winlink Form Import & Incident Archiving

<http://192.168.50.1/winlink-import.html>

Winlink Express has its own built-in ICS forms. This chapter explains how to bring that form data into the FieldComms server so the whole incident is documented and archived in one place — and how to re-print a received ICS-213, ICS-214, or ICS-309 on the Pi.

Step-by-Step Import

1. In Winlink Express, open the ICS form message (sent or received).
2. Right-click the **RMS_Express_Form_*.xml** attachment and save it to your computer.
3. On the Winlink Form Import page, drag the saved XML file onto the drop zone, or click Browse.
4. Click **Parse Form Data**. The page detects the form type and extracts all fields.
5. Review the extracted fields in the editable grid. Fix any fields that need correction.
6. Choose the Incident and Direction (Received/Sent), then click **Archive to incident**.

FORM	RE-PRINT ON PI?	NOTES
ICS-213 General Message	Yes	Re-renders as the Pi's ICS-213 for printing
ICS-214 Activity Log	Yes	Activity and personnel lines split into rows automatically
ICS-309 Comms Log	Yes	Log rows parsed into the comms log
Other Winlink forms	Archive only	Data captured and archived — no ICS re-print

Recommended Workflow

1. Run Winlink traffic in Express as your operators normally do.
2. At the end of each operational period, collect any RMS_Express_Form_*.xml files from operators.
3. Import them via the Winlink Form Import page to complete the incident record.
4. Cross-check the ICS-309 log with the Net Control log for completeness.

25

HF Propagation <http://192.168.50.1/propagation.html>

The propagation page fetches live solar and geomagnetic data from hamqsl.com (when internet is available) and uses it to estimate current HF band conditions.

Reading the Indicators

INDICATOR	WHAT IT MEANS FOR HF
SFI (Solar Flux)	Higher = better high-band propagation. >130 excellent; 90–130 good; <90 40m/80m only.
Sunspot Number	More sunspots = more solar activity = better HF. Follows the 11-year cycle.
A-Index	Daily geomagnetic activity. <10 quiet (good HF); 10–30 unsettled; >30 disturbed.
K-Index (0–9)	3-hour geomagnetic snapshot. ≤2 quiet; 3–4 unsettled; ≥5 storm (HF degraded); ≥7 severe.
X-Ray Flux Class	Solar flare class. A/B/C minor; M moderate (SID possible); X strong HF blackout risk.
Band Condition Bars	Green = good / Amber = fair / Red = poor for each band from 10m through 80m.

- When the Pi has no internet connection, the propagation page shows the last fetched values with a timestamp. For field activations without WAN, check propagation before departing on a device with internet, then switch to the offline Pi for the activation.

26

Repeater Database <http://192.168.50.1/repeaters.html>

The Repeater Database displays repeater data with rich filtering. It works in three modes: an offline file you load yourself (most reliable), the server API, or built-in sample data. Real repeater data comes from RepeaterBook.com.

The Three Sources

SOURCE	HOW TO USE IT
Offline File (recommended)	Load a RepeaterBook CSV or JSON export. Drag-and-drop the file onto the drop zone, or click Browse. Data persists in your browser after the first load. This needs no API token and is the most dependable method.
Server API	Pulls from the FieldComms server if the net manager has run <code>fetch_repeaters.py</code> to download RepeaterBook data. Requires a RepeaterBook API token.
Sample Data	Three placeholder entries (SAMPLE-1/2/3) for testing the interface. Shows a "not a real repeater" warning. Do not use for operations.

Filtering and Sorting

FILTER	OPTIONS
Band	2m, 70cm, 23cm, 6m, 10m, 1.25m
State	IL, WI, IN, IA (default), or any US state
Affiliation	ARES, SKYWARN, RACES, SATERN, EmComm
Mode	FM, DMR, C4FM/Fusion, D-STAR, P25, NXDN
Sort	Callsign, Frequency, City, Distance (nearest first)

- A systemd timer (`repeater-refresh.timer`) runs the fetch automatically on the first of each month at 04:00, as long as the token is saved in the `repeaterbook.env` file and the Pi has internet at that time.

2 7

Facilities Directory <http://192.168.50.1/facilities.html>

Maintain a directory of EOC locations, hospitals, shelters, staging areas, and command posts. Each entry stores address, coordinates, radio frequencies, CTCSS tone, contact person, on-site callsign, generator status, ADA access, capacity, and operational notes.

Default Facilities

On first startup, FieldComms seeds four McHenry County facilities: the McHenry County EOC (Woodstock), Centegra Hospital Woodstock, the McHenry County Fairgrounds staging area, and Centegra Hospital McHenry. Edit these with your actual operational details.

Managing Facilities

1. Click **+ Add** to create a facility, or click any facility card to view its full detail.
2. In the detail view, click **Edit** to change fields, or **Delete** to remove it.
3. Use **Copy Address** to copy the street address to clipboard for navigation apps.
4. Click **Export CSV** to download the full directory for offline reference.

2 8

Grid Square Calculator <http://192.168.50.1/grid.html>

Convert between decimal latitude/longitude and Maidenhead grid squares in both directions, and calculate distance and bearing between two grid squares. Supports 4-character (EN52) and 6-character (EN52ab) precision.

Using the Calculator

1. To convert coordinates to a grid square: enter latitude and longitude, click **Calculate from Lat/Lon**.
2. To convert a grid square to coordinates: enter the grid square, click **Calculate from Grid**.
3. To use your current location: click **Use My Location** (requires location permission, or uses the configured/GPS coordinates).
4. To find distance and bearing: enter two grid squares and click **Calculate Distance**.

The map on the page highlights the grid square on a North America outline for quick visual reference. McHenry County, IL is in grid square **EN52**.

29

Radio Cheat Sheets <http://192.168.50.1/cheatsheets.html>

A quick-reference set of radio and ICS cheat sheets, organized into tabs. No internet needed — everything is built in.

TAB	CONTENTS
Phonetic Alphabet	NATO phonetics A–Z with pronunciation, plus ITU number pronunciation (Zero, WUN, TOO, TREE, FOW-er, FIFE, SIX, SEV-en, AIT, NIN-er)
Q-Codes	Common amateur Q-codes (QRM, QRN, QRP, QSL, QTH...) and EmComm net Q-codes (QNI, QNS, QND, QNN...)
Prowords	Full procedure word reference — ROGER, WILCO, SAY AGAIN, BREAK, OVER, OUT, CORRECTION, SILENCE, AUTHENTICATE, and more, with meanings and examples
Band Plan	2m and 70cm segments, HF emergency frequencies (ARES, ARRL, IARU, 60m channels), and service bands (MURS, FRS, GMRS, Marine, Aviation)
NTS Precedence	EMERGENCY / PRIORITY / WELFARE / ROUTINE — definitions, when to use each, and examples
ICS Positions	Standard ICS command and general staff titles with abbreviations (IC, OSC, PSC, LSC, FSC, SO, IO, LO)
CTCSS/DCS Tones	Standard CTCSS tone table (67.0–254.1 Hz) and DCS code table for repeater access
Signal Reports	RST and RS signal report codes, S-meter calibration, and signal quality descriptions

30

Print Center <http://192.168.50.1/printcenter.html>

The Print Center is a one-stop hub for every printable document, plus a built-in incident cover-sheet generator.

CATEGORY	DOCUMENTS
ICS / NTS Forms	ICS-213 General Message, ICS-214 Activity Log, NTS Radiogram, Pre-Flight Checklist
Reference Cards	Phonetic Alphabet, Q-Codes & Prowords, ICS Structure & Forms, CTCSS/DCS & Signal Reports
Operations	Net Control Log (ICS-309), Starcom Net Log (ICS-309), Member Roster, Resource Board
Cover Sheet	Generate a formatted IAP cover sheet from incident details

Generating an Incident Cover Sheet

1. Fill in incident name, number, IC, operational period, frequency, location, and situation summary.
2. Click **Generate Cover** to preview it in the page.
3. Click **Print Cover** to print it in a new window.
4. Click **Clear** to reset the form.

Connecting a Printer to EMCOMM-NET

FieldComms has print buttons on 17 pages. All printing uses the browser standard print function — it sends the job to whatever printer the operator's browser can reach. Three options are supported:

OPTION	HOW IT WORKS	BEST FOR
A — Own printer	Each operator prints to their own locally connected printer. No Pi setup needed.	Single operator with their own printer
B — USB printer via Pi (CUPS)	USB printer plugged into the Pi. CUPS shares it across EMCOMM-NET. Installed automatically. Admin at http://192.168.50.1:631 . Supports Windows, Mac, iOS AirPrint, Android, Chromebook.	Field activations — one shared printer for all operators
C — Network printer	Wi-Fi or Ethernet printer connected directly to EMCOMM-NET. Devices discover it via Bonjour/mDNS automatically.	Sites with an existing Wi-Fi capable printer

Setting Up Option B — USB Printer via CUPS

1. Plug the USB printer into the Pi or powered USB hub.
2. Open <http://192.168.50.1:631> from any device on EMCOMM-NET.
3. Click **Administration** → **Add Printer** and log in with the Pi username/password.
4. Select the printer from Local Printers. Check **Share This Printer**. Click Continue.
5. Select the driver, click Add Printer, then print a test page.
6. Windows: Settings → Printers → Add a printer — it appears automatically on EMCOMM-NET.

7. iOS/iPad: tap Share → Print in any FieldComms page — AirPrint finds it automatically.

8. Android: install CUPS Print app → add printer at 192.168.50.1 port 631.

- Recommended field printers: **Brother HL-L2350DW** (laser, excellent Linux support), **Canon PIXMA TR150** or **HP OfficeJet 200** (battery-powered portable options). See the Installation Guide Step 8 for full setup instructions and the complete comparison of all three printer connection options.

3 1

Reference Library <http://192.168.50.1/refs.html>

The Reference Library is a document-management system for all field reference materials — radio manuals, interoperability plans, ICS form packages, SOGs, agency plans, and training documents. Files are stored on the Pi and accessible from any device on EMCOMM-NET.

TAB	CONTENTS
■ Amateur Radio	Radio manuals, frequency plans, ARRL publications, band plans, antenna refs
■ ICS / Emergency Mgmt	SWIC plans, NIMS docs, ICS form packages, agency SOGs, mutual aid plans
■ All Documents	Every uploaded document regardless of category

Uploading a Document

1. Click ■ **Upload Document**. A panel slides in from the right.
2. Drag-and-drop a file or click Browse. Accepts PDF, Word, Excel, PowerPoint, images, KML, ZIP, GPX — up to 200 MB.
3. Fill in Title, Category, Source, Description, Tags, Revision, and Expiry (if relevant).
4. Under **Show on tab(s)**, check Amateur Radio, ICS/EmMgmt, or both.
5. Click ■ **Upload Document**. PDFs get an automatic thumbnail.

Finding Documents

1. Use the Category filter, tag cloud, or sort options (Newest, Title, Most Downloaded).
2. Switch between grid and list view using the view toggle.
3. Click any document to open its detail, then Download, Edit, or Delete.

3 2

Kiwix Offline Library <http://192.168.50.1:8081/>

Kiwix serves a complete offline reference library from the Pi on port 8081. Every device on EMCOMM-NET can browse it with no internet. Content is stored as ZIM files — compressed, self-contained web archives organized into tiers by size and operational value.

Accessing Kiwix

Open a browser to **<http://192.168.50.1:8081>**, or tap the Kiwix Library card on the dashboard. Kiwix has a built-in full-text search bar that searches across all installed content at once — type any symptom, procedure, or topic and results appear instantly, offline.

Content Catalogue

TIER	CONTENT	SIZE	BEST FOR
1	WikiMed Medical Encyclopedia	~471 MB	Mass-casualty events, medical support
1	Wikipedia (Mini)	~1.2 GB	General field reference, briefings
1	Wikivoyage	~820 MB	Maps, local facilities, travel info
2	iFixit Repair Guides	~2.3 GB	Equipment repair in the field
2	Wikipedia (Full EN)	~22 GB	Complete reference — large download

Adding a Custom ZIM

1. Download a ZIM from kiwix.org to a device with internet.
2. Copy it to the Pi: `scp mybook.zim fieldcomms@192.168.50.1:/opt/kiwix/zim/`
3. Register it: `sudo kiwix-manage /opt/kiwix/library.xml add /opt/kiwix/zim/mybook.zim`
4. Restart: `sudo systemctl restart kiwix`
5. Open <http://192.168.50.1:8081> — the new content appears.

33

Offline Maps, GPS & Health Monitor

This chapter covers three infrastructure features: the offline map tile system, GPS live position, and the system Health Monitor.

32.1 Offline Map Tile System

Map tiles are downloaded in advance, stored as MBTiles files on the Pi, and served locally on port 8083. Both the Tactical APRS Map and Starcom Resource Map use offline tiles by default. The default source is USGS Imagery+Topo Hybrid — public-domain satellite imagery with roads, contours, and place names.

Downloading Tiles

1. Run `sudo bash /opt/fieldcomms/scripts/download_tiles.sh` for the interactive menu (106 presets: all Illinois counties, WI/IN/IA border counties, all 50 states).
2. Search presets: `download_tiles.sh --search "mchenry"`
3. Download a preset: `download_tiles.sh --area "McHenry County IL" --zoom 8-16`
4. Tiles are stored in `/opt/fieldcomms/data/tiles/` and served by the tile server on port 8083.

32.2 GPS Live Position

If a USB GPS receiver is connected to the Pi (via the powered USB hub), `gpsd` provides live coordinates to the tactical map, health monitor, and NWS alerts. The GPS receiver creates a stable `/dev/gps0` device via `udev` rules installed automatically.

CHECK	COMMAND
GPS status	<code>gpspipe -w -n 5</code>
GPS device	<code>ls -la /dev/gps0</code>
gpsd status	<code>sudo systemctl status gpsd</code>
Live fix data	<code>cgps -s</code>

32.3 Health Monitor

The health monitor runs as a background service on port 5051 and feeds the dashboard sidebar with live system diagnostics. Raw data is at <http://192.168.50.1:5051/health>.

METRIC	NORMAL	ACTION IF EXCEEDED
CPU Temperature	< 70°C	Improve ventilation. Pi 5 throttles at 85°C.
Memory Usage	< 80%	Close unused browser tabs; restart non-essential services
Disk Usage	< 90%	Archive old logs; remove unused ZIM files
Service Status	All green	Red dot = service down. Restart with <code>systemctl</code> .

Internet	Connected (if avail.)	Check Ethernet. Core features work offline.
GPS	Fix (if attached)	No GPS is fine — coordinates configured at install.

Restarting a Stopped Service

`sudo systemctl restart fcc-lookup # or: health-monitor, ics-platform, fieldcomms-refs, kiwix, deadmans`

34

Network Hardware — ASUS RT-BE58 Go & UniFi Switch Flex 2.5G

FieldComms v1.0 uses a dedicated Wi-Fi 7 travel router and a 2.5 GbE managed switch instead of the Pi broadcasting its own Wi-Fi hotspot. This gives every device on scene a faster, more reliable connection and lets the Pi focus entirely on serving the FieldComms application.

Network Architecture Overview

DEVICE	ROLE	CONNECTION
ASUS RT-BE58 Go	Wi-Fi 7 access point + DHCP server + WAN gateway	WAN: Ethernet uplink or USB tether · LAN: 2.5G to UniFi switch
UniFi Switch Flex 2.5G-5	5-port 2.5 GbE wired distribution switch	Port 1 (PoE in): uplink to ASUS router · Ports 2–5: Pi, TNC, EOC laptop, spare
Raspberry Pi 5 (16 GB)	FieldComms application server	Wired 2.5 GbE via UniFi switch · Static IP: 192.168.50.1
Windows Laptop	Winlink Express + JS8Call + IC-7300	Wi-Fi (EMCOMM-NET) or wired via UniFi switch

33.5 ASUS RT-BE58 Go Setup

1. Connect a device to the router (Wi-Fi or Ethernet) and open **http://192.168.50.1** (default gateway).
2. Change the LAN IP to **192.168.50.1** (LAN → LAN IP).
3. Set the subnet to **255.255.255.0**.
4. Set DHCP range to **192.168.50.100 – 192.168.50.200**.
5. Disable the router's Wi-Fi security on the management interface — the router LAN IP becomes the FieldComms server IP once the Pi is assigned 192.168.50.1 via nmcli.
6. Set the Wi-Fi SSID to **EMCOMM-NET** on both 2.4 GHz and 5 GHz bands.
7. Set a strong WPA3/WPA2 password. Apply.

Write down the ASUS router admin password and store it on a USB drive labeled FIELDCOMMS. If the router is factory-reset in the field you will need it to reconfigure the LAN subnet and SSID before FieldComms is accessible.

33.7 Power Budget & Field Deployment Notes

DEVICE	TYPICAL DRAW	NOTES
Raspberry Pi 5 (16 GB)	~12–25W	Higher under load (FCC search, APRS, all services active)
ASUS RT-BE58 Go	~8–12W	USB-C powered — power bank compatible
UniFi Switch Flex 2.5G	~10–18W	PoE input from router or separate adapter
Raspberry Pi Monitor	~5–8W	USB-C powered from Pi USB port or separate supply

Windows Laptop	~30–65W	Varies widely — use laptop power supply, not power bank
----------------	---------	---

33.8 Extending Coverage — ASUS AiMesh

A single ASUS RT-BE58 Go covers approximately 2,000–2,500 sq ft. For larger deployments, add one or more AiMesh nodes. All nodes share the same EMCOMM-NET SSID and 192.168.50.x subnet. Devices roam automatically — the Pi remains at 192.168.50.1 regardless of which node a device connects through.

SCENARIO	RECOMMENDED SETUP
Single room EOC ($\leq$ 2,500 sq ft)	1× RT-BE58 Go primary only — no extension needed
Multi-room / large shelter (2,500–7,500 sq ft)	1× primary + 1 AiMesh node (wireless or wired backhaul)
Large building or campus ($>$ 7,500 sq ft)	1× primary + 2–3 nodes, wired backhaul recommended
Outdoor SAR staging area	Primary at command post + battery-powered nodes at field positions

- 1. Factory reset the node.** Hold reset 5–10 seconds until LED flashes.
- 2. Power on the node** within 30 ft of the primary for initial pairing.
- 3.** On the primary router: **AiMesh** → **Add AiMesh Node**. Select the node and click Connect.
- 4. Move the node** to its final position once pairing completes.
- 5. Test coverage** by walking the area with a phone on EMCOMM-NET.

- Up to 8 AiMesh nodes are supported. Pairing takes under 5 minutes on site. For wired Ethernet backhaul, run a CAT 6 cable from any UniFi switch port to the node LAN port — AiMesh detects the wired connection automatically.

3 5

JS8Call — HF Digital Keyboard Messaging (Windows)

JS8Call is a weak-signal HF digital mode designed for keyboard-to-keyboard messaging, store-and-forward relay, and group nets — all without an internet connection. It runs on the Windows laptop alongside Winlink Express, connected to the IC-7300 via USB. The FieldComms dashboard provides a quick-launch card that opens JS8Call's built-in web interface from any device on EMCOMM-NET.

What JS8Call Does

CAPABILITY	DESCRIPTION
Keyboard-to-keyboard	Type messages directly to any JS8 station within range — no internet required
Store and forward	Messages are relayed station-to-station across multiple hops when no direct path exists
Group / net messaging	Send a message addressed to a group callsign (e.g. @EMCOMM); any station in the group receives it
Heartbeats	Periodic automatic transmissions that advertise station presence — great for EmComm awareness
APRS-like reporting	Station info (grid, frequency, status) reported to JS8Call.info when internet is available

Enabling the JS8Call API

1. In JS8Call, go to **File** → **Settings** (or press F2).
2. Click the **Reporting** tab.
3. Set **TCP Server Hostname** to **0.0.0.0** (allows any device on EMCOMM-NET to connect).
4. Check **Enable TCP Server API**.
5. Verify **TCP Server Port** is set to **2442**.
6. Check **Accept TCP Requests**.
7. Check **Allow setting station information from network**.
8. Click OK. Restart JS8Call for the settings to take effect.

Using JS8Call from FieldComms

1. Note the Windows laptop's IP address on EMCOMM-NET: run `ipconfig` in Command Prompt and look for the 192.168.50.x address.
2. On any EMCOMM-NET device, open FieldComms and tap the **JS8Call** card.
3. A prompt appears asking for the Windows laptop's IP address.
4. Enter the IP address (e.g. 192.168.50.105). Click OK.
5. The card opens JS8Call's web interface at `http://192.168.50.105:2442`.
6. The IP is saved on that device. Future taps open JS8Call directly.



Never leave both Winlink Express and JS8Call connected to the IC-7300 in an active session simultaneously — they will key over each other. Close or disconnect one before activating the other.

Recommended JS8Call Frequency

7.078 MHz USB-D — the 40m JS8Call calling frequency. Also used: 14.078 MHz (20m), 3.578 MHz (80m for regional/night operations).

36

ICS Planning P — Operational Planning Cycle

<http://192.168.50.1/ics/planningp.html>

The Planning P page is an interactive guide to the ICS operational planning cycle. It presents all 15 phases of the Planning P — from the initial incident through each operational period — with the standard agenda, required ICS forms, and attendee list for every phase. Access it from the **■ Planning P** tab on any ICS platform page.

The 15 Phases

PHASE	NAME	KEY FORMS
1	Incident / Event	ICS-201 (begin)
2	Notification	ICS-201
3	Initial Response & Assessment	ICS-201
4	Initial UC Meeting	ICS-201, ICS-202
5	Incident Brief — ICS-201	ICS-201
6	IC/UC Develop/Update Objectives Meeting	ICS-202
7	Command & General Staff Meeting/Briefing	ICS-202, ICS-203
8	Preparing for the Tactics Meeting	ICS-215, ICS-215A
9	Tactics Meeting	ICS-215, ICS-215A, ICS-203, ICS-204
10	Preparing for the Planning Meeting	ICS-204, ICS-205, ICS-206, ICS-207, ICS-208
11	Planning Meeting	ICS-202 through ICS-206
12	IAP Prep & Approval	ICS-202 through ICS-208 (complete IAP)
13	Operations Briefing	Complete IAP, ICS-204 by Division
14	Execute Plan & Assess Progress	ICS-214, ICS-209, ICS-309
15	New Ops Period Begins	ICS-214, ICS-209

Using the Planning P Page

1. Open the ICS Platform (<http://192.168.50.1/ics/>) and click the **■ Planning P** tab.
2. The reference image of the official Planning P diagram is shown on the left for reference.
3. The 15 phase buttons are listed in the center panel, organized into five color-coded groups.
4. Click any phase button to see its details in the right panel.

Phase Detail Panel

SECTION	WHAT IT SHOWS
Standard Agenda	Numbered list of the standard agenda items for that meeting or activity
Required Forms	ICS form numbers as clickable chips — click to open the form directly
Who Should Attend	List of ICS roles required or optional for that phase, with red/green roster dots showing who is currently checked in

The Phase Color Groups

COLOR	GROUP	PHASE S	ICS PHASE OF PLANNING
Gray	Initial Response	1–5	Stem — initial incident response
Yellow	Establish Objectives	6–7	Stem — incident objectives set by IC/UC
Red	Develop the Plan	8–11	Loop — tactics through planning meeting
Green	Prepare & Disseminate	12–13	Loop — IAP approval and ops briefing
Teal	Execute, Evaluate & Revise	14–15	Loop — field operations and next period

Generating a Briefing Sheet

1. Select any phase by clicking its button.
2. Click **Generate briefing sheet** in the detail panel.
3. A printable one-page cover sheet opens with the phase name, agenda, required forms, and an attendance table with signature lines.
4. Print it for the IAP package or the planning meeting folder.

■ The Planning P page is a guide, not a workflow enforcer. You do not need to click through the phases in order. Use it as a quick reference during planning meetings to ensure nothing is missed — especially on activations where the planning cycle is compressed.

3 4

Appendix — Administration & Quick Reference

A1 Installation & Updates

COMMAND	WHAT IT DOES
<code>sudo bash install.sh</code>	Interactive installer — sets callsign, coordinates, Wi-Fi, services
<code>sudo bash update.sh</code>	Updates FieldComms code and restarts services
<code>sudo bash kiwix_setup.sh</code>	Install/manage Kiwix offline content
<code>sudo bash download_tiles.sh</code>	Download offline map tiles

A2 Wi-Fi & Network

ITEM	DETAIL
SSID	EMCOMM-NET
Pi IP	192.168.50.1 (static, set via nmcli on eth0)
DHCP range	192.168.50.100 – 192.168.50.200
Router admin	http://192.168.50.1 (ASUS RT-BE58 Go)
CUPS admin	http://192.168.50.1:631 (printer management)

A3 Database Backup

The main database is a single SQLite file. Back it up by copying **fieldcomms.db** to a USB drive. Export the roster CSV monthly and keep a copy on a USB drive labeled FIELDCOMMS as a secondary backup. Plugging in a drive labeled FIELDCOMMS automatically triggers a full rsync backup of the application data via the udev backup rule.

A4 Winlink — Email Over Radio

MCESV/MCEMA uses **Winlink Express** as the primary Winlink client on the Windows laptop with the IC-7300 + VARA HF. The Pi also runs **Pat** as a backup browser-based Winlink client on port 8090. Never run both clients with an active session on the same radio simultaneously.

A5 Service & Port Reference

SERVICE	PORT	DESCRIPTION
nginx	80	Web server — serves all HTML pages
fcc-lookup.service	5050	FCC callsign API, net log, forms, DMS, roster, resources
health-monitor.service	5051	System health API

ics-platform.service	5055	ICS incident platform API
fieldcomms-refs.service	5056	Reference library API
Graywolf APRS	8080	APRS client with REST API and WebSocket
Kiwix	8081	Offline library — WikiMed, Wikipedia, iFixit
YAAC APRS	8082	Secondary APRS client
Tile server	8083	Offline map tile server (MBTiles)
Pat Winlink	8090	Browser-based backup Winlink client
CUPS printer	631	Print server — USB printer shared to EMCOMM-NET
JS8Call (Windows)	2442	JS8Call TCP API on Windows laptop

Operator Workstation Options — Raspberry Pi 500 / 500+ + Raspberry Pi Monitor

FieldComms is a browser-based system — any device with a modern browser and Wi-Fi can connect to EMCOMM-NET and access every tool. The Raspberry Pi 500 paired with the official Raspberry Pi Monitor provides a purpose-built, low-cost, low-power operator workstation that is fully Pi ecosystem compatible and ideal for fixed EOC positions, shelter check-in stations, and net control operator desks. Funding through ARPA-E grants, FEMA BRIC, or 501(c)(3) equipment donations may cover these workstations.

Pi 500 vs Pi 500+ vs Pi 400 — Comparison

SPEC	Pi 400 (2020)	Pi 500 (Dec 2024) ★ Recommended	Pi 500+ (Sept 2025)
Processor	Cortex-A72 @ 1.8 GHz (Pi 4 generation)	Cortex-A76 @ 2.4 GHz (Pi 5 generation)	Cortex-A76 @ 2.4 GHz (Pi 5 generation)
RAM	4 GB DDR4	8 GB LPDDR4X	16 GB LPDDR4X
Storage	microSD only	microSD only (32 GB A2 included)	256 GB NVMe built-in + microSD slot
Keyboard	Membrane	Membrane	Mechanical (Gateron Blue KS-33)
Wi-Fi	802.11ac dual-band	802.11ac dual-band	802.11ac dual-band
Ethernet	Gigabit	Gigabit	Gigabit
USB ports	2× USB 3.0, 1× USB 2.0	2× USB 3.0, 1× USB 2.0	2× USB 3.0, 1× USB 2.0
Display output	2× micro-HDMI	2× micro-HDMI	2× micro-HDMI
Production until	Jan 2028	TBD (current model)	TBD (current model)
Best for FieldComms?	Acceptable — older chip, only 4 GB RAM	✓ YES — Pi 5 chip, 8 GB RAM, current generation	Overkill for browser use Justified only if also running heavy Linux apps locally

Raspberry Pi Monitor — 15.6"

SPEC	DETAIL
Panel	15.6" IPS LCD, 1920×1080 Full HD @ 60 Hz
Video input	Standard HDMI 1.4 (full-size) — requires micro-HDMI to HDMI cable with Pi 500
Audio	2× front-facing stereo speakers, 3.5mm headphone jack
Power	USB-C, 5V/1.5A — can power from Pi 500 USB port at 60% brightness/volume, or from separate USB-C supply for 100% brightness/volume
Mounting	Integrated angle-adjustable kickstand, VESA mount, wall hanger
Dimensions	Slim 15.6" form — similar footprint to a laptop
Colors	Red/White (matching Pi 500 keyboard) or Black
Where to buy	raspberrypi.com · Adafruit · PiShop.us · GigaParts · Amazon

The Pi 500 has micro-HDMI ports; the Raspberry Pi Monitor has a standard full-size HDMI input. You need a micro-HDMI to standard HDMI cable (or adapter). The Pi 500 desktop kit (\$120) includes one. When ordering separately, confirm the cable is included or purchase one — they are available from the same retailers listed above.

Operator Workstation — Bill of Materials (Per Station)

ITEM	MODEL / SPEC	WHERE TO BUY
— Standard Workstation (Pi 500) —		
Raspberry Pi 500 keyboard computer	Pi 500 standalone — Pi 5 chip, 8 GB RAM, 32 GB A2 microSD, keyboard	raspberrypi.com Adafruit · Amazon
Raspberry Pi Monitor	15.6" Full HD IPS, built-in speakers, kickstand, VESA mount	raspberrypi.com GigaParts · Amazon
micro-HDMI to HDMI cable	1m micro-HDMI to standard HDMI (Pi 500 → Monitor) Included in Pi 500 Kit (\$120) — verify before ordering separately	raspberrypi.com Amazon
USB mouse	Any USB or Bluetooth mouse — included in Pi 500 Kit	Amazon
USB-C power supply for Pi 500	Official Raspberry Pi 27W USB-C PD power supply (or equivalent)	raspberrypi.com Amazon
USB-C power supply for monitor (optional, for full brightness)	5V/1.5A USB-C supply — skip if powering monitor from Pi USB port (Pi USB port gives 60% brightness which may be dim outdoors)	Amazon
— Premium Workstation (Pi 500+) —		
Raspberry Pi 500+ keyboard computer	Pi 500+ — Pi 5 chip, 16 GB RAM, 256 GB NVMe SSD, mechanical keyboard (Gateron Blue), RGB	raspberrypi.com Adafruit · Amazon
Raspberry Pi Monitor + cables + mouse	Same as Standard Workstation above	Same as above

501(c)(3) Grant Funding Note: MCEMV/MCEMA is a 501(c)(3) nonprofit. Operator workstation equipment may be eligible for funding through: FEMA BRIC (Building Resilient Infrastructure & Communities), ARPA-E Emergency Communications grants, ARRL Foundation grants, local Community Foundation equipment grants, or AUXCOMM/ARES regional funding. Document each workstation as "emergency communications operator terminal for the McHenry County Emergency Services Volunteers (K9ESV), a 501(c)(3) nonprofit supporting McHenry County Emergency Management Agency (MCEMA) RACES/ARES/Starcom communications."

Recommended Deployment by Position

POSITION	RECOMMENDED DEVICE	REASON
Net Control Operator (fixed EOC desk)	Pi 500 + Pi Monitor	Dedicated keyboard, good display, Chromium runs every FieldComms page smoothly
ICS Section Chief (Planning, Ops, Logistics)	Pi 500 + Pi Monitor or Windows/Mac laptop	Needs reliable keyboard for ICS form entry; Pi 500 is sufficient for all ICS platform pages
Served Agency Staff (EOC or shelter)	Any tablet, Chromebook, or Pi 500	Observer Mode and ICS forms work on any browser — no special hardware needed
Winlink / JS8Call Operator	Windows laptop (required)	Winlink Express and JS8Call are Windows applications — Pi 500 cannot run them natively

Mobile / Field Operator	Phone or tablet	FieldComms works on any smartphone browser on EMCOMM-NET — no dedicated hardware needed
-------------------------	-----------------	---

■ The Pi 500 cannot run Windows applications natively. Winlink Express and JS8Call must run on the Windows laptop connected to the IC-7300. The Pi 500 is ideal for all browser-based FieldComms tools — net control logging, ICS forms, tactical maps, resource tracking, and the full ICS platform.