4010ES OPERATING INSTRUCTIONS
FOLLOWING AN ALARM, SUPERVISORY, OR TROUBLE CONDITION



YOUR SAFETY AND THE SAFETY OF THOSE AROUND YOU ALWAYS COMES FIRST.
Actions taken during a fire depend upon local practices. Be sure you know what to do.

Systems Using Individual Acknowledge

ALARM
RED LED FLASHES AND TONE ALERT PULSES



Acknowledging Alarms

1. Unlock and open the panel door. The appearance of the alphanumeric display depends on whether the Display 1st Alarm Option is enabled or not.
   - **If Display 1st Alarm Option is enabled.** The display alternates between two screens similar to Screen 1 and Screen 2 below.
   - **If Display 1st Alarm Option is not enabled**. Only a screen similar to Screen 1 appears, indicating the total number of alarm conditions present on the system.

Screen 1

```
**FIRE**                Press (ACK) to review.
FIRE = 1    PRI2=0      SUPV=0      TRBL=0
```

Screen 2

```
FIRST FLOOR EAST WING     ROOM 31
PULL STATION
```

2. Press the <FIRE ALARM ACK> key under the flashing red LED. Read and follow the instructions on the alphanumeric display. Repeat this procedure until all alarms are acknowledged. When all alarms are acknowledged, the tone-alert silences and the ALARMS LEDS change from flashing to ON steady.

Silencing the Signals

Press the ALARM SILENCE key and read the display. The alphanumeric display reads “ALARM SILENCE IN PROGRESS” and the ALARM SILENCED LED turns on steady.

Resetting the System With Active Alarms

1. Press the SYSTEM RESET key. The alphanumeric display reads “SYSTEM RESET IN PROGRESS”.
2. If all zones or devices in alarm reset, the ALARMS LEDs flash. Press the FIRE ALARM ACK or the PRIORITY 2 ACK key, or both. The message “SYSTEM IS NORMAL” appears.
3. If a zone or a device remains in alarm and fails to reset, the message “ALARM PRESENT, SYSTEM RESET ABORTED” appears.
4. Read the display to determine the type and the location of the device(s) in alarm. Follow local procedures to investigate the area of the building in alarm. Look for devices in the alarm state, for example, pull stations with the handle down, or smoke detectors with the LED lit.

Performing a Hardware Reset

To perform a hardware reset, press the SYSTEM RESET key when no alarms are present.

SUPERVISORY/TROUBLE
YELLOW LED FLASHES AND TONE ALERT ON STEADY



Acknowledging Supervisory or Trouble Conditions

1. Unlock and open the panel door. The alphanumeric display shows the number of abnormal conditions. (This example describes managing a Trouble condition. A Supervisory condition is handled similarly.)

```
**TROUBLE**             Press (ACK) to review.
FIRE = 0    PRI2=0      SUPV=0      TRBL=1
```

2. Press the <TROUBLE ACK> key under the flashing yellow LED. Read and follow instructions on the alphanumeric display. The display shows the area and type of problem.

```
  FIRST FLOOR EAST WING       ROOM 31
    Press ACK key to acknowledge
FIRE MONITOR ZONE OPEN CKT TROUBLE
```

3. Investigate the problem to determine its cause.
4. If a Trouble condition exists, restore or replace the defective equipment (switch, wire, device, etc.) in accordance with the equipment’s instructions.

   Note: When the abnormal condition causing the trouble clears, the yellow LED flashes and the tone-alert sounds steadily.
5. Press the <TROUBLE ACK> key under the flashing yellow LED. The alphanumeric display shows the system status.
6. Press the <TROUBLE ACK> key again. After a delay the system shows the following:

```
          SYSTEM IS NORMAL
       9:27:40    TUE 29 NOV 00
```

If the Trouble Does Not Clear

1. If the trouble is a Style D initiating device circuit trouble, a City Circuit trouble, or a 24 Point I/O trouble, press the SYSTEM RESET key.
2. If the trouble does not clear or toggles and reappears, you may choose to disconnect the device or disable the point.

Note: A disabled point does not report alarm conditions or other status changes. Appropriate steps must be taken to provide alternate means of protecting the area covered by the disabled point. Repair or replace the failed device or circuit as soon as possible and reenable the point.

In case of trouble, notify:

Name: _____

Address _____

Phone # _____

FRAME AND MOUNT THESE INSTRUCTIONS ADJACENT TO THE PANEL.
SEE OPERATOR’S MANUAL FOR DETAILED OPERATION.

AUTOCALL

© 2017 Johnson Controls. All rights reserved. All specifications and other information shown were current as of document revision and are subject to change without notice. Additional listings may be applicable, contact your local Autocall® product supplier for the latest status. Listings and approvals under Tyco Fire & Security GmbH, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited. NFPA 72 and National Fire Alarm Code

579-995AC Rev. A

4010ES OPERATING INSTRUCTIONS
FOLLOWING AN ALARM, SUPERVISORY, OR TROUBLE CONDITION



YOUR SAFETY AND THE SAFETY OF THOSE AROUND YOU ALWAYS COMES FIRST.
Actions taken during a fire depend upon local practices. Be sure you know what to do.

Systems Using Global Acknowledge

ALARM
RED LED FLASHES AND TONE ALERT PULSES



Acknowledging Alarms

1. Unlock and open the panel door. The appearance of the alphanumeric display depends on whether the Display 1st Alarm Option is enabled or not.
   - **If Display 1st Alarm Option is enabled.** The display alternates between two screens similar to Screen 1 and Screen 2 below.
   - **If Display 1st Alarm Option is not enabled**. Only a screen similar to Screen 1 appears, indicating the total number of alarm conditions present on the system.

Screen 1

```
**FIRE**                Press (ACK) to review.
FIRE = 1    PRI2=0      SUPV=0      TRBL=0
```

Screen 2

```
FIRST FLOOR EAST WING     ROOM 31
PULL STATION
```

2. Press the <FIRE ALARM ACK> key under the flashing red LED. Read and follow the instructions on the alphanumeric display. The tone-alert silences and the ALARMS LED changes from flashing to ON steady.

Silencing the Signals

Press the ALARM SILENCE key and read the display. The alphanumeric display reads “ALARM SILENCE IN PROGRESS” and the ALARM SILENCED LED turns on steady.

Resetting the System With Active Alarms

1. Press the SYSTEM RESET key. The alphanumeric display reads “SYSTEM RESET IN PROGRESS”.
2. If all zones or devices in alarm reset, the ALARMS LEDs flash. Press the FIRE ALARM ACK or the PRIORITY 2 ACK key, or both. The message “SYSTEM IS NORMAL” appears.
3. If a zone or device remains in alarm and fails to reset, the message “ALARM PRESENT, SYSTEM RESET ABORTED” appears.
4. Read the display to determine the type and the location of the device(s) in alarm. Follow local procedures to investigate the area of the building in alarm. Look for devices in the alarm state, for example, pull stations with the handle down, or smoke detectors with the LED lit.

Performing a Hardware Reset

To perform a hardware reset, press the SYSTEM RESET key when no alarms are present.

SUPERVISORY/TROUBLE
YELLOW LED FLASHES AND TONE ALERT ON STEADY



Acknowledging Supervisory or Trouble Conditions

1. Unlock and open the panel door. The alphanumeric display shows the number of abnormal conditions. (This example describes managing a Trouble condition. A Supervisory condition is handled similarly.

```
**TROUBLE**             Press (ACK) to review.
FIRE = 0    PRI2=0      SUPV=0      TRBL=1
```

2. Press the <TROUBLE ACK> key under the flashing yellow LED. The display shows the area and type of problem. The tone alert silences and the yellow LED turns on steady.
3. Read the alphanumeric display to determine the cause of the trouble.
4. If a Trouble condition exists, restore or replace the defective equipment (switch, wire, device, etc.) in accordance with the equipment’s instructions.

   The Trouble condition automatically clears when the problem has been corrected.

   After a short delay, the system returns to normal and displays the following.

```
          SYSTEM IS NORMAL
       9:27:40    FRI 15 SEP 00
```

If the Trouble Does Not Clear

1. If the trouble is a Style D initiating device circuit trouble, a City Circuit trouble, or a 24 Point I/O trouble, press the SYSTEM RESET key.
2. If the trouble does not clear or toggles and reappears, you may choose to disconnect the device or disable the point.

Note: A disabled point does not report alarm conditions or other status changes. Appropriate steps must be taken to provide alternate means of protecting the area covered by the disabled point. Repair or replace the failed device or circuit as soon as possible and reenable the point.

In case of trouble, notify:

Name: _____

Address _____

Phone # _____

FRAME AND MOUNT THESE INSTRUCTIONS ADJACENT TO THE PANEL.
SEE OPERATOR’S MANUAL FOR DETAILED OPERATION.

AUTOCALL

© 2017 Johnson Controls. All rights reserved. All specifications and other information shown were current as of document revision and are subject to change without notice. Additional listings may be applicable, contact your local Autocall® product supplier for the latest status. Listings and approvals under Tyco Fire & Security GmbH, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited.

579-995AC Rev. A