4100ES/4010ES ES Touch Screen Display OPERATING INSTRUCTIONS FOLLOWING AN ALARM, SUPERVISORY, OR TROUBLE CONDITION

YOUR SAFETY AND THE SAFETY OF THOSE AROUND YOU ALWAYS COMES FIRST.
Actions taken during a fire depend upon local practices. Be sure you know what to do.

Systems Using Individual Acknowledge

ALARM AND PRIORITY 2
RED LED FLASHES AND TONE ALERT PULSES



1. Unlock and open the panel door. You will see an Event List display. The display shows the highest priority events in the system. In all displays, the point status and the custom label will displayed. This example describes managing an Alarm condition. A PRIORITY 2 condition is handled similarly.

   Note: The LED for Priority 2 can be configured as blue or red.

2. Press the ALARM ACK key above the flashing red LED or a cell in the active list. Read and follow the instructions on the display. The display shows the zone and type of problem. The tone-alert momentarily silences and then resounds. Continue to press the cells or the ALARM ACK key until all trouble conditions are acknowledged.

Silencing the Signals

1. Press the ALARM SILENCE hardware key/touch screen key and read the display. The alphanumeric display reads “ALARM SILENCE IN PROGRESS” and the ALARM SILENCE LED turns on steady.

Resetting the System

1. When the alarm condition has been cleared, restore or replace all affected devices (smoke detectors, motion sensors, etc.) in accordance with the instructions provided with each device.
2. Reset the system as follows:
   - FIRE ALARM condition. Press the SYSTEM RESET key.
   - PRIORITY 2 ALARM condition. Depending on the system configuration, reset the alarm condition using the PRIORITY 2 reset key.

   After a delay, the red LED flashes and the tone-alert sounds with a pulsing tone.
3. Press the ALARM ACK key under the flashing red LED. Continue to press the ALARM ACK key until all alarm conditions have been acknowledged.
4. After a delay, the LED goes off.

SUPERVISORY/TROUBLE
YELLOW LED FLASHES AND TONE ALERT ON STEADY



1. Unlock and open the panel door. The display shows the number of abnormal conditions. This example describes managing a Trouble condition. A Supervisory condition is handled similarly.
2. Press the TROUBLE ACK key above the flashing yellow LED or a cell in the active list. Read and follow the instructions on the display. The display shows the zone and type of problem. The tone-alert momentarily silences and then resounds. Continue to press the cells or the TROUBLE ACK key until all trouble conditions are acknowledged.
3. Tap the status message again to review the abnormal status. The display shows the area and type of problem, the tone-alert silences, and the SYSTEM TROUBLE LED turns on steady. Read the alphanumeric display and then investigate the problem to determine its cause.
4. If a Trouble condition exists, restore or replace the defective equipment (switch, wire, device, etc.) in accordance with the equipment’s instructions.

   Note: When the abnormal condition causing the trouble clears, the yellow LED flashes and the tone-alert sounds steady.
5. Press the TROUBLE ACK key under the flashing yellow LED. The display shows the system status.
6. Press the TROUBLE ACK key again. After a delay the system returns to normal operation.

In case of trouble, notify:

Name: _____

Address _____

Phone # _____

FRAME AND MOUNT THESE INSTRUCTIONS ADJACENT TO THE PANEL.
SEE OPERATOR’S MANUAL FOR DETAILED OPERATION.

AUTOCALL

© 2021 Johnson Controls. All rights reserved.

4100ES/4010ES ES Touch Screen Display OPERATING INSTRUCTIONS FOLLOWING AN ALARM, SUPERVISORY, OR TROUBLE CONDITION

YOUR SAFETY AND THE SAFETY OF THOSE AROUND YOU ALWAYS COMES FIRST.
Actions taken during a fire depend upon local practices. Be sure you know what to do.

Systems Using Global Acknowledge

ALARM AND PRIORITY 2
RED LED FLASHES AND TONE ALERT PULSES



1. Unlock and open the panel door. You will either see an **Event List** display or a site map. If the site map has been configured, the display can be switched by pressing the softkey next to the “Site” icon (see the preceding figure) or “System Status” icon. In all text screens, the point status and the custom label will display. This example describes managing an alarm condition. A Priority 2 condition is handled similarly.

   Note: The LED for Priority 2 can be configured as blue or red.

2. Press the ALARM ACK key above the flashing red LED or a cell in the active list. Read and follow the instructions on the display. The display shows the zone and type of problem. The tone-alert momentarily silences and then resounds. Continue to press the cells or the ALARM ACK key until all trouble conditions are acknowledged

Silencing the Signals

1. Press the ALARM SILENCE hardware key/touch screen key and read the display. The alphanumeric display reads “ALARM SILENCE IN PROGRESS” and the ALARM SILENCE LED turns on steady.

Resetting the System

1. When the alarm condition has been cleared, restore or replace all affected devices (smoke detectors, motion sensors, etc.) in accordance with the instructions provided with each device.
2. Reset the system as follows:
   - FIRE ALARM condition. Press the SYSTEM RESET key.
   - PRIORITY 2 ALARM condition. Depending on the system configuration, reset the alarm condition using the SYSTEM RESET.

   After a delay, the red LED goes off.

SUPERVISORY/TROUBLE
YELLOW LED FLASHES AND TONE ALERT ON STEADY



1. Unlock and open the panel door. The display shows the number of abnormal conditions. This example describes managing a trouble condition. A supervisory condition is handled similarly.
2. The display shows the area and type of problem, the tone-alert silences. Tap the cell with a flashing border key and the corresponding LED turns ON steady. Read the display and then investigate the problem to determine its cause.
3. If a Trouble condition exists, restore or replace the defective equipment (switch, wire, device, etc.) in accordance with the equipment’s instructions. The Trouble condition automatically clears when the abnormal condition has been corrected.

   After a short delay, the system returns to normal operation.

In case of trouble, notify:

Name: _____

Address _____

Phone # _____

FRAME AND MOUNT THESE INSTRUCTIONS ADJACENT TO THE PANEL.
SEE OPERATOR’S MANUAL FOR DETAILED OPERATION.

© 2021 Johnson Controls. All rights reserved.

579-1322AC
Rev. A

AUTOCALL