{Learn, Create, Innovate};

# Puzzlebot configuration

Robot setup, motion, and control






### **Puzzlebot: Jetson Edition**



NVIDIA Jetson Nano
For Al and computer vision

**Hacker Board** 

For low-level control algorithms



Raspberry Pi Camera


**GPIO** Arrays

Expansion possible via the Jetson or the Hacker Board



### The PuzzleBot








### **The Hacker Board**

- ESP32-based Microcontroller
  - Xtensa dual-core 32-bit LX6 microprocessor
  - 520 KB of SRAM
  - WiFi & Bluetooth
- DC-DC Converter
- Motor Driver
- 0.96" I2C LCD Display






### **The Hacker Board**



- Preprogramed firmware including basic control, sensing, and communication libraries
- Two programming configurations:
  - Standalone Configuration
  - External-Control Configuration






### The Webpage



- Connect to the WiFi Network displayed on the Hacker Board
- Go to 192.168.1.1 in a browser

#### **Robot Parameters**



| Sonar and Servo Parameters |                     |  |
|----------------------------|---------------------|--|
| Servo Angle 0 Submit       | Servo Offset 0 Save |  |
| Sonar Distance: 2.0000     |                     |  |

| Reflectance sensor                           |  |
|--|--|
| Sensor Min Average:2000<br>Start Calibration |  |
| Line Position: 0.0000                        |  |
| Raw values: 2500 2500 2500 2500 2500 2500    |  |

| PID Parameters           |                          |
|--------------------------|--------------------------|
| Right Motor              | Left Motor               |
| Kp 0.1 Ti 0.05 Td 0 Save | Kp 0.1 Ti 0.05 Td 0 Save |



### The Config



## Now visit 192.168.1.1/config

#### Configuration parameters for the robot ("config.yaml" file)

```
Upload to robot
                 Restart robot
# Config file for puzzlebot with pololu brushed dc motors
PidDt: 0.01
                                # Pid controller loop sampling time
# Main parameters for the robot
                                # 1-differential drive robot; 2-holonomic robot
  Type: 1
  ControlInput: 2
                                # 1-robot linear and angular velocities; 2-wheel angular velocities setpoints; 3-wheel pwm voltage signals
  WheelBase: 0.083
                                # Half of the robot width
  WheelRadius: 0.0505
                                # Wheel radius
  TopicVx: VelocityLinearX
                                # Topic for receiving linear velocity of the robot
  TopicVy: VelocityLinearY
                                # Topic for receiving linear velocity of the robot on Y(for holonomic robot)
  TopicW: VelocityAngular
                                # Topic for receiving angular velocity of the robot
# Parameters for the right wheel
RightWheel:
 Motor:
                        # Right motor parameters
                                # Motor driver pins
    Pins: [4, 15, 18]
    Sign: -1
                                # Motor direction setting (-1/1)
                                # Motor type, 1-brushless: 2-brushed
    Type: 2
                                # Topic for receiving control pwm
    Topic: ControlR
                        # Right encoder parameters
  Encoder:
    Pins: [34, 36]
                                # Encoder pins
    Sign: 1
                                # Encoder direction setting (-1/1)
                                # Encoder number of ticks for one rotation
    Ticks: 48
    Gear: 34
                                # Gear ratio
    Type: 2
                                # Encoder type. 1-single pulse(no direction); 2-double pulse(with direction)
                                # Encoder velocity measurement type. 1-count pulses; 2-measure pulse duration
   MeasureType: 1
    Topic: VelocityEncR
                                # Encoder velocity publish topic
                        # Right Pid controller parameters
  Pid:
    Kp: 0.1
                                # Proportional gain
    Ti: 0.05
                                # Integration time
    Td: 0
                                # Derivation time
    DeadZone: 0.1
                                # Motor control dead zone
    Topic: VelocitySetR
                                # Topic for receiving velocity setpoint
# Parameters for the left wheel
LeftWheel:
                        # Left motor parameters
 Motor:
    Pins: [2, 14, 13]
                                # Motor driver pins
```



### The Jetson Nano 2GB



- 128-core NVIDA Maxwell GPU
- 1.43 GHz Quad-core ARM A57 CPU
- 2 GB of 64-bit LPDDR4 Memory
- SD card for storage
- Ethernet & WiFi
- CSI-2 Connector for Camera
- Runs a modified version of Ubuntu 18.04





### **The Jetson Nano 2GB**




- Communicates with the Hacker Board serially via micro-ROS
- Runs NVIDIA's own version of Linux, similar to Ubuntu
- The OS is flashed onto the SD card by a PC
- Three options for setup
  - Use the provided image in place of the NVIDIA image (recommended)
  - Run a setup bash file
  - Manual installation



### The Jetson Nano with ROS



ROS



**ROS** Implementation



### **Activity Teleoperation**



- Setup a PuzzleBot Jetson:
  - Get Started With Jetson Nano Developer Kit | NVIDIA Developer
  - Use the image provided in the git
- Install the ROS teleop twist keyboard package on an external PC
  - sudo apt install ros-humble-teleop-twist-keyboard -y
- Connect to the Puzzlebot via ssh
  - The Jetson will create its own WiFi network that can be used to communicate with it
  - Name: PuzzlebotJetson
  - Password: Puzzlebot72
    - The WiFi details can be changed on the Jetson by selecting:
    - Networks->Edit Connections->Hotspot
  - ssh puzzlebot@10.42.0.1



### **Activity: Teleoperation**



- Once connected, run the micro-ROS agent
  - ros2 run micro-ros-agent micro-ros-agent serial —dev /dev/ttyUSB0
- use ros2 topic list to check if the connection has been successful
  - The topics /cmd\_vel, /wr, and /wl should be displayed, along with a few others
- Use the external device to remotely operate the puzzlebot
  - ros2 run teleop\_twist\_keyboard teleop\_twist\_keyboard.
  - Follow the instructions displayed in the command window




### **Twist Message**



- geometry\_msgs/Vector3 linear
  - float64 x
  - float64 y
  - float64 z
- geometry\_msgs/Vector3 angular
  - float64 x
  - float64 y
  - float64 z
- Publish on the node using ros2 topic pub

### Thank You


**Robotics For Everyone** 



{Learn, Create, Innovate};

T&C

**Terms and conditions** 



{Learn, Create, Innovate};



### Terms and conditions





- THE PIECES, IMAGES, VIDEOS, DOCUMENTATION, ETC. SHOWN HERE ARE FOR INFORMATIVE PURPOSES ONLY. THE DESIGN IS PROPRIETARY

  AND CONFIDENTIAL TO MANCHESTER ROBOTICS LTD. (MCR2). THE INFORMATION, CODE, SIMULATORS, DRAWINGS, VIDEOS PRESENTATIONS

  ETC. CONTAINED IN THIS PRESENTATION IS THE SOLE PROPERTY OF MANCHESTER ROBOTICS LTD. ANY REPRODUCTION, RESELL,

  REDISTRIBUTION OR USAGE IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MANCHESTER ROBOTICS LTD. IS STRICTLY

  PROHIBITED.
- THIS PRESENTATION MAY CONTAIN LINKS TO OTHER WEBSITES OR CONTENT BELONGING TO OR ORIGINATING FROM THIRD PARTIES OR LINKS TO WEBSITES AND FEATURES IN BANNERS OR OTHER ADVERTISING. SUCH EXTERNAL LINKS ARE NOT INVESTIGATED, MONITORED, OR CHECKED FOR ACCURACY, ADEQUACY, VALIDITY, RELIABILITY, AVAILABILITY OR COMPLETENESS BY US.
- WE DO NOT WARRANT, ENDORSE, GUARANTEE, OR ASSUME RESPONSIBILITY FOR THE ACCURACY OR RELIABILITY OF ANY INFORMATION
   OFFERED BY THIRD-PARTY WEBSITES LINKED THROUGH THE SITE OR ANY WEBSITE OR FEATURE LINKED IN ANY BANNER OR OTHER
   ADVERTISING.