

AC Tonnage Calculator Logic

Base AC Capacity

Area SFT	Base
Up to 100	1.0 Ton
101-150	1.5 Ton
151-220	2.0 Ton
221-300	2.5 Ton
301-380	3.0 Ton
381-450	4.0 Ton
Above 450	Calculate separately

Direction

Direction	Add
North	+0.00
South	+0.05
East	+0.10
West	+0.20

Floor

Type	Add
Ground	+0.00
Middle	+0.05
Top	+0.20

Temperature

Temp	Add
<30C	+0.00
30-35	+0.10
35-40	+0.20
>40	+0.30

Occupants

People	Add
1-2	+0.00
3-4	+0.10
5-6	+0.20

Every +2	+0.10
----------	-------

Windows

Count	Add
1	+0.00
2	+0.05
3	+0.10
4+	+0.20

Roof

Type	Add
Insulated RCC	+0.00
Normal RCC	+0.10
Metal/Asbestos	+0.30

Ceiling Height

Height	Add
<=10 ft	+0.00
10-12 ft	+0.10
>12 ft	+0.20

Sun Exposure

Exposure	Add
Low	+0.00
Medium	+0.10
High	+0.20

Formula: Recommended AC = Base + all adjustments. Round to nearest available size (1,1.5,2,2.5,3,4,5 Ton).