

Home Network Troubleshooting – Simple Guide

This easy guide is designed for home users and single parents. Follow the steps in order for quick results.

Step-by-Step Checklist

- Restart your modem and router. Turn them off, wait 30 seconds, then turn them back on.
- Check how many devices are connected. Pause streaming or downloads you are not using.
- Move closer to the router to test signal strength.
- Ensure the router is placed centrally and not hidden or on the floor.
- Avoid interference from microwaves, baby monitors, or thick walls.
- Test one device at a time to see if the issue affects all devices or just one.
- Restart and update phones, tablets, laptops, and smart TVs.
- Contact support if internet drops frequently or Wi-Fi does not reach key rooms.

Tip: Slow Wi-Fi is often a coverage issue, not your internet plan. Small changes can make a big difference.

Provided by d10 IT Solutions – Simple, reliable technology support for homes and families.