Network Engineer-Shortened IOS Commands

Command	Shortened version	Brief description of the command
auto-summary	**auto**	Enabling automatic summarization mode (for some routing protocols)
configure terminal	**conf t**	Switch to global configuration mode
clock rate	**cl r**	Setting the clock rate for the DCE serial interface
disable	**disa**	Exit privileged mode
enable	**en**	Entering privileged mode
exit	**ex**	Exit to higher configuration level
end	**end**	Exit to global configuration mode
hostname	**h**	Setting the name of the router (switch)
interface	**int**	Entering interface configuration mode
description	**desc**	Configuring the description for the interface
ip address	**ip ad**	Configuring the IP address for the interface
network	**net**	Setting up the adjacent network
no shutdown	**no sh**	In interface configuration mode, it sets the interface to the "up" state
no auto-summary	**no auto**	Disables auto-summary mode (for some routing protocols)
ping	**p**	Sends an ICMP message
reload	**rel**	Performs a reboot of the router (switch
rip router	**ro r**	Transitions to RIP configuration mode (in global configuration mode)
router eigrp	**ro e**	Enters EIGRP configuration mode (in global configuration mode)
router ospf	**ro o**	Enters OSPF configuration mode (in global configuration mode)
router bgp	**ro b**	Switch to BGP configuration mode (in global configuration mode)
show dhcp	**sh dh**	Displays DHCP address leases
show interfaces	**sh in**	Displays status of interfaces
show running-config	**sh r**	Displays the current configuration

show startup-config	**sh star**	Displays initial configuration
show users	**sh u**	Displays the line status of the terminal
show version	**sh v**	Displays IOS information
show ip arp	**sh ip ar**	Displays ARP table
show ip dhcp binding	**sh ip d b**	Displays the DHCP table
show ip interface	**sh ip i**	Displays all interfaces in detail
show ip rip data	**sh ip rip d**	Displays RIP protocol data
show ip route	**sh ip rou**	Displays the routing table
show ip route connected	**sh ip rou c**	Displays the routing table (Directly adjacent networks only)
show ip route rip	**sh ip rou r**	Displays the routing table (RIP routes only)
show ip route eigrp	**sh ip rou e**	Displays the routing table (EIGRP routes only)
show ip route ospf	**sh ip rou o**	Displays the routing table (OSPF routes only)
show ip route bgp	**sh ip rou b**	Displays routing table (only BGP routes)
shutdown	**shut**	In interface configuration mode, sets the interface to the "down" state
traceroute ip	**tr ip**	Allows you to trace the route of an IP packet
version	**v**	Sets the RIP protocol version
write	**w**	Saving the running-config to the startup-config