

- 2.5 Using the 3/8" Drift remove the 3/8" Cross Tube which locates the Back Release spring from the Casing. Retain the Cross Tube.
- 2.6 Remove the 1/4" UNF Ring Cage/Beak pivot bolt. Discard the nut and bolt.
- 2.7 Withdraw the Ring Cage/Beak assembly from the bottom of the Casing, remove the 3/8" bush and shim washers, **noting the position of the shim washers**, and separate the Ring Cage from the Beak leaving the remaining assembly inside the Casing. Discard both the bush and the Back Release spring.
- 2.8 Fit the new Release Lever spring and bush to the Lever Carriage and insert the Carriage, and shim washers, into the Casing. Replace the 1/4" UNF Shear pivot bolt, washer and fit the new 1/4" UNF bolt and nut. Do not tighten the nut at this stage. The preferred bolt installation is from RIGHT to LEFT.
- 2.9 Using the notched screwdriver push each spring leg in turn into the top of the Casing locating the legs with the 3/16" diameter Bullet Guide. Place the 3/16" Cross Tube on to the Bullet Guide shoulder and drive into place using the 3/16" Drift.
- 2.10 Lock the Lever Carriage in the FORWARD position by inserting a 2BA bolt through the rearmost hole of the Lever Carriage and allow it to rest against the rear edges of the Casing. Push the beak as far as possible inside the Casing.
- 2.11 Insert the new Back Release spring through the bottom of the Casing ensuring that the two legs fit into the rear corner of the Casing. Locate the spring coils with the 3/8" Bullet Guide, fit the 3/8" Cross Tube on to the guide shoulder and drive into place using the 3/8" Drift.
- 2.12 Using a strong piece of twine pull the Back Release spring hard back against its rear stop and secure in position. (N.B. A second pair of hands are useful for this task).
- 2.13 Pull the Beak down out of the Casing, re-fit the Ring Cage, **with the original shim washers in the same position as before**, to the Beak, insert the new 3/8" bush and push the complete assembly into the Casing. Fit the new 1/4" UNF pivot bolt, washer and nut. Do not tighten the nut at this stage.
- 2.14 Untie/release the Back Release spring and remove the 2BA bolt holding the Lever Carriage forward.

DOF-1