

USER MAINTENANCE.

Drg. No. CW3400UM.

GENERAL.

The CW Series of Ottfur QR Units are designed and engineered such they are not 'lived', release to service being based on 'On Condition' inspection parameters that are listed in the Unit's Log Book.

ROUTINE SERVICING.

Routine servicing is limited to cleaning and lubrication on an annual basis and guidelines are also included in the Unit Log Book. However discretion may be used to reduce this periodicity, dependant on usage and local environment.

Long-term serviceability is primarily dependent on the integrity of the Release Lever Spring and in service experience has demonstrated that the useful life of this spring to be approximately 5000 launches and to avoid unscheduled repairs a spring change after 4000 launches is recommended.

SPRING/BUSH CHANGE.

Spring/Bush changes can be carried out at Club Engineer or BGA Inspector supervised levels and the procedures for both the CW 300 and CW400 QR units are defined in Drawings CW300SCP and CW400SCP below.

Details of the tools required are given Drawing No CW3400TK.

25CW3400UM

OK-1