WLOXO

Lithium Ion Electric Fillet Knife



English

User'S Manual

contact@vloxo.net

IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic safety precautions should always be followed including the following:

- 1. Do not place the machine and battery in water or other liquids.
- 2. Please remove the battery, when assembling, disassembling, and cleaning.
- 3. Do not use this product while charging.
- 4. When the surface of the product overheats during use, please allow the machine to rest for some time.
- 5. When using, do not block the heat dissipation hole of the machine.
- 6. Keep away from children and bodies when using.
- 7. When replacing the blade, ensure that the safety lock is closed.
- 8. After use, do not wash directly with water, dry with a dry towel.
- 9. After use, keep the product away from children.
- 10. Do not use the machine when it is damaged.

PRODUCT INFORMATION



REPLACE BLADE



STEP 1

Slide the blade rivet into the rivet slot and align



STEP 2

Hold the blade protection cover in one hand and align it with the blade slot



STEP 3

Insert the blade into the slot of the machine blade and make a click



STEP 4

Pull the blade to ensure successful installation

⚠ TIPS

- 1. Wear cut-proof gloves when installing blades.
- 2. When installing the blade, ensure that the rounded corners of the bottom blade are aligned
- 3. When replacing a blade, remove the battery.

REPLACE BATTERY



Please fully charge the battery before use.



Push the battery
release button down



2. Push the battery forward along the battery slot



3. Replace a new battery



4. Align the battery charging hole with the machine charging slot



5. Push the battery backward along the battery slot and merge it with the machine

HOW TO USE



Press and hold the battery release button to remove the battery and charge it fully.



Install the blade you want to use



Press the safety lock



Turn on the power switch to work

CLEANING, MAINTENANCE, AND SAVE

- 1. Remove the battery during cleaning, maintenance, and repair operations.
- 2. Keep away from corrosive cleaners, high-pressure cleaners, and sharp objects.
- 3. After use, dry the machine and blade with a dry towel and store
 - a. Wipe the machine with a dry towel and store it in a dry and ventilated place.
 - b. Clean the blade with warm water and dry it with a dry towel.
 - c. Keep the battery dry. If you do not use it for a long time, please charge the battery regularly.
- 4. When cleaning the blade, wear durable working gloves to avoid injury.
- 5. Place all accessories in the toolbox and keep them out of the reach of children.

USE REQUIREMENTS

- 1. Please read the instructions carefully before use.
- 2. Adults use only
- 3. Make sure the battery is fully charged the first time you
- 4. After use, clean the blade and place it in the toolbox. And keep the toolbox out of reach of Children.

PACKAGE CONTENTS

VLOXO Electric Fillet Knife	
Blade	x 4
Bag	x 1
Battery	x 2
Charger	x 1
Manual	x 1

SERVICE

Should you have any questions regarding the Electric Fillet Knife, please contact us immediately (**Email:contact@vloxo.net**). Our professionals will resolve the problems for you.

DISPOSAL & RECYCLING



You must dispose of the Electric Fillet Knife properly according to local laws and regulations. Because this machine contains electronic components, it should be discarded and separated from household waste. When it reaches its end life, contact local authorities to learn about disposal and recycling options. You can help protect the environment! Please remember to respect the local regulations, and dispose of the non-working electrical equipment to an appropriate waste disposal center.