🔍

- contact
- support
- order
- MODBUS
- Data Logger
- COM Port

- Advanced NMEA Data Logger
  - About
  - Download
  - Screenshots
  - Tutorials
  - PDF manual
  - Feature Matrix
  - Changelog
  - AIS Decoder
  - Buy
  - Plugins
  - Help
- Data Logger Suite
- Advanced Serial Data Logger
- Advanced TCP/IP Data Logger
- GPS Tracker Data Logger
- Serial Printer Logger
- Advanced OPC Data Logger
- Advanced PBX Data Logger
- SNMP Data Logger
- USB HID Logger
- Log Monitor & Export
- All Software

Advanced NMEA Data Logger

Trust In Confidence!

For Windows 2000 - Windows 11 (2019) (incl. Server, x86 and x64). Latest version: **3.5.4 build 913**. September 13, 2022.

Export AIS data to a database

🖶 Print version

The AIS data are exported slightly differently from the NMEA data.

1. Select the packet types that contain the AIS data (Figure 1).

Figure 1: AIS data packets

2. Disable data aggregation (Figure 12).

Figure 2: Disable data aggregation

3. The AIS data stream contains a lot of data, and the number and names of variables are not known beforehand. Therefore:

1. The active items list in the "DDE Server" dialog box may contain tons of variables.
2. Write down the names of variables that you need, because they will not be present in the dropdown list in the data export module.

Related articles:

- [FAQ](#).
- [Get NMEA GPS and Sounder data through the OPC interface](#).
- [Write NMEA data to a database (using MS Access in this example)](#).
- [Export AIS data to a database](#).
- [Export all received AIS or NMEA data to XML or a text file](#).
- [Saving NMEA or AIS data to a Microsoft Excel file (CSV format).](#)
- [Saving selected NMEA values to an Excel file (CSV format)](#).
- [Grouping NMEA data from two data sources to one row in a CSV file](#).
- [Grouping NMEA data from two data sources with different communication parameters](#).
- [Decoding AIS files (batch AIS files processing)](#).

Read more about:

[Serial port interface](#) [RS232 pinout and signals](#) [Cables and signals](#) [Data monitor cables](#)

- [site map](#)
- |
- [contact](#)

- |
- [support](#)
- |
- [rs232 software](#)
- |
- [rs232 pinout](#)
- |
- [order](#)
- |
- [news](#)
- |
- [links](#)