

1. Overview

The Daikin Inverter AC XYZ-492 is a split inverter air conditioner. This manual covers diagnosis, fault codes, and board-level repair for authorised technicians.

Reference: <https://support.example-daikin.test/xyz-492/manual>

Daikin Inverter AC XYZ-492 - Service Manual - page 1

2. Fault codes

F3 - Control board (PCB) failure. The inverter PCB cannot drive the compressor. Replace the control board assembly; compatible part is PCB-492 with capacitor CAP-492. Requires skill 'daikin-inverter'.

F6 - Outdoor temperature sensor open circuit. Replace sensor; no board work.

U4 - Indoor/outdoor communication error. Check harness before replacing any board.

Daikin Inverter AC XYZ-492 - Service Manual - page 2

3. Control board (PCB-492) replacement

Isolate mains. Discharge CAP-492 before handling. Swap the PCB-492 assembly, refit CAP-492, and run the self-test. Estimated time 90 minutes. A loaner unit may be offered if PCB-492 stock is unavailable at the serving location.

Safety: high-voltage capacitor - follow the discharge SOP before contact.

Daikin Inverter AC XYZ-492 - Service Manual - page 3