

1. Overview & specifications

The ThermaCore Storage Water Heater GZ-25 (ThermaCore, water-heater) is covered by this service manual for authorised technicians holding the 'heating' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: storage geyser, capacityL: 25, powerW: 2000.

Warranty: 84 months. Inner tank covered 7 years; heating element and thermostat 24 months.

Reference: <https://support.example-fieldflow.test/gz-25/manual>

ThermaCore Storage Water Heater GZ-25 — Service Manual — page 1

2. Installation & commissioning

Fit the pressure-relief valve, fill the tank fully before switching on (dry-firing destroys the element), and set the thermostat to 60 C.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

G1 — No heating; element burnt out. Replace ELEM-25. Skill: heating.

G2 — Over-temperature trip; thermal cut-out open. Replace TCO-25. Skill: heating. SAFETY: high-risk, follow discharge/isolation SOP.

G4 — Water too hot/cold; thermostat drift. Replace THRM-25. Skill: heating.

G6 — Leak from relief valve; pressure fault. Replace VALV-25. Skill: heating. SAFETY: high-risk, follow discharge/isolation SOP.

4. Part replacement — ELEM-25 / THRM-25

ELEM-25 — Heating element 2kW (heating-element). Isolate mains and follow the safety SOP. Remove the faulty unit, fit ELEM-25, and run the self-test. Requires 'heating'. This part is covered under active warranty (free). List price ■920.

THRM-25 — Adjustable thermostat (thermostat). Isolate mains and follow the safety SOP. Remove the faulty unit, fit THRM-25, and run the self-test. Requires 'heating'. This part is covered under active warranty (free). List price ■560.

5. Part replacement — TCO-25 / ANOD-25

TCO-25 — Thermal cut-out safety switch (sensor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit TCO-25, and run the self-test. Requires 'heating'. This part is covered under active warranty (free). List price ■380.

ANOD-25 — Magnesium anode rod (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit ANOD-25, and run the self-test. Requires 'heating'. This part is chargeable (out of warranty scope). List price ■440.

6. Part replacement — GASK-25 / VALV-25

GASK-25 — Flange gasket (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit GASK-25, and run the self-test. Requires 'heating'. This part is chargeable (out of warranty scope). List price ■260.

VALV-25 — Pressure relief valve (valve). Isolate mains and follow the safety SOP. Remove the faulty unit, fit VALV-25, and run the self-test. Requires 'heating'. This part is chargeable (out of warranty scope). List price ■480.

7. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

Isolate mains and relieve tank pressure. Never energise a partially filled tank.

Warranty annex: under an active warranty, ELEM-25, THRM-25, TCO-25 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

ThermaCore Storage Water Heater GZ-25 — Service Manual — page 7