

1. Overview & specifications

The HeatWave Induction Cooktop IC-30 (HeatWave, induction-cooktop) is covered by this service manual for authorised technicians holding the 'kitchen-appliance' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: single-zone induction, powerW: 2100, zones: 1.

Warranty: 24 months. Parts and labour 24 months on the IGBT and control board.

Reference: <https://support.example-fieldflow.test/ic-30/manual>

HeatWave Induction Cooktop IC-30 — Service Manual — page 1

2. Installation & commissioning

Confirm a dedicated 16A circuit, verify pan-detection with a ferrous pan, and check the cooling fan spins on load.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

I1 — No heating; IGBT power module failed. Replace IGBT-30. Skill: kitchen-appliance. SAFETY: high-risk, follow discharge/isolation SOP.

I3 — Overheat shutdown; cooling fan stalled. Replace FAN-30. Skill: kitchen-appliance.

I5 — Pan-detect error; NTC sensor drift. Replace NTC-30. Skill: kitchen-appliance.

I7 — Dead panel; control board fault. Replace PCB-30. Skill: kitchen-appliance.

HeatWave Induction Cooktop IC-30 — Service Manual — page 3

4. Part replacement — IGBT-30 / PCB-30

IGBT-30 — IGBT power module (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit IGBT-30, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■980.

PCB-30 — Induction control board (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PCB-30, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■1,150.

5. Part replacement — COIL-30 / FAN-30

COIL-30 — Induction work coil (mechanical). Isolate mains and follow the safety SOP. Remove the faulty unit, fit COIL-30, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■860.

FAN-30 — Cooling fan (motor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit FAN-30, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■400.

6. Part replacement — NTC-30 / GLAS-30

NTC-30 — Pan-temperature NTC sensor (sensor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit NTC-30, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■280.

GLAS-30 — Ceramic glass top (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit GLAS-30, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■1,200.

7. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

Discharge the IGBT bus before service; the ceramic top can retain heat.

Warranty annex: under an active warranty, IGBT-30, PCB-30, COIL-30 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

HeatWave Induction Cooktop IC-30 — Service Manual — page 7