

1. Overview & specifications

The Glacio Side-by-Side Refrigerator SBS-620 (Glacio, refrigerator) is covered by this service manual for authorised technicians holding the 'refrigeration' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: side-by-side with water dispenser, capacityL: 620, refrigerant: R600a, starRating: 4.

Warranty: 120 months. Compressor covered 10 years; other parts and labour 24 months. Water filter is a consumable.

Reference: <https://support.example-fieldflow.test/sbs-620/manual>

Glacio Side-by-Side Refrigerator SBS-620 — Service Manual — page 1

2. Installation & commissioning

Let the unit stand upright for four hours before power-on, level the cabinet, and confirm the door gasket seals a paper strip on all four sides.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

S1 — Compressor fault; both compartments warm. Replace COMP-620. Skill: refrigeration.

S3 — Dispenser not dispensing water; valve stuck. Replace DISP-620. Skill: refrigeration.

S6 — Main board communication error. Replace PCB-620. Skill: refrigeration.

S8 — Dispenser chute frozen; heater open. Replace HEAT-620. Skill: refrigeration.

Glacio Side-by-Side Refrigerator SBS-620 — Service Manual — page 3

4. Part replacement — COMP-620 / PCB-620

COMP-620 — Linear inverter compressor (compressor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit COMP-620, and run the self-test. Requires 'refrigeration'. This part is covered under active warranty (free). List price ■16,800.

PCB-620 — Main control board (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PCB-620, and run the self-test. Requires 'refrigeration'. This part is covered under active warranty (free). List price ■3,900.

5. Part replacement — DISP-620 / FANC-620

DISP-620 — Ice & water dispenser valve (valve). Isolate mains and follow the safety SOP. Remove the faulty unit, fit DISP-620, and run the self-test. Requires 'refrigeration'. This part is chargeable (out of warranty scope). List price ■1,500.

FANC-620 — Condenser fan motor (motor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit FANC-620, and run the self-test. Requires 'refrigeration'. This part is chargeable (out of warranty scope). List price ■1,600.

6. Part replacement — WFILT-620 / SENS-620

WFILT-620 — Inline water filter (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit WFILT-620, and run the self-test. Requires 'refrigeration'. This part is chargeable (out of warranty scope). List price ■700.

SENS-620 — Ambient humidity sensor (sensor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit SENS-620, and run the self-test. Requires 'refrigeration'. This part is covered under active warranty (free). List price ■440.

7. Part replacement — HEAT-620

HEAT-620 — Dispenser anti-freeze heater (heating-element). Isolate mains and follow the safety SOP. Remove the faulty unit, fit HEAT-620, and run the self-test. Requires 'refrigeration'. This part is chargeable (out of warranty scope). List price ■650.

8. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

R600a is flammable: no open flame, ensure ventilation, and recover before brazing.

Warranty annex: under an active warranty, COMP-620, PCB-620, SENS-620 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

Glacio Side-by-Side Refrigerator SBS-620 — Service Manual — page 8