

1. Overview & specifications

The Vortex Top-Load Washer TL-65 (Vortex, washing-machine) is covered by this service manual for authorised technicians holding the 'laundry' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: top-load washer, capacityKg: 6.5, maxRpm: 740, powerW: 360.

Warranty: 24 months. Motor covered 5 years; parts and labour 24 months. Consumables excluded.

Reference: <https://support.example-fieldflow.test/tl-65/manual>

Vortex Top-Load Washer TL-65 — Service Manual — page 1

2. Installation & commissioning

Remove the transit bolts, level the chassis against vibration, connect the inlet and standpipe drain, and run an empty calibration cycle.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

T1 — No agitation; gearbox worn. Replace GEAR-65. Skill: laundry.

T3 — Not filling; inlet valve stuck. Replace VALV-65. Skill: laundry.

T5 — Won't start; lid switch open. Replace LID-65. Skill: laundry.

T8 — Timer board stuck mid-cycle. Replace PCB-65. Skill: laundry.

Vortex Top-Load Washer TL-65 — Service Manual — page 3

4. Part replacement — MOT-65 / PCB-65

MOT-65 — Universal wash motor (motor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit MOT-65, and run the self-test. Requires 'laundry'. This part is covered under active warranty (free). List price ■3,200.

PCB-65 — Timer control board (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PCB-65, and run the self-test. Requires 'laundry'. This part is covered under active warranty (free). List price ■1,500.

5. Part replacement — VALV-65 / LID-65

VALV-65 — Water inlet valve (valve). Isolate mains and follow the safety SOP. Remove the faulty unit, fit VALV-65, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■620.

LID-65 — Lid switch (sensor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit LID-65, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■400.

6. Part replacement — GEAR-65 / BELT-65

GEAR-65 — Gearbox / transmission (mechanical). Isolate mains and follow the safety SOP. Remove the faulty unit, fit GEAR-65, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■2,400.

BELT-65 — Pulley belt (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit BELT-65, and run the self-test. Requires 'laundry'. This part is chargeable (out of warranty scope). List price ■300.

7. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

Isolate mains and discharge; the heater circuit can hold a lethal charge. Never bypass the door interlock.

Warranty annex: under an active warranty, MOT-65, PCB-65 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

Vortex Top-Load Washer TL-65 — Service Manual — page 7