

FOR AFTER THE SETUP GUIDE

The cases the guide leaves out. Most installs never need them.

The setup guide is still the order to do things in. Page numbers below are the guide's.

Can the probe lead be **extended**?

Yes. **Ten metres is fine.** The probe is a resistance the unit measures, and ten metres of cable adds about a hundredth of a degree, well inside the sensor's own accuracy. Either way round: the probe has no polarity, so the extension has none either.

- **Use two-core twisted pair, 0.35 mm² or thicker.** Unshielded CAN or RS-485 cable is a good choice. Alarm cable works. The twist matters more than the thickness, because the lead runs near the element's mains cable.
- **Make the joint properly.** Crimp or solder, then heatshrink. A loose screw-connector joint in a damp geyser cupboard drifts over time, and that is the one thing that moves the reading. Keep the joint off the tank body.
- **Route it apart from mains cables** where you can, and cross them at right angles.
- **Only the black probe lead is extended.** The thermostat's other wires carry 230 V and stay at the geyser. Keep the probe joint clear of any mains joint.

Can it be fitted at the geyser first and **set up afterwards**?

Yes. If your installer fits the unit and the thermostat before you have done the table steps, set it up in place, in its enclosure with the lid closed. It is the bare board that must never be on mains, not the unit in its box.

On first power it offers its own WiFi network, named gs- followed by six characters, exactly as page 3 describes. **Do step 1 and step 3 of the guide as written. Skip step 2,** the resistor test: the probe is already connected, so Home never asks for it. Home shows the tank temperature on its own within about a minute and a half of power.

Two things look different from the guide, and both are expected:

- Home does not say **Nothing is connected yet.** It goes straight to a reading.
- A tank that has been standing reads below the range the probe was measured over, and Home says so under the temperature. The note clears by itself as the water heats. Page 8.

If Home shows a sensor fault instead of a reading, resolve it while the installer is still there. Page 7 says how.

Do I need the 10 kΩ resistor **at all**?

Not for setup, once the probe is connected. **Keep it.** It is how you tell a probe or wiring fault from a fault in the unit without taking anything apart: with the resistor in place of the probe lead, a healthy unit reads about 25 °C. If it does, the fault is in the probe or its wiring.

Will it tell me when the thermostat's **cut-out trips**?

No. It does not detect a tripped cut-out. It reports the over-heating that usually comes before one, and keeps a record of it that survives a power cut. Page 9 covers the cut-out and what to do when it has tripped.

Still stuck?

Open [Help](#) › [Technical details](#) on the unit, tap [Copy diagnostics](#), and paste it into an email to karl@elektrohome.co.za. It needs no password.