
RV1
E0001 FADER DRIVER rev B
J1: 1=+5V 2=SCL 3=SDA 4=GND