

FX-PARAMETER MAP

FX	Parameter	FX Num	Parameter Num
Input Gain	fx_gain	F0	P0
Gate	fx_threshold	F1	P0
Gate	fx_attack	F1	P1
Gate	fx_release	F1	P2
Gate	fx_knee	F1	P3
Gate	fx_depth	F1	P4
EQ1	fx_sub_gain	F2	P0
EQ1	fx_low_gain	F2	P1
EQ1	fx_mid_gain	F2	P2
EQ1	fx_high_gain	F2	P3
Compressor	fx_threshold	F3	P0
Compressor	fx_ratio	F3	P1
Compressor	fx_attack	F3	P2
Compressor	fx_release	F3	P3
Compressor	fx_input_gain	F3	P4
Compressor	fx_makeup_gain	F3	P5
Compressor	fx_mix	F3	P7
Distortion	fx_drive	F4	P0
Distortion	fx_makeup_gain	F4	P1
Distortion	fx_bias	F4	P2
Distortion	fx_sag	F4	P3
Distortion	fx_tone	F4	P4
Distortion	fx_tightness	F4	P5
Distortion	fx_smooth	F4	P6
Distortion	fx_mix	F4	P7

FX	Parameter	FX Num	Parameter Num
EQ2	fx_sub_gain	F5	P0
EQ2	fx_low_gain	F5	P1
EQ2	fx_mid_gain	F5	P2
EQ2	fx_high_gain	F5	P3
Chorus	fx_rate	F6	P0
Chorus	fx_depth	F6	P1
Chorus	fx_mix	F6	P7
EXP Gain	fx_gain	F7*	P0*
Delay	fx_time	F8	P0
Delay	fx_feedback	F8	P1
Delay	fx_mix	F8	P7
Reverb	fx_size	F9	P0
Reverb	fx_damping	F9	P1
Reverb	fx_decay	F9	P2
Reverb	fx_mix	F9	P7
Output Gain	fx_gain	F10	P0
Global Gain	fx_gain	F15	P0

<IN

<OUT

B0

B1

B2

B3

#FX >

#Param >

#Bank >

SW Map Table

SW Number	Usage
SW9	FX[3] and Freq/Note Tuner Toggle
SW8	FX[2]
SW7	FX[1]
SW6	FX[0]
SW5	Param[2]
SW4	Param[1]
SW3	Param[0]
SW2	Switch Bank on rising edge
SW1	Load Saved Params on rising edge
SW0	Save Current Params on rising edge

KEY Map Table

KEY Number	Usage
KEY[3]	Decrease Parameter Values
KEY[2]	Increase Parameter Values
KEY[1]	Mute / Tap Delay
KEY[0]	Design Reset

CONTROLS

Kirbeats
KFX Engine v1.1

