DK T7 Compliant, Audio, Loudness & Logging System - Ouick Sheet

Change Scale & Loudness Setup

Click the scale area to change the Scale and Loudness Setup.

Starfish & TC Setup

Click with two fingers or the

Goniometer section to change the Starfish setup and enable the timecode window.

right mouse button in the

Select TC source

the timecode source.

Prevent changes

Click the logo to lock the user

interface with a password to

prevent unintended changes.

Click with two fingers or use

timecode window to change

the right mouse button in the

Meter source select

±1 5.1 EMBEDO

Click the legend of the meter sources, to open and select from the list of input sources.

00:08-45:26/

RISET

Bargraph Options

Change colours, Over/Normal/Under levels.

-20.5(UFS

STARFISH

G. PH LEQ

FFT 1024 POINT

AUTOMATION

PEAK

PRESET :

Assign "Type" to specify what role the bargraph reprecents e.g. Left, Right, Loudness level or other.

Text Read Out

Touch the text lines to bring up the parameter list and configure which parameters are visible.

In the parameter list, touch the right side of the selected parameter to set the text size.

When the vertical menu is hidden up to 16 different readouts can be shown.

Rename a preset

Click the "Preset" button to open the preset list.

Click with two fingers or the right mouse button on a preset name to rename the selected preset.

Use the save button in the preset list to save the current preset.

Save a preset

Vertical menu visibility

When the vertical menu is hidden, slide two fingers from right to left to temporarily show the menu. Slide from left to right to hide it again.

screen to slide the menu in or out of the screen.

Show / Hide Menu

CLEAR

Slide two fingers from left to right to hide the menu.

Slide two fingers from right to left to show the menu.

Select downmix for headphone output."


Clicking the audio group number selects the source for the headphone output and the Goniometer.*)

*) Requires a DK T7 Loudness+ license key.

Select / Customize

Click a button to select the menu function.

Use two fingers or the right mouse button to assign a new function.




When using the mouse, click in the rightmost part of the

Exit any menu by clicking the menu headline box.


PRESET Loudness Button Set Preset Button Set Main Button Set SHORTTM INTEGRT HOLD CLEAR 3 SEC 10 SEC START STOP PEAK Slide to change button set To perform a factoryreset, assign the factory reset function to a menu button and click it.

DK T7 Compliant, Audio, Loudness & Logging System – I/O Connections

DK T7 I/O SPEC



15 pin DSUB Pinout.



1: USB GND 9: VBus (USB 5V)
2: D+ USB 10: D- USB
3: Supply 15V 11: Pwr GND
4: HP Left 12: HP Right
5: GPIO 0 13: GPIO 1
6: Ana 1+ 14: Ana 1 7: Ana GND 15: Ana 2 8: Ana 2+

Visit our web site www.dk-technologies.com for free software tools, video tutorials and user guides.

