MAN-200 Motor Service Manual

1 Scope

Service procedures for the 48V traction motor family.

2 Fastener Torque

Use the following torque values when reassembling the motor. Always use a calibrated wrench.

Fastener	Size	Torque (N·m)
End-cap bolt	M8	25
Bearing housing bolt	M10	45
Mounting bracket bolt	M12	70