

en	English	英語
----	---------	----

◆ Supplementary Parts and Dealer Options – Instructions for Use

ORIGINAL INSTRUCTIONS

PANTOGRAPH JACK 「800, 1100, 1300, 1350, 1500」

INSTRUCTION MANUAL

【Manufacturer Information】

KAWASAKI INDUSTRIAL CO., LTD. (川崎工業株式会社)

1131 Kamo, Kikugawa-Shi, Shizuoka-Ken, 439-0031, Japan

(URL: www.kawasaki-ind.co.jp)

【Applicable Models】

Generic Name: Pantograph Jack

Model Names: 800, 1100, 1300, 1350, 1500

■ Safety Precautions

To use this product safely, be sure to read this manual before use.

※Keep this manual in the vehicle and store it carefully to avoid loss.

■ WARNING

If the jack slips out from the vehicle, you may be seriously injured or the vehicle may move unexpectedly. Follow the instructions below when jacking up the vehicle.

Emergency Use Only: This product is designed exclusively for emergency tire replacement and is not suitable for frequent, repetitive use like a professional lift. Repeated use may cause metal fatigue and damage. Inspect regularly and discontinue use if any abnormality is suspected.

Location Selection: Do not use on unstable surfaces such as mud, sand, steps, ships, or truck beds. Use only on a hard, flat, level surface.

Environment: Do not use below -20° C or in extreme weather conditions such as storms.

Physical Condition: Do not use if you have illness, disability, frailty, are elderly, pregnant, or under the influence of alcohol or drugs.

Usage Restrictions: Do not use for purposes other than tire replacement or puncture repair of the designated vehicle. Do not use on vehicles other than the applicable models.

No Modification: Do not use a jack that has been modified or disassembled.

Surrounding Safety: Ensure no one is under or near the vehicle. Do not lift the vehicle with someone inside.

Vehicle Securing: Block the diagonal tire, set the gear to "P" (AT) or "R/1st" (MT), and apply the parking brake firmly.

Jack Point: Ensure the jack is correctly positioned at the vehicle's designated jacking point.

No Entry Under Vehicle: Do not place any part of your body under the vehicle while it is lifted. If you must go underneath, always use jack stands.

en	English	英語
----	---------	----

Owner's Manual: Always check the vehicle owner's manual when using the jack.

■ Purpose and Positioning

This jack is a supply part intended for emergency tire replacement or puncture repair of applicable vehicles. It must not be used for other purposes (general maintenance, industrial use, etc.).

■ Risks That Cannot Be Fully Prevented (Things you should know)

This jack is designed with safety in mind, but unexpected shaking or surface changes may cause the vehicle to fall or fingers to be pinched. Follow the instructions in this manual to prevent serious accidents.

■ Maintenance and Inspection

- Pre-use Inspection: Check for deformation, cracks, abnormalities, and ensure the handle rotates smoothly.
- **Do Not Oil:** Do not apply oil or grease to the screw. The "self-locking mechanism" may fail, causing the vehicle to fall.
- Disposal Criteria: If abnormalities are found or deterioration is suspected due to long-term use, discontinue use immediately and recycle as metal waste according to local regulations.

■ How to Use

Follow the jacking procedure described in the vehicle owner's manual. If lost or unclear, consult your dealer.

■ About the Original Document

This document is the Original Instructions created in accordance with the EU Machinery Regulation (EU) 2023/1230.

■ Important Information

In Case of Accident: If a serious accident occurs during use, contact your dealer immediately.