



## **Operation and Safety Manual**

*Original Instructions - Keep this manual with the machine at all times.*

### **Boom Lift Models**

**450A Series II**

**450AJ Series II**

**Prior to S/N 0300160835 -**

**S/N E0300001114**

**510AJ**

**Prior to S/N E300001115**

**ANSI   CE**

**3121179**

*August 1, 2016*

**Read & Understand this manual before using this machine,  
failure to do so may result in death or injury.**

**EMERGENCY PROCEDURES, SECTION 5**

---

**FOREWORD****FOREWORD**

This manual is a very important tool! Keep it with the machine at all times.

The purpose of this manual is to provide owners, users, operators, lessors, and lessees with the precautions and operating procedures essential for the safe and proper machine operation for its intended purpose.

Due to continuous product improvements, JLG Industries, Inc. reserves the right to make specification changes without prior notification. Contact JLG Industries, Inc. for updated information.

3121179

-JLG Lift-

a

---

**FOREWORD****SAFETY ALERT SYMBOLS AND SAFETY SIGNAL WORDS**

This is the Safety Alert Symbol. It is used to alert you to the potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

**DANGER**

INDICATES AN IMMINENTLY HAZARDOUS SITUATION. IF NOT AVOIDED, WILL RESULT IN SERIOUS INJURY OR DEATH. THIS DECAL WILL HAVE A RED BACKGROUND.

**CAUTION**

INDICATES A POTENTIALLY HAZARDOUS SITUATION. IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY. IT MAY ALSO ALERT AGAINST UNSAFE PRACTICES. THIS DECAL WILL HAVE A YELLOW BACKGROUND.

**WARNING**

INDICATES A POTENTIALLY HAZARDOUS SITUATION. IF NOT AVOIDED, COULD RESULT IN SERIOUS INJURY OR DEATH. THIS DECAL WILL HAVE AN ORANGE BACKGROUND.

**NOTICE**

INDICATES INFORMATION OR A COMPANY POLICY THAT RELATES DIRECTLY OR INDIRECTLY TO THE SAFETY OF PERSONNEL OR PROTECTION OF PROPERTY.

## FOREWORD

### ⚠ WARNING

THIS PRODUCT MUST COMPLY WITH ALL SAFETY RELATED BULLETINS. CONTACT JLG INDUSTRIES, INC. OR THE LOCAL AUTHORIZED JLG REPRESENTATIVE FOR INFORMATION REGARDING SAFETY-RELATED BULLETINS WHICH MAY HAVE BEEN ISSUED FOR THIS PRODUCT.

### NOTICE

JLG INDUSTRIES, INC. SENDS SAFETY RELATED BULLETINS TO THE OWNER OF RECORD OF THIS MACHINE. CONTACT JLG INDUSTRIES, INC. TO ENSURE THAT THE CURRENT OWNER RECORDS ARE UPDATED AND ACCURATE.

### NOTICE

JLG INDUSTRIES, INC. MUST BE NOTIFIED IMMEDIATELY IN ALL INSTANCES WHERE JLG PRODUCTS HAVE BEEN INVOLVED IN AN ACCIDENT INVOLVING BODILY INJURY OR DEATH OF PERSONNEL OR WHEN SUBSTANTIAL DAMAGE HAS OCCURRED TO PERSONAL PROPERTY OR THE JLG PRODUCT.

#### For:

- Accident Reporting
- Product Safety Publications
- Current Owner Updates
- Questions Regarding Product Safety
- Standards and Regulations Compliance Information
- Questions Regarding Special Product Applications
- Questions Regarding Product Modifications

#### Contact:

Product Safety and Reliability Department  
JLG Industries, Inc.  
13224 Fountainhead Plaza  
Hagerstown, MD 21742  
USA

or Your Local JLG Office  
(See addresses on Inside of manual cover)

#### In USA:

Toll Free: 877-JLG-SAFE (877-554-7233)

#### Outside USA:

Phone: 240-420-2661  
Fax: 301-745-3713  
E-mail: ProductSafety@JLG.com

3121179

- JLG Lift -

c

## FOREWORD

## REVISION LOG

Original Issue	Revised	Revised
Revised	- April 24, 2003	- August 1, 2016
Revised	- August 26, 2003	
Revised	- June 15, 2004	
Revised	- May 4, 2005	
Revised	- February 8, 2006	
Revised	- May 22, 2006	
Revised	- August 2, 2007	
Revised	- January 11, 2008	
Revised	- October 29, 2009	
Revised	- November 25, 2009	
Revised	- July 30, 2010	
Revised	- September 8, 2011	
Revised	- March 5, 2012	
Revised	- May 8, 2012	
Revised	- September 23, 2014	

d

- JLG Lift -

3121179

## TABLE OF CONTENTS

SECTION - PARAGRAPH, SUBJECT	PAGE	SECTION - PARAGRAPH, SUBJECT	PAGE
<b>SECTION - 1 - SAFETY PRECAUTIONS</b>			
1.1 GENERAL .....	1-1	General .....	2-8
1.2 PRE-OPERATION .....	1-1	Function Check.....	2-10
Operator Training and Knowledge .....	1-1	SkyGuard Function Test.....	2-11
Workplace Inspection.....	1-2	2.3 OSCILLATING AXLE LOCKOUT TEST (IF EQUIPPED) .....	2-12
Machine Inspection.....	1-3		
1.3 OPERATION.....	1-3		
General .....	1-3		
Trip and Fall Hazards.....	1-4		
Electrocution Hazards.....	1-5		
Tipping Hazards.....	1-7		
Crushing and Collision Hazards .....	1-10		
1.4 TOWING, LIFTING, AND HAULING.....	1-11		
1.5 MAINTENANCE.....	1-11		
Maintenance Hazards.....	1-11		
Battery Hazards.....	1-13		
<b>SECTION - 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION</b>			
2.1 PERSONNEL TRAINING .....	2-1	3.1 GENERAL .....	3-1
Operator Training .....	2-1	3.2 CONTROLS AND INDICATORS .....	3-1
Training Supervision.....	2-1	Ground Control Station .....	3-1
Operator Responsibility.....	2-1	Ground Control Indicator Panel .....	3-5
2.2 PREPARATION, INSPECTION, AND MAINTENANCE .....	2-2	Platform Control Station .....	3-9
Pre-Start Inspection.....	2-4	Platform Control Indicator Panel .....	3-14

3121179

- JLG Lift -

i

## TABLE OF CONTENTS

SECTION - PARAGRAPH, SUBJECT	PAGE	SECTION - PARAGRAPH, SUBJECT	PAGE
4.5 STEERING.....	4-8	4.15 SKYGUARD OPERATION.....	4-15
4.6 PLATFORM .....	4-8	<b>SECTION - 5 - EMERGENCY PROCEDURES</b>	
Platform Level Adjustment .....	4-8	5.1 GENERAL .....	5-1
Platform Rotation .....	4-8	5.2 INCIDENT NOTIFICATION.....	5-1
4.7 BOOM .....	4-9	5.3 EMERGENCY OPERATION .....	5-2
Swinging the Boom .....	4-9	Operator Unable to Control Machine.....	5-2
Raising and Lowering the Lower and Mid Boom .....	4-9	Platform or Boom Caught Overhead .....	5-2
Raising and Lowering the Main (Upper) Boom .....	4-9	5.4 EMERGENCY TOWING PROCEDURES.....	5-2
Telescoping the Main Boom .....	4-9		
4.8 FUNCTION SPEED CONTROL .....	4-10	<b>SECTION - 6 - GENERAL SPECIFICATIONS &amp; OPERATOR MAINTENANCE</b>	
4.9 AUXILIARY PUMP .....	4-10	6.1 INTRODUCTION.....	6-1
4.10 OSCILLATING AXLE LOCKOUT TEST (IF EQUIPPED) .....	4-10	6.2 OPERATING SPECIFICATIONS AND PERFORMANCE DATA.....	6-1
4.11 SHUT DOWN AND PARK .....	4-11	Reach Specifications.....	6-3
4.12 LIFTING AND TIE DOWN .....	4-11	Dimensional Data .....	6-4
Lifting.....	4-11	Chassis.....	6-4
Tie Down.....	4-11	Capacities.....	6-5
4.13 TOWING .....	4-13	Tires .....	6-5
Prior to Towing.....	4-13	Engine .....	6-6
4.14 DUAL FUEL SYSTEM (GAS ENGINE ONLY) .....	4-14	Major Component Weights .....	6-10
Changing From Gasoline to LP Gas.....	4-14	Hydraulic Oil .....	6-10
Changing From LP Gas to Gasoline.....	4-14	Serial Number Location .....	6-14

ii

- JLG Lift -

3121179

## TABLE OF CONTENTS

SECTION - PARAGRAPH, SUBJECT	PAGE	SECTION - PARAGRAPH, SUBJECT	PAGE
6.3 OPERATOR MAINTENANCE .....	6-28	2-1. Basic Nomenclature - Sheet 1 of 2 .....	2-5
6.4 TIRES & WHEELS .....	6-44	2-2. Basic Nomenclature - Sheet 2 of 2 .....	2-6
Tire Inflation .....	6-44	2-3. Daily Walk-Around Inspection - Sheet 1 of 3 .....	2-7
Tire Damage .....	6-44	2-4. Daily Walk-Around Inspection - Sheet 2 of 3 .....	2-8
Tire Replacement .....	6-44	2-5. Daily Walk-Around Inspection - Sheet 3 of 3 .....	2-9
Wheel Replacement .....	6-45	3-1. Ground Control Station - A Models .....	3-2
Wheel Installation .....	6-45	3-1. Ground Control Station - AJ Models .....	3-3
6.5 DRAINING OIL BUILD UP FROM THE PROPANE REGULATOR (PRIOR TO S/N 0300137808) .....	6-47	3-2. Ground Control Indicator Panel - Sheet 1 of 2 .....	3-6
6.6 PROPANE FUEL FILTER REPLACEMENT .....	6-49	3-3. Ground Control Indicator Panel - Sheet 2 of 2 .....	3-7
Removal .....	6-49	3-4. Platform Control Console .....	3-10
Installation .....	6-49	3-5. Platform Control Console - w/Drive Orientation .....	3-11
6.7 PROPANE FUEL SYSTEM PRESSURE RELIEF .....	6-51	3-6. Platform Control Indicator Panel - Sheet 1 of 2 .....	3-16
6.8 SUPPLEMENTAL INFORMATION .....	6-51	3-7. Platform Control Indicator Panel - Sheet 2 of 2 .....	3-17
<b>SECTION - 7 - INSPECTION AND REPAIR LOG</b>			
<b>LIST OF FIGURES</b>			
2-1. Basic Nomenclature - Sheet 1 of 2 .....	2-5		
2-2. Basic Nomenclature - Sheet 2 of 2 .....	2-6		
2-3. Daily Walk-Around Inspection - Sheet 1 of 3 .....	2-7		
2-4. Daily Walk-Around Inspection - Sheet 2 of 3 .....	2-8		
2-5. Daily Walk-Around Inspection - Sheet 3 of 3 .....	2-9		
3-1. Ground Control Station - A Models .....	3-2		
3-1. Ground Control Station - AJ Models .....	3-3		
3-2. Ground Control Indicator Panel - Sheet 1 of 2 .....	3-6		
3-3. Ground Control Indicator Panel - Sheet 2 of 2 .....	3-7		
3-4. Platform Control Console .....	3-10		
3-5. Platform Control Console - w/Drive Orientation .....	3-11		
3-6. Platform Control Indicator Panel - Sheet 1 of 2 .....	3-16		
3-7. Platform Control Indicator Panel - Sheet 2 of 2 .....	3-17		
3-8. Platform Control Indicator Panel - w/Drive Orientation .....	3-18		
4-1. Position of Least Forward Stability .....	4-5		
4-2. Position of Least Backward Stability .....	4-6		
4-3. Grade and Side Slopes .....	4-7		
4-4. Lifting and Tie Down Chart .....	4-12		
4-5. Drive Disconnect Hub .....	4-13		
4-6. Decal Installation - Sheet 1 of 6 .....	4-16		
4-7. Decal Installation - Sheet 2 of 6 .....	4-17		
4-8. Decal Installation - Sheet 3 of 6 .....	4-18		
4-9. Decal Installation - Sheet 4 of 6 .....	4-19		

3121179

-JLG Lift -

iii

## TABLE OF CONTENTS

SECTION - PARAGRAPH, SUBJECT	PAGE	SECTION - PARAGRAPH, SUBJECT	PAGE
4-10. Decal Installation - Sheet 5 of 6 .....	4-20	6-13. Operator Maintenance and Lubrication Diagram - All Except D2.9 and GM .....	6-26
4-11. Decal Installation - Sheet 6 of 6 .....	4-21	6-14. Operator Maintenance and Lubrication Diagram - GM Dual-Fuel .....	6-27
6-1. Serial Number Locations .....	6-14	6-15. Deutz D2011 Engine Dipsticks .....	6-35
6-2. Engine Operating Temperature Specifications - Caterpillar - Sheet 1 of 2 .....	6-15	6-16. Filter Lock Assembly .....	6-50
6-3. Engine Operating Temperature Specifications - Caterpillar - Sheet 2 of 2 .....	6-16		
6-4. Engine Operating Temperature Specifications - Deutz - Sheet 1 of 2 .....	6-17		
6-5. Engine Operating Temperature Specifications - Deutz - Sheet 2 of 2 .....	6-18		
6-6. Engine Operating Temperature Specifications - Ford - Sheet 1 of 2 .....	6-19		
6-7. Engine Operating Temperature Specifications - Ford - Sheet 2 of 2 .....	6-20		
6-8. Engine Operating Temperature Specifications - GM - Sheet 1 of 2 .....	6-21		
6-9. Engine Operating Temperature Specifications - GM - Sheet 2 of 2 .....	6-22		
6-10. Engine Operating Temperature Specifications - Perkins - Sheet 1 of 2 .....	6-23		
6-11. Engine Operating Temperature Specifications - Perkins - Sheet 2 of 2 .....	6-24		
6-12. Operator Maintenance and Lubrication Diagram - Deutz D2.9 .....	6-25		

iv

JLG Lift

3121179

**TABLE OF CONTENTS**

SECTION - PARAGRAPH, SUBJECT	PAGE	SECTION - PARAGRAPH, SUBJECT	PAGE
<b>LIST OF TABLES</b>			
1-1 Minimum Approach Distances (M.A.D.) .....	1-6	6-17 GM 3.0L .....	6-8
1-2 Beaufort Scale (For Reference Only).....	1-9	6-18 Perkins 404D-22 .....	6-9
2-1 Inspection and Maintenance Table .....	2-3	6-19 Component Weights - 450 .....	6-10
4-1 SkyGuard Function Table.....	4-15	6-20 Component Weights - 510 .....	6-10
4-2 Decal Legend - Prior to S/N 0300141424 .....	4-22	6-21 Hydraulic Oil.....	6-10
4-3 Decal Legend - S/N 0300141424 to Present .....	4-25	6-22 Mobilfluid 424 Specs .....	6-11
6-1 Operating Specifications - 450A/450AJ - Prior to S/N 03001414246-1		6-23 Mobil DTE 13M Specs .....	6-11
6-2 Operating Specifications - 450A/450AJ - S/N 0300141424 to Present6-2		6-24 UCon Hydrolube HP-5046.....	6-12
6-3 Operating Specifications - 510AJ .....	6-3	6-25 Mobil EAL H 46 Specs .....	6-12
6-4 Reach Specifications - 450.....	6-3	6-26 Exxon Univas HVI 26 Specs.....	6-13
6-5 Reach Specifications - 510.....	6-3	6-27 Quilntolubric 888-46.....	6-13
6-6 Dimensional Data - 450.....	6-4	6-28 Lubrication Specifications.....	6-28
6-7 Dimensional Data - 510.....	6-4	6-29 Wheel Torque Chart.....	6-46
6-8 Chassis Specifications - 450.....	6-4	7-1 Inspection and Repair Log.....	7-1
6-9 Chassis Specifications - 510.....	6-5		
6-10 Capacities .....	6-5		
6-11 Tires .....	6-5		
6-12 Caterpillar 3024/C2.2.....	6-6		
6-13 Deutz D2.9L4 Specifications .....	6-6		
6-14 Deutz F3M1011F .....	6-7		
6-15 Deutz F3M2011F/D2011L03 .....	6-7		
6-16 Ford LRG-425 (Gas or Dual Fuel) .....	6-8		

3121179

-JLG Lift-

v

**TABLE OF CONTENTS**

SECTION - PARAGRAPH, SUBJECT	PAGE	SECTION - PARAGRAPH, SUBJECT	PAGE
------------------------------	------	------------------------------	------

This page intentionally blank.

## SECTION 1. SAFETY PRECAUTIONS

### 1.1 GENERAL

This section outlines the necessary precautions for proper and safe machine usage and maintenance. It is mandatory that a daily routine is established based on the content of this manual to promote proper machine usage. A maintenance program, using the information provided in this manual and the Service and Maintenance Manual, must also be established by a qualified person and must be followed to ensure that the machine is safe to operate.

The owner/user/operator/lessor/lessee of the machine must not accept operating responsibility until this manual has been read, training is accomplished, and operation of the machine has been completed under the supervision of an experienced and qualified operator.

This section contains the responsibilities of the owner, user, operator, lessor, and lessee concerning safety, training, inspection, maintenance, application, and operation. If there are any questions with regard to safety, training, inspection, maintenance, application, and operation, please contact JLG Industries, Inc. ("JLG").


#### **WARNING**

FAILURE TO COMPLY WITH THE SAFETY PRECAUTIONS LISTED IN THIS MANUAL COULD RESULT IN MACHINE DAMAGE, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

### 1.2 PRE-OPERATION

#### Operator Training and Knowledge

- The Operation and Safety Manual must be read and understood in its entirety before operating the machine. For clarification, questions, or additional information regarding any portions of this manual, contact JLG Industries, Inc.



3121179

- JLG Lift -

1-1

## SECTION 1 - SAFETY PRECAUTIONS

- An operator must not accept operating responsibilities until adequate training has been given by competent and authorized persons.
- Allow only those authorized and qualified personnel to operate the machine who have demonstrated that they understand the safe and proper operation and maintenance of the unit.
- Read, understand, and obey all DANGERS, WARNINGS, CAUTIONS, and operating instructions on the machine and in this manual.
- Ensure that the machine is to be used in a manner which is within the scope of its intended application as determined by JLG.
- All operating personnel must be familiar with the emergency controls and emergency operation of the machine as specified in this manual.
- Read, understand, and obey all applicable employer, local, and governmental regulations as they pertain to your utilization and application of the machine.

#### Workplace Inspection

- Precautions to avoid all hazards in the work area must be taken by the user before and during operation of the machine.
- Do not operate or raise the platform from a position on trucks, trailers, railway cars, floating vessels, scaffolds or other equipment unless the application is approved in writing by JLG.
- Before operation, check work area for overhead hazards such as electric lines, bridge cranes, and other potential overhead obstructions.
- Check operating surfaces for holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards.
- Check the work area for hazardous locations. Do not operate the machine in hazardous environments unless approved for that purpose by JLG.
- Ensure that the ground conditions are adequate to support the maximum tire load indicated on the tire load decals located on the chassis adjacent to each wheel. Do not travel on unsupported surfaces.

**Machine Inspection**

- Do not operate this machine until the inspections and functional checks as specified in Section 2 of this manual have been performed.
- Do not operate this machine until it has been serviced and maintained according to the maintenance and inspection requirements as specified in the machine's Service and Maintenance Manual.
- Ensure all safety devices are operating properly. Modification of these devices is a safety violation.

** WARNING**

**MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER.**

- Do not operate any machine on which the safety or instruction placards or decals are missing or illegible.
- Check the machine for modifications to original components. Ensure that any modifications have been approved by JLG.
- Avoid accumulation of debris on platform floor. Keep mud, oil, grease, and other slippery substances from footwear and platform floor.

**1.3 OPERATION****General**

- Machine operation requires your full attention. Bring the machine to a full stop before using any device, i.e. cell phones, two-way radios, etc. that will distract your attention from safely operating the machine.
- Do not use the machine for any purpose other than positioning personnel, their tools, and equipment.
- Before operation, the user must be familiar with the machine capabilities and operating characteristics of all functions.
- Never operate a malfunctioning machine. If a malfunction occurs, shut down the machine. Remove the unit from service and notify the proper authorities.
- Do not remove, modify, or disable any safety devices.
- Never slam a control switch or lever through neutral to an opposite direction. Always return switch to neutral and stop before moving the switch to the next function. Operate controls with slow and even pressure.
- Do not allow personnel to tamper with or operate the machine from the ground with personnel in the platform, except in an emergency.

**SECTION 1 - SAFETY PRECAUTIONS**

- Do not carry materials directly on platform railing unless approved by JLG.
- When two or more persons are in the platform, the operator shall be responsible for all machine operations.
- Always ensure that power tools are properly stowed and never left hanging by their cord from the platform work area.
- When driving, always position boom over rear axle in line with the direction of travel. Remember, if boom is over the front axle, steer and drive functions will be reversed.
- Do not assist a stuck or disabled machine by pushing or pulling except by pulling at the chassis tie-down lugs.
- Fully lower platform and shut off all power before leaving machine.
- Remove all rings, watches, and jewelry when operating machine. Do not wear loose fitting clothing or long hair unrestrained which may become caught or entangled in equipment.
- Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not operate this machine.

**Trip and Fall Hazards**


- During operation, occupants in the platform must wear a full body harness with a lanyard attached to an authorized lanyard anchorage point. Attach only one (1) lanyard per lanyard anchorage point..



- Enter and exit only through gate area. Use extreme caution when entering or leaving platform. Ensure that the platform assembly is fully lowered. Face the machine when entering or leaving the platform. Always maintain "three point contact" with the machine, using two hands and one foot or two feet and one hand at all times during entry and exit.

## SECTION 1 - SAFETY PRECAUTIONS

- Before operating the machine, make sure all gates are closed and fastened in their proper position.



### Electrocution Hazards

- This machine is not insulated and does not provide protection from contact or proximity to electrical current.




- Keep both feet firmly positioned on the platform floor at all times. Never position ladders, boxes, steps, planks, or similar items on unit to provide additional reach for any purpose.
- Keep oil, mud, and slippery substances cleaned from footwear and the platform floor.

3121179

-JLG Lift-

1-5

## SECTION 1 - SAFETY PRECAUTIONS



- Maintain distance from electrical lines, apparatus, or any energized (exposed or insulated) parts according to the Minimum Approach Distance (MAD) as shown in Table 1-1.
- Allow for machine movement and electrical line swaying.

Table 1-1. Minimum Approach Distances (M.A.D.)

Voltage Range (Phase to Phase)	MINIMUM APPROACH DISTANCE In Feet (Meters)
0 to 50 KV	10 (3)
Over 50 KV to 200 KV	15 (5)
Over 200 KV to 350 KV	20 (6)
Over 350 KV to 500 KV	25 (8)
Over 500 KV to 750 KV	35 (11)
Over 750 KV to 1000 KV	45 (14)

NOTE: This requirement shall apply except where employer, local or governmental regulations are more stringent.

- Maintain a clearance of at least 10 ft. (3m) between any part of the machine and its occupants, their tools, and their equipment from any electrical line or apparatus carrying up to 50,000 volts. One foot additional clearance is required for every additional 30,000 volts or less.

## SECTION 1 - SAFETY PRECAUTIONS


- The minimum approach distance may be reduced if insulating barriers are installed to prevent contact, and the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum approach distance shall be reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with the employer, local, or governmental requirements for work practices near energized equipment

### **DANGER**

DO NOT MANEUVER MACHINE OR PERSONNEL INSIDE PROHIBITED ZONE (MZ). ASSUME ALL ELECTRICAL PARTS AND WIRING ARE ENERGIZED UNLESS KNOWN OTHERWISE.

### Tipping Hazards

- The user must be familiar with the surface before driving. Do not exceed the allowable sideslope and grade while driving.



- Do not elevate platform or drive with platform elevated while on or near a sloping, uneven, or soft surface. Ensure machine is positioned on a firm, level and smooth surface before elevating platform or driving with the platform in the elevated position.
- Before driving on floors, bridges, trucks, and other surfaces, check allowable capacity of the surfaces.

3121179

-JLG Lift -

1-7

## SECTION 1 - SAFETY PRECAUTIONS

- Never exceed the maximum work load as specified on the platform. Keep all loads within the confines of the platform, unless authorized by JLG.
- Keep the chassis of the machine a minimum of 2 ft. (0.6m) from holes, bumps, drop-offs, obstructions, debris, concealed holes, and other potential hazards at the ground level.
- Do not push or pull any object with the boom.
- Never attempt to use the machine as a crane. Do not tie-off machine to any adjacent structure. Never attach wire, cable, or any similar items to platform.
- Do not operate the machine when wind conditions exceed 28 mph (12.5 m/s). Refer to Table 1-2, Beaufort Scale (For Reference Only).
- Do not increase the surface area of the platform or the load. Increase of the area exposed to the wind will decrease stability.
- Do not increase the platform size with unauthorized deck extensions or attachments.
- If boom assembly or platform is in a position that one or more wheels are off the ground, all persons must be removed before attempting to stabilize the machine. Use cranes, forklift trucks, or other appropriate equipment to stabilize machine.

1-3

-JLG Lift -

3121179

## **SECTION 1 - SAFETY PRECAUTIONS**

### **NOTICE**

DO NOT OPERATE THE MACHINE WHEN WIND CONDITIONS EXCEED 28 MPH (12.5 M/S).

**Table 1-2. Beaufort Scale (For Reference Only)**

Beaufort Number	Wind Speed		Description	Local Conditions
	mi/h	km/h		
0	0	0-0.2	Calm	Calm. Smoke rises vertically
1	1-3	0.3-1.5	Light air	Wind motion visible in smoke
2	4-7	1.6-3.3	Light breeze	Wind felt on exposed skin. Leaves rustle
3	8-12	3.4-5.4	Gentle breeze	Leaves and smaller twigs in constant motion
4	13-18	5.5-7.9	Moderate breeze	Dust and loose paper raised. Small branches begin to move.
5	19-24	8.0-10.7	Fresh breeze	Small trees sway.
6	25-31	10.8-13.8	Strong breeze	Large branches in motion. Flags waving near horizontal. Umbrella use becomes difficult.
7	32-38	13.9-17.1	Near Gale/Moderate Gale	Whole trees in motion. Effort needed to walk against the wind.
8	39-46	17.2-20.7	Fresh Gale	Twigs broken from trees. Cars veer on road.
9	47-54	20.8-24.4	Strong Gale	Light structure damage.

3121179


- JLG Lift -

**1-9**

## **SECTION 1 - SAFETY PRECAUTIONS**

### **Crushing and Collision Hazards**

- Approved head gear must be worn by all operating and ground personnel.
- Check work area for clearances overhead, on sides, and bottom of platform when lifting or lowering platform, and driving.



- During operation, keep all body parts inside platform railing.
- Use the boom functions, not the drive function, to position the platform close to obstacles.
- Always post a lookout when driving in areas where vision is obstructed.

- Keep non-operating personnel at least 6 ft. (1.8m) away from machine during all driving and swing operations.
- Under all travel conditions, the operator must limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel, and other factors which may cause collision or injury to personnel.
- Be aware of stopping distances in all drive speeds. When driving in high speed, switch to low speed before stopping. Travel grades in low speed only.
- Do not use high speed drive in restricted or close quarters or when driving in reverse.
- Exercise extreme caution at all times to prevent obstacles from striking or interfering with operating controls and persons in the platform.
- Be sure that operators of other overhead and floor level machines are aware of the aerial work platform's presence. Disconnect power to overhead cranes.
- Warn personnel not to work, stand, or walk under a raised boom or platform. Position barricades on floor if necessary.

**1.4 TOWING, LIFTING, AND HAULING**

- Never allow personnel in platform while towing, lifting, or hauling.
- This machine should not be towed, except in the event of emergency, malfunction, power failure, or loading/unloading. Refer to the Emergency Procedures section of this manual for emergency towing procedures.
- Ensure boom is in the stowed position and the turntable locked prior to towing, lifting or hauling. The platform must be completely empty of tools.
- When lifting machine, lift only at designated areas of the machine. Lift the unit with equipment of adequate capacity.
- Refer to the Machine Operation section of this manual for lifting information.

**1.5 MAINTENANCE**

This sub-section contains general safety precautions which must be observed during maintenance of this machine. Additional precautions to be observed during machine maintenance are inserted at the appropriate points in this manual and in the Service and Maintenance Manual. It is of utmost importance that maintenance personnel pay strict attention to these precautions to avoid possible injury to personnel or damage to the machine or property. A maintenance program must be established by a qualified person and must be followed to ensure that the machine is safe.

**Maintenance Hazards**

- Shut off power to all controls and ensure that all moving parts are secured from inadvertent motion prior to performing any adjustments or repairs.
- Never work under an elevated platform until it has been fully lowered to the full down position, if possible, or otherwise supported and restrained from movement with appropriate safety props, blocking, or overhead supports.
- DO NOT attempt to repair or tighten any hydraulic hoses or fittings while the machine is powered on or when the hydraulic system is under pressure.
- Always relieve hydraulic pressure from all hydraulic circuits before loosening or removing hydraulic components.

3121179

-JLG Lift-

1-11

**SECTION 1 - SAFETY PRECAUTIONS**

- DO NOT use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



- Ensure replacement parts or components are identical or equivalent to original parts or components.
- Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. Ensure adequate support is provided when raising components of the machine.

- Do not use machine as a ground for welding.
- When performing welding or metal cutting operations, precautions must be taken to protect the chassis from direct exposure to weld and metal cutting spatter.
- Do not refuel the machine with the engine running.
- Use only approved non-flammable cleaning solvents.
- Do not replace items critical to stability, such as batteries or solid tires, with items of different weight or specification. Do not modify unit in any way to affect stability.
- Refer to the Service and Maintenance Manual for the weights of critical stability items.

** WARNING**

MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH PRIOR WRITTEN PERMISSION FROM THE MANUFACTURER.

## **SECTION 1 - SAFETY PRECAUTIONS**

**Battery Hazards**

- Always disconnect batteries when servicing electrical components or when performing welding on the machine.
  - Do not allow smoking, open flame, or sparks near battery during charging or servicing.
  - Do not contact tools or other metal objects across the battery terminals.
  - Always wear hand, eye, and face protection when servicing batteries. Ensure that battery acid does not come in contact with skin or clothing.

**CAUTION**

**BATTERY FLUID IS HIGHLY CORROSIVE. AVOID CONTACT WITH SKIN AND CLOTHING AT ALL TIMES. IMMEDIATELY RINSE ANY CONTACTED AREA WITH CLEAN WATER AND SEEK MEDICAL ATTENTION.**

- Charge batteries only in a well ventilated area.
  - Avoid overfilling the battery fluid level. Add distilled water to batteries only after the batteries are fully charged.

3121179

-JLG Lift -

1-13

## **SECTION 1 - SAFETY PRECAUTIONS**



**NOTES:**

---

**SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION**

---

**SECTION 2. USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION****2.1 PERSONNEL TRAINING**

The aerial platform is a personnel handling device; so it is necessary that it be operated and maintained only by trained personnel.

Persons under the influence of drugs or alcohol or who are subject to seizures, dizziness or loss of physical control must not operate this machine.

**Operator Training**

Operator training must cover:

1. Use and limitations of the controls in the platform and at the ground, emergency controls and safety systems.
2. Control labels, instructions, and warnings on the machine.
3. Rules of the employer and government regulations.
4. Use of approved fall protection device.
5. Enough knowledge of the mechanical operation of the machine to recognize a malfunction or potential malfunction.

6. The safest means to operate the machine where overhead obstructions, other moving equipment, and obstacles, depressions, holes, dropoffs.
7. Means to avoid the hazards of unprotected electrical conductors.
8. Specific job requirements or machine application.

**Training Supervision**

Training must be done under the supervision of a qualified person in an open area free of obstructions until the trainee has developed the ability to safely control and operate the machine.

**Operator Responsibility**

The operator must be instructed that he/she has the responsibility and authority to shut down the machine in case of a malfunction or other unsafe condition of either the machine or the job site.

3121179

-JLG Lift-

2-1

---

**SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION**

---

**2.2 PREPARATION, INSPECTION, AND MAINTENANCE**

The following table covers the periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as necessary when the machine is used in a harsh or hostile environment, if the machine is used with increased frequency, or if the machine is used in a severe manner.

**NOTICE**

JLG INDUSTRIES, INC. RECOGNIZES A FACTORY TRAINED SERVICE TECHNICIAN AS A PERSON WHO HAS SUCCESSFULLY COMPLETED THE JLG SERVICE TRAINING SCHOOL FOR THE SPECIFIC JLG PRODUCT MODEL.

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

Table 2-1.Inspection and Maintenance Table

Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Start Inspection	Before using each day; or whenever there's an Operator change.	User or Operator	User or Operator	Operator and Safety Manual
Pre-Delivery Inspection (See Note)	Before each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form
Frequent Inspection (See Note)	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or Purchased used.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form
Annual Machine Inspection (See Note)	Annually, no later than 13 months from the date of prior inspection.	Owner, Dealer, or User	Factory Trained Service Technician (Recommended)	Service and Maintenance Manual and applicable JLG inspection form
Preventative Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual

**NOTE:** Inspection forms are available from JLG. Use the Service and Maintenance Manual to perform inspections.

3121179

- JLG Lift -

2-3

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

### Pre-Start Inspection

The Pre-Start Inspection should include each of the following:

1. **Cleanliness** – Check all surfaces for leakage (oil, fuel, or battery fluid) or foreign objects. Report any leakage to the proper maintenance personnel.
2. **Decals and Placards** – Check all for cleanliness and legibility. Make sure none of the decals and placards are missing. Make sure all illegible decals and placards are cleaned or replaced.
3. **Operators and Safety Manuals** – Make sure a copy of the Operator and Safety Manual, EMI Safety Manual (Domestic only), and ANSI Manual of Responsibilities (Domestic only) is enclosed in the weather resistant storage container.
4. **"Walk-Around" Inspection** – Refer to Figure 2-3, and Figure 2-4, and Figure 2-5.
5. **Battery** – Charge as required.
6. **Fuel** (Combustion Engine Powered Machines) – Add the proper fuel as necessary.
7. **Engine Oil Supply** – Ensure the engine oil level is at the Full mark on the dipstick and the filler cap is secure.
8. **Hydraulic Oil** – Check the hydraulic oil level. Ensure hydraulic oil is added as required.


9. **Accessories/Attachments** – Reference the Operator and Safety Manual of each attachment for accessory installed upon the machine for specific inspection, operation, and maintenance instructions.

10. **Function Check** – Once the "Walk-Around" inspection is complete, perform a functional check of all systems in an area free of overhead and ground level obstructions. Refer to Section 4 for more specific instructions.

### WARNING

IF THE MACHINE DOES NOT OPERATE PROPERLY, TURN OFF THE MACHINE IMMEDIATELY! REPORT THE PROBLEM TO THE PROPER MAINTENANCE PERSONNEL. DO NOT OPERATE THE MACHINE UNTIL IT IS DECLARED SAFE FOR OPERATION.

**SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION**



**Figure 2-1. Basic Nomenclature - Sheet 1 of 2**

3121179

- JLG Lift -

**2-5**

**SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION**

1. SteerWheels
2. Drive Wheels
3. Lower Lift Cylinder
4. Lower Upright
5. Mid Boom
6. Upper Lift Cylinder
7. Main Boom Assembly
8. Power Track
9. Level Cylinder
10. Jib Cylinder
11. Platform
12. Platform Console
13. Jib
14. Fly Boom
15. Base Boom
16. Master Cylinder
17. Tower or Lower Boom
18. Turntable
19. Frame
20. TowerLink
21. SkyGuard (Ifequipped)

**Figure 2-2. Basic Nomenclature - Sheet 2 of 2**

2-6

- JLG Lift -

3121179

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION




Figure 2-3. Daily Walk-Around Inspection - Sheet 1 of 3

3121179

- JLG Lift -

2-7

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

### General

Begin the "Walk-Around Inspection" at Item 1, as noted on the diagram. Continue to the right (counterclockwise viewed from top) checking each item in sequence for the conditions listed in the following checklist.

#### WARNING

TO AVOID POSSIBLE INJURY, BE SURE MACHINE POWER IS OFF.

DO NOT OPERATE MACHINE UNTIL ALL MALFUNCTIONS HAVE BEEN CORRECTED.

**INSPECTION NOTE:** On all components, make sure there are no loose or missing parts, that they are securely fastened, and no visible damage, leaks or excessive wear exists in addition to any other criteria mentioned.


1. Platform Assembly and Gate - Lockbolts in place, Foot-switch works properly, not modified, disabled or blocked. Latch, stop, and hinges in working condition.

2. Platform & Ground Control Consoles - Switches and levers return to neutral, decals/placards secure and legible, control markings legible.
3. All Hydraulic Cylinders - No visible damage; pivot pins and hydraulic hoses undamaged, not leaking.
4. Boom Sections/Uprights/Turntable - See Inspection Note.
5. Boom Limit Switches - Switches operate properly.
6. Drive Motor, Brake, and Hub - No evidence of leakage.
7. Wheel/Tire Assemblies - Properly secured, no missing lug nuts, proper inflation (pneumatic).
8. Hood Assemblies - See Inspection Note.

Figure 2-4. Daily Walk-Around inspection - Sheet 2 of 3

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

9. **Oscillation Lockout Valve (If Equipped) (450 Models Prior to S/N 0300077285, 510 Models Prior to S/N 1300000353)** - Check the lockout valve plunger in the depressed position. Swing the turntable until the axle lockout bracket passes the plunger and make sure the plunger is fully extended as shown below



10. **Tie Rod Ends and Steering Spindles** - See Inspection Note.
11. **Turntable Bearing** - Evidence of proper lubrication. No evidence of loose bolts or looseness between bearing and machine.
12. **Swing Motor and Worm Gear** - Evidence of proper lubrication; No evidence of damage.
13. **Auxiliary Hydraulic Pump** - See Inspection Note.
14. **Main Hydraulic Pump** - See Inspection Note.
15. **Platform Rotator** - See Inspection Note.
16. **SkyGuard** - See Inspection Note.

Figure 2-5, Daily Walk-Around Inspection - Sheet 3 of 3

3121179

-JLG Lift -

2-9

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

### Function Check

Perform the Function Check as follows:

1. From the ground control panel with no load in the platform:
  - a. Check that all guards protecting the switches or locks are in place;
  - b. Operate all functions and check boom limit switches; drive speed should switch to creep mode if lower boom is elevated or main boom is above horizontal;
  - c. Check auxiliary power (or manual descent);
  - d. Ensure that all machine functions are disabled when the Emergency Stop Button is activated.
2. From the platform control console:
  - a. Ensure that the control console is firmly secured in the proper location;
  - b. Check that all guards protecting the switches or locks are in place;
  - c. Operate all functions and check all limiting and cut-out switches;
  - d. Ensure that all machine functions are disabled when the Emergency Stop Button is pushed in.

### With the platform in the transport (stowed) position:

- a. Drive the machine on a grade, not to exceed the rated gradeability, and stop to ensure the brakes hold;
- b. Check the tilt sensor alarm to ensure proper operation.

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

### SkyGuard Function Test

From the Platform Console:


Test the SkyGuard feature by operating the telescope out functions and then activating the SkyGuard sensor. The telescope out function will stop and the telescope in function will operate for a short duration. The horn will sound until the SkyGuard sensor and footswitch are disengaged.

**NOTE:** If the machine is equipped with both SkyGuard and Soft Touch, functions will not reverse, only stop.

**NOTE:** If equipped, ensure the SkyGuard beacon illuminates when SkyGuard is activated.

Disengage the SkyGuard sensor, release controls, recycle the emergency stop button, and ensure sure normal operation is available.

If SkyGuard remains activated after function reversal or cutout, depress and hold the SkyGuard Override Switch to allow normal use of machine functions until the SkyGuard sensor is disengaged.



3121179

- JLG Lift -

2-11

## SECTION 2 - USER RESPONSIBILITIES, MACHINE PREPARATION, AND INSPECTION

### 2.3 OSCILLATING AXLE LOCKOUT TEST (IF EQUIPPED)

#### NOTICE

LOCKOUT SYSTEM TEST MUST BE PERFORMED QUARTERLY, ANY TIME A SYSTEM COMPONENT IS REPLACED, OR WHEN IMPROPER SYSTEM OPERATION IS SUSPECTED.

**NOTE:** Ensure boom is fully retracted, lowered, and centered between drive wheels prior to beginning lockout cylinder test.

1. Place a 6 inches (15.2 cm) high block with ascension ramp in front of left front wheel.
2. From platform control station, start engine.
3. Place the Drive control lever to the forward position and carefully drive machine up ascension ramp until left front wheel is on top of block.
4. Carefully activate Swing control lever and position boom over right side of machine. With boom over right side of machine, place Drive control lever to Reverse and drive machine off of block and ramp.
5. Have an assistant check to see that left front or right rear wheel remains elevated in position off of ground.
6. Carefully activate Swing control lever and return boom to stowed position (centered between drive wheels). When boom reaches center stowed position, lockout cylinders

should release and allow wheel to rest on ground, it may be necessary to activate Drive to release cylinders.

7. Place the 6 inches (15.2 cm) high block with ascension ramp in front of right front wheel.
8. Place Drive control lever to Forward and carefully drive machine up ascension ramp until right front wheel is on top of block.
9. With boom over left side of machine, place Drive control lever to Reverse and drive machine off of block and ramp.
10. Have an assistant check to see that right front or left rear wheel remains elevated in position off of ground.
11. Carefully activate Swing control lever and return boom to stowed position (centered between drive wheels). When boom reaches center, stowed position, lockout cylinders should release and allow wheel to rest on ground, it may be necessary activate Drive to release cylinders.
12. If lockout cylinders do not function properly, have qualified personnel correct the malfunction prior to any further operation.

## SECTION 3 - MACHINE CONTROLS AND INDICATORS

### SECTION 3. MACHINE CONTROLS AND INDICATORS

#### 3.1 GENERAL

##### NOTICE

THE MANUFACTURER HAS NO DIRECT CONTROL OVER MACHINE APPLICATION AND OPERATION. THE USER AND OPERATOR ARE RESPONSIBLE FOR CONFORMING WITH GOOD SAFETY PRACTICES.

This section provides the necessary information needed to understand control functions.

#### 3.2 CONTROLS AND INDICATORS

##### Ground Control Station

**NOTE:** If equipped, the Function Enable switch must be held down in order to operate Telescope, Swing, Tower Lift, Main Lift, Jib Lift, Platform Level Override, and Platform Rotate functions.

##### WARNING

DO NOT OPERATE FROM GROUND CONTROL STATION WITH PERSONNEL IN THE PLATFORM EXCEPT IN AN EMERGENCY.

PERFORM AS MANY PRE-OPERATIONAL CHECK AND INSPECTIONS FROM GROUND CONTROLS AS POSSIBLE.

##### 1. Platform Rotate

A three position switch controls rotation of the platform.

##### WARNING

ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANTS TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

##### 2. Platform Leveling Override

A three position switch allows the operator to adjust the automatic self leveling system. This switch is used to adjust the platform level in situations such as ascending/descending a grade.

3121179

- JLG Lift -

3-1

### SECTION 3 - MACHINE CONTROLS AND INDICATORS




Figure C-1. Ground Control Station - A Models

### SECTION 3 - MACHINE CONTROLS AND INDICATORS




Figure 3-1. Ground Control Station - AJ Models

3121179

- JLG Lift -

3-3

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

#### 3. Articulating Jib Boom (If Equipped)

This switch provides raising and lowering of the jib.

#### 4. Engine Start/Auxiliary Power Switch OR

Engine Start/ Auxiliary Power Switch /Function Enable.



To start the engine, the switch must be held "UP" until the engine starts.



To use auxiliary power, the switch must be held "DOWN" for duration of auxiliary pump use. Aux power can only be used if the engine is not running.



If equipped, the enable switch must be held "DOWN" to enable all boom controls when the engine is running.

**NOTE:** Auxiliary power only works if there is no oil pressure, and is disabled if engine is running.

#### 5. Power/Emergency Stop

A two-position red mushroom shaped switch furnishes power to Platform/Ground Select switch when pulled out (on). When pushed in (off), power is shut off to the Platform/Ground Select switch.

#### 6. Platform/Ground Select

A three position, key operated switch supplies power to the platform control console when positioned to Platform. With the switch key held in the Ground position, power is shut off to platform and only ground controls are operable.

**NOTE:** When machine is shut down the Platform/Ground Select switch and Emergency Stop must be positioned to OFF.

**NOTE:** With PLATFORM/GROUND SELECT switch in the center position, power is shut off to controls at both operating stations.

#### 7. Hourmeter

The hourmeter registers up to 9,999.9 hours and cannot be reset.

#### 8. Swing Control

The Swing control switch provides 360 degrees non-continuous turntable rotation when positioned to the right or left.

### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**

**9. Tower Lift**

Provides for raising and lowering of the Lower and Mid Booms.

**10. Main Boom Lift**

Provides for raising and lowering of the Main Boom.

**11. Telescope**

Provides for extension and retraction of the Main Boom.

### **Ground Control Indicator Panel**

**1. Battery Charging Indicator**

Indicates a problem in the battery or charging circuit, and service is required.

**2. Engine Oil Pressure Indicator**

Indicates that engine oil pressure is below normal and service is required.

**3. Engine Coolant Temperature Indicator (Liquid Cooled Engines)**

Indicates that engine coolant temperature is abnormally high and service is required.

**4. Engine Oil Temperature Indicator (Deutz)**

Indicates that the temperature of the engine oil, which also serves as engine coolant, is abnormally high and service is required.

3121179

-JLG Lift-

3-5

### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**





Figure 3-2. Ground Control Indicator Panel - Sheet 1 of 2

---

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

---



S/N's 0300099085 & 1300002506 to Present

- |                            |                             |
|----------------------------|-----------------------------|
| 1. Battery Charging        | 6. Low Fuel                 |
| 2. Low Engine Oil Pressure | 7. Glow Plug Wait           |
| 3. Engine Coolant Temp.    | 8. Overload                 |
| 4. Engine Oil Temp.        | 9. Not Used                 |
| 5. Engine Malfunction      | 10. Drive and Steer Disable |

Figure 3-3. Ground Control Indicator Panel - Sheet 2 of 2

3121179

-JLG Lift-

3-7

---

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

---

#### 5. Engine Malfunction Indicator

The light indicates that the JLG Control System has detected a malfunction and a Diagnostic Trouble Code has been set in the system memory. Refer to the Service Manual for instructions concerning the trouble codes and trouble code retrieval.

The malfunction indicator light will illuminate for 2-3 seconds when the key is positioned to the on position to act as a self test.

#### 6. Low Fuel Level Indicator

Indicates fuel level is 1/8 full or less.

**NOTE:** Refer to Fuel Reserve/Shut-Off System in Section 4 for detailed information.

#### 7. Glow Plug Wait Indicator

Indicates the glow plugs are on. The glow plugs are automatically turned on with the ignition circuit and remain on for approximately seven seconds. Start the engine only after the light goes out.

#### 8. Overload Indicator. (If Equipped)

Indicates the platform has been overloaded.

#### 9. Engine Air Filter Indicator

Indicates that the air filter is too restrictive and needs to be replaced.

#### 10. Drive and Steer Disable Indicator (If equipped)

Indicates the Drive and Steer Disable function has been activated.

## SECTION 3 - MACHINE CONTROLS AND INDICATORS

### Platform Control Station

#### 1. Drive Speed Switch

**(4WD Machines)** - The forward position gives maximum drive speed by shifting the drive motors to minimum displacement and giving high engine when drive controller is moved. The back position gives maximum torque for rough terrain and climbing grades by shifting the wheel motors to maximum displacement and giving high engine speed when drive controller is moved. The center position allows the machine to be driven as quietly as possible by leaving the engine at mid speed and the drive motors in maximum displacement.

**(2WD Machines)** - The forward position selects maximum speed by operating at high engine rpm. The backward position selects mid engine rpm.

#### A WARNING

ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANTS TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

#### 2. Platform Leveling Override

A three position switch allows the operator to adjust the automatic self leveling system. This switch is used to adjust the platform level in situations such as ascending/descending a grade.

#### 3. Horn

If pressed, this switch supplies power to the horn.

#### 4. Power/Emergency Stop


An on-off Power/Emergency Stop switch and a separate Engine Start/Auxiliary Power toggle switch on the platform console supply electrical power to the starter solenoid, when the Ignition switch is placed in the ON position and the ENGINE START switch is pushed forward.

3121179

- JLG Lift -

3-9

## SECTION 3 - MACHINE CONTROLS AND INDICATORS



1. Drive Speed      3. Aux. Power      9. Telescope      13. Function Speed  
2. Platform Leveling Override      4. FuelSelect      10. Jlb      14. Main Lift/Swing  
3. Horn      5. Lights      11. Tower Lift  
4. Power/Emergency Stop      6. Driver Steer      12. Platform Rotate


Figure 3-4. Platform Control Console

3-12

- JLG Lift -

3-12

### SECTION 3 - MACHINE CONTROLS AND INDICATORS



**Figure 3-5. Platform Control Console - w/Drive Orientation**

3121179

-JLG Lift-

3-11

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

#### **WARNING**

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVERS OR TOGGLE SWITCHES CONTROLLING PLATFORM MOVEMENT DO NOT RETURN TO THE OFF OR NEUTRAL POSITION WHEN RELEASED.

##### 5. Auxiliary Power

The Auxiliary Power control switch energizes the electrically operated hydraulic pump. (Switch must be held ON for duration of auxiliary pump use.)

The auxiliary pump functions to provide sufficient oil flow to operate the basic machine functions should the main pump or engine fail. The auxiliary pump will operate tower boom lift, tower telescope, main boom lift, main telescope and swing.

##### 6. Fuel Select (Dual Fuel Engine Only) (If Equipped)

Moving the switch to the appropriate position selects gasoline or liquid propane fuel.

##### 7. Lights (If Equipped)

This switch operates control console panel lights and head lights if the machine is so equipped.

##### 8. Drive/Steer

The DRIVE joystick provides for driving either forward or backward. The controller is 'ramped' to allow variable drive speed.

Steering is controlled by a thumb operated switch on top of the joystick.

##### 9. Telescope Control

This switch allows extension and retraction of the main boom.

##### 10. Articulating Jib Boom (If Equipped)

This switch controls the raising or lowering of the jib.

##### 11. Tower or Lower Boom Lift

Provides for raising and lowering of the lower and mid booms when positioned up or down.

##### 12. Platform Rotate

This switch controls the rotation of the basket (left or right).

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

#### 13. Function Speed Control

Controls the speed of Boom and Swing Functions. Rotate CCW for slower speed and CW for faster speed. To adjust to creep, turn knob fully CCW until it clicks.

#### 14. Main Lift/Swing

The dual axis joystick is provided for main lift and swing. Push forward to lift up, pull backward to lower. Move right to swing right, move left to swing left. Proportional control of these functions can be attained by using the Function Speed control.

**NOTE:** Main lift and swing functions may be selected at the same time. Maximum speed is reduced when both functions are selected.

#### 15. Drive Orientation Override

When the boom is swung over the rear tires or further in either direction, the Drive Orientation indicator will illuminate when the drive function is selected. Push and release the switch, and within 3 seconds move the Drive/Steer control to activate drive or steer. Before driving, locate the black/white orientation arrows on both the chassis and the platform controls and match the control direction arrow to the intended chassis direction.

#### 16. Soft Touch/SkyGuard Override Switch (If Equipped)

The machine can be equipped with one of three options. It may have Soft Touch, SkyGuard, or both Soft Touch and SkyGuard.

If equipped with Soft Touch, the switch enables the functions that were cut out by the Soft Touch system to operate again at creep speed, allowing the operator to move the platform away from the obstacle that caused the shutdown situation.

If equipped with SkyGuard, the switch enables functions cut out by the Skyguard system to be operated again, allowing the operator to resume use of machine functions.

If equipped with both Soft Touch and SkyGuard, the switch

3121179

- JLG Lift -

3-13

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

operates like described above and allows the operator to override the system that has experienced a cutout situation.

#### 17. Soft Touch Indicator/SkyGuard (If Equipped)

Indicates the Soft Touch bumper is against an object or the SkyGuard sensor has been activated. All controls are cut out until the override button is pushed. For Soft Touch, controls are then active in the Creep Mode or for SkyGuard, controls will work normally.

#### Platform Control Indicator Panel

**NOTE:** The platform control indicator panel (S/N 0300065315 to Present) uses different shaped symbols to alert the operator to different types of operational situations that could arise. The meaning of those symbols are explained below.



Indicates a potentially hazardous situation, which if not corrected, could result in serious injury or death. This indicator will be red.



Indicates an abnormal operating condition, which if not corrected, may result in machine interruption or damage. This indicator will be yellow.



Indicates important information regarding the operating condition, i.e. procedures essential for safe operation. This indicator will be green with the exception of the capacity indicator which will be green or yellow depending upon platform position.

#### 1. AC Generator (Green)

Indicates the generator is in operation.

3121179

- JLG Lift -

3121179

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

2. Overload Indicator, (If equipped)

Indicates the platform has been overloaded.

3. Tilt Alarm Warning Light and Alarm

This orange illuminator indicates that the chassis is on a slope. An alarm will also sound when the chassis is on a slope and the boom is above horizontal. If lit when boom is raised or extended, retract and lower to below horizontal then reposition machine so that it is level before continuing operation. If the boom is above horizontal and the machine is on a slope, the tilt alarm warning light will illuminate and an alarm will sound and CREEP is automatically activated.

and the function selected within seven seconds. The enable indicator shows that the controls are enabled. If a function is not selected within seven seconds, or if a seven second lapse between ending one function and beginning the next function, the enable light will go out and the footswitch must be released and depressed again to enable the controls.

**NOTE:** For engine starting, the footswitch must be in the released (up) position.

**WARNING**

**TO AVOID SERIOUS INJURY, DO NOT REMOVE, MODIFY OR DISABLE THE FOOTSWITCH BY BLOCKING OR ANY OTHER MEANS.**

**WARNING**

**FOOTSWITCH MUST BE ADJUSTED IF FUNCTIONS ACTIVATE WHEN SWITCH ONLY OPERATES WITHIN LAST 1/4" OF TRAVEL, TOP OR BOTTOM.**

**WARNING**

**IF TILT WARNING LIGHT IS ILLUMINATED WHEN BOOM IS RAISED OR EXTENDED, RETRACT AND LOWER TO BELOW HORIZONTAL THEN REPOSITION MACHINE SO THAT IT IS LEVEL BEFORE EXTENDING BOOM OR RAISING BOOM ABOVE HORIZONTAL.**

4. Glow Plug Indicator

Indicates the glow plugs are operating. After turning on ignition, wait until light goes out before cranking engine.

5. Footswitch/Enable Indicator


To operate any function, the footswitch must be depressed

3121179

- JLG Lift -

3-15

### SECTION 3 - MACHINE CONTROLS AND INDICATORS



Prior to S/N 0300065315


- |                     |              |                      |
|---------------------|--------------|----------------------|
| 1. ACGenerator      | 4. GlowPlug  | 7. CreepSpeed        |
| 2. Overload         | 5. Enable    | 8. SystemMalfunction |
| 3. TiltAlarmWarning | 6. FuelLevel | 9. SoftTouch         |

Figure 3-6. Platform Control Indicator Panel - Sheet 1 of 2

---

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

---



S/N 0300065315 & 1300000001 to Present

- |                       |               |                       |
|-----------------------|---------------|-----------------------|
| 1. AC Generator       | 4. Glow Plug  | 7. Creep Speed        |
| 2. Overload           | 5. Enable     | 8. System Malfunction |
| 3. Tilt Alarm Warning | 6. Fuel Level | 9. Soft Touch         |

Figure 3-7. Platform Control Indicator Panel - Sheet 2 of 2

3121179


- JLG Lift -

3-17

---

### SECTION 3 - MACHINE CONTROLS AND INDICATORS

---



- |                       |                |                       |
|-----------------------|----------------|-----------------------|
| 1. AC Generator       | 5. Enable      | 8. System Malfunction |
| 2. Overload           | 6. Fuel Level  | 9. Not Used           |
| 3. Tilt Alarm Warning | 7. Creep Speed | 10. Drive Orientation |
| 4. Glow Plug          |                |                       |

Figure 3-8. Platform Control Indicator Panel - w/Drive Orientation

3-18

- JLG Lift -

3121179

### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**

- 6. Low Fuel Indicator (Yellow)**  
Indicates fuel tank is 1/8 full or less.
  - NOTE:** Refer to *Fuel Reserve/Shut-Off System* in Section 4 for detailed information.
  - 7. Creep Speed Indicator**  
Illuminates when the Function Speed Control is turned to the creep position.
  - 8. System Malfunction Indicator**  
The light indicates that the JLG Control System has detected a malfunction and a Diagnostic Trouble Code has been set in the system memory. Refer to the Service Manual for instructions concerning the trouble codes and trouble code retrieval.  
  
The malfunction indicator light will illuminate for 2-3 seconds when the key is positioned to the on position to act as a self test.
  - 9. Soft Touch Indicator (If Equipped)**  
Illuminates when the Soft Touch bumper is against an object. All controls are cut out until the override button is pushed, at which time controls are active in the Creep mode.
  - 10. Drive Orientation Indicator**  
When the boom is swung beyond the rear drive tires or further in either direction, the Drive Orientation indicator will illuminate when the drive function is selected. This is a signal for the operator to activate the Drive Orientation Override Switch and verify the drive control direction is correct.

3121179

- 116 / lift -

3-19

### **SECTION 3 - MACHINE CONTROLS AND INDICATORS**



#### **NOTES:**

**SECTION 4. MACHINE OPERATION****4.1 DESCRIPTION**

This machine is a self-propelled hydraulic lift equipped with a work platform on the end of an elevating, articulating and rotating boom.

The primary operator control station is in the platform. From this control station, the operator can drive and steer the machine in both forward and reverse directions. The operator can raise or lower the boom or swing the boom to the left or right. Standard boom swing is 360 degree non continuous left and right of the stowed position. The machine has a Ground Control Station which will override the Platform Control Station. Ground Controls operate Boom Lift and Swing, and are to be used in an emergency to lower the platform to the ground should the operator in the platform be unable to do so. The Ground Control is also to be used in Pre-Start Inspection.

**4.2 OPERATING CHARACTERISTICS AND LIMITATIONS****Capacities**

The boom can be raised above horizontal with or without any load in platform, if:

1. Machine is positioned on a smooth, firm and level surface.
2. Load is within manufacturer's rated capacity.
3. All machine systems are functioning properly.
4. Proper tire pressure.
5. Machine is as originally equipped from JLG.

3121179

- JLG Lift -

4-1

**SECTION 4 - MACHINE OPERATION****Stability**

Machine stability is based on two (2) conditions which are called FORWARD and BACKWARD stability. The machine's position of least FORWARD stability is shown in (See Figure 4-1), and its position of least BACKWARD stability is shown in (See Figure 4-2).

** WARNING**

TO AVOID FORWARD OR BACKWARD TIPPING, DO NOT OVERLOAD MACHINE OR OPERATE THE MACHINE ON AN OUT-OF-LEVEL SURFACE.

**4.3 ENGINE OPERATION**

**NOTE:** Initial starting should always be performed from the Ground Control station.

**Starting Procedure**** CAUTION**

IF ENGINE FAILS TO START PROMPTLY, DO NOT CRANK FOR AN EXTENDED TIME. SHOULD ENGINE FAIL TO START AGAIN, ALLOW STARTER TO "COOL OFF" FOR 2-3 MINUTES. IF ENGINE FAILS AFTER SEVERAL ATTEMPTS, REFER TO ENGINE MAINTENANCE MANUAL.

**NOTE:** Diesel engines only: After turning on ignition, operator must wait until glow plug indicator light goes out before cranking engine.

1. Turn key of SELECT switch to GROUND. Position POWER/EMERGENCY STOP switch to ON, then push the ENGINE START switch until engine starts.

** CAUTION**

ALLOW ENGINE TO WARM-UP FOR A FEW MINUTES AT LOW SPEED BEFORE APPLYING ANY LOAD.

## SECTION 4 - MACHINE OPERATION

2. After engine has had sufficient time to warm up, shut engine off.
3. Turn SELECT switch to PLATFORM.
4. From Platform, pull POWER/EMERGENCY STOP switch out, then push the ENGINE START switch until engine starts.

**NOTE:** Footswitch must be in released (up) position before starter will operate. If starter operates with footswitch in the depressed position, DO NOT OPERATE MACHINE.

### Shutdown Procedure

#### CAUTION

IF AN ENGINE MALFUNCTION CAUSES AN UNSCHEDULED SHUTDOWN, DETERMINE THE CAUSE AND CORRECT IT BEFORE RESTARTING THE ENGINE.

1. Remove all load and allow engine to operate at low speed for 3-5 minutes; this allows further reduction of internal engine temperature.
2. Push POWER/EMERGENCY STOP switch in.
3. Turn MASTER switch to Off.

Refer to Engine Manufacturer's manual for detailed information.

## SECTION 4 - MACHINE OPERATION

### Fuel Reserve / Shut-Off System (450/510)

**NOTE:** Reference the Service and Maintenance Manual along with a qualified JLG Mechanic to verify your machine setup.

The Fuel Shutoff System monitors the fuel in the tank and senses when the fuel level is getting low. The JLG Control System automatically shuts the engine down before the fuel tank is emptied unless the machine is set up for Engine Restart.

If fuel level reaches the Empty range, the Low Fuel light will begin to flash once a second and there will be approximately 60 minutes of engine run time left. If the system is in this condition and automatically shuts down the engine or if the operator manually shuts down the engine before the 60 minute run time is complete, the Low Fuel light will flash 10 times a second and the engine will react according to machine setup. Setup options are as follows:



- Engine One Restart - When the engine shuts down, the operator will be permitted to cycle power and restart the engine once with approximately 2 minutes of run time. After the 2 minute run time is complete or if the engine is shut down by the operator prior to the completion of the 2 minute run time, it cannot be restarted until fuel is added to the tank.

- Engine Restart - When the engine shuts down, the operator will be permitted to cycle power and restart the engine for approximately 2 minutes of run time. After the 2 minutes of run time is complete, the operator may cycle power and restart the engine for an additional 2 minutes of run time. The operator can repeat this process until there is no more fuel available.

- Engine Stop - When the engine shuts down, no restarts will be permitted until fuel is added to the tank.




Figure 4-1. Position of Least Forward Stability

3121179

- JLG Lift -

4-5

## SECTION 4 - MACHINE OPERATION

## 4.4 TRAVELING (DRIVING)

**WARNING**

DO NOT DRIVE WITH BOOM ABOVE HORIZONTAL EXCEPT ON A SMOOTH, FIRM AND LEVEL SURFACE.

TO AVOID LOSS OF TRAVEL CONTROL OR "TIP OVER", DO NOT DRIVE MACHINE ON GRADES EXCEEDING THOSE SPECIFIED ON THE SERIAL NUMBER TAG OR AS NOTED IN THE OPERATORS MANUAL.

DO NOT DRIVE ON SIDESLOPES WHICH EXCEED 5 DEGREES (ANSI MARKETS) OR 4 DEGREES (CE & AUSTRALIA MARKETS).

USE EXTREME CAUTION WHEN DRIVING IN REVERSE AND AT ALL TIMES WHEN THE PLATFORM IS ELEVATED.

TRAVEL GRADES WITH DRIVE SPEED/TORQUE SELECT SWITCH IN THE FORWARD POSITION. USE CAUTION WHEN DRIVING IN REVERSE AND WHEN DRIVING WITH PLATFORM ELEVATED, ESPECIALLY WHEN DRIVING WITH ANY PART OF MACHINE WITHIN 6 FEET (2 M) OF AN OBSTRUCTION.

BEFORE DRIVING, MAKE SURE BOOM IS POSITIONED OVER REAR DRIVE AXLE. IF BOOM IS OVER FRONT WHEELS, STEER AND DRIVE CONTROLS WILL BE REVERSED.




Figure 4-2. Position of Least Backward Stability

4-6

- JLG Lift -

3121179

## SECTION 4 - MACHINE OPERATION





Figure 4-1. Position of Least Forward Stability

3121179

-JLG Lift-

4-5

## SECTION 4 - MACHINE OPERATION



### 4.4 TRAVELING (DRIVING)

#### ⚠ WARNING

DO NOT DRIVE WITH BOOM ABOVE HORIZONTAL EXCEPT ON A SMOOTH, FIRM AND LEVEL SURFACE.

TO AVOID LOSS OF TRAVEL CONTROL OR "TIP OVER", DO NOT DRIVE MACHINE ON GRADES EXCEEDING THOSE SPECIFIED ON THE SERIAL NUMBER TAG OR AS NOTED IN THE OPERATORS MANUAL.

DO NOT DRIVE ON SIDESLOPES WHICH EXCEED 5 DEGREES (ANSI MARKETS) OR 4 DEGREES (CE & AUSTRALIA MARKETS).

USE EXTREME CAUTION WHEN DRIVING IN REVERSE AND AT ALL TIMES WHEN THE PLATFORM IS ELEVATED.

TRAVEL GRADES WITH DRIVE SPEED/TORQUE SELECT SWITCH IN THE FORWARD POSITION. USE CAUTION WHEN DRIVING IN REVERSE AND WHEN DRIVING WITH PLATFORM ELEVATED, ESPECIALLY WHEN DRIVING WITH ANY PART OF MACHINE WITHIN 6 FEET (2 M) OF AN OBSTRUCTION.

BEFORE DRIVING, MAKE SURE BOOM IS POSITIONED OVER REAR DRIVE AXLE. IF BOOM IS OVER FRONT WHEELS, STEER AND DRIVE CONTROLS WILL BE REVERSED.

Figure 4-2. Position of Least Backward Stability

4-5

-JLG Lift-

3121179




Figure 4-3. Grade and Side Slopes

3121179

-JLG Lift-

4-7

**SECTION 4 - MACHINE OPERATION****Traveling Forward and Reverse**

- With the engine running, activate footswitch.
- Position Drive controller to FORWARD or REVERSE as desired.

This machine is equipped with a Drive Orientation Indicator. The yellow light on the platform control console indicates that the boom is swung beyond the rear drive tires and the machine may Drive/Steer in the opposite direction from the movement of the controls. If the indicator is illuminated, operate the Drive function in the following manner:

- Match the black and white direction arrows on both platform control panel and the chassis to determine the direction the machine will travel.
- Push and release the Drive Orientation Override switch. Within 3 seconds, slowly move the Drive control toward the arrow matching the intended direction of machine travel. The indicator light will flash during the 3 second interval until the drive function is selected.

**4.5 STEERING**

Position thumb switch on Drive/Steer controller to RIGHT for steering right, or to LEFT for steering left.

**4.6 PLATFORM****Platform Level Adjustment****WARNING**

ONLY USE THE PLATFORM LEVELING OVERRIDE FUNCTION FOR SLIGHT LEVELING OF THE PLATFORM. INCORRECT USE COULD CAUSE THE LOAD/OCCUPANTS TO SHIFT OR FALL. FAILURE TO DO SO COULD RESULT IN DEATH OR SERIOUS INJURY.

This switch is used to adjust the platform level in situations such as ascending/descending a grade. To Level Up or Down - Position the Platform/Level control switch Up or Down and hold until the platform is level.

**Platform Rotation**

To rotate the platform to the left or right, use the Platform Rotate control switch to select the direction and hold until desired position is reached.

#### 4.7 BOOM

**WARNING**

DO NOT SWING OR RAISE BOOM ABOVE HORIZONTAL WHEN MACHINE IS OUT OF LEVEL.

DO NOT DEPEND ON TILT ALARM AS A LEVEL INDICATOR FOR THE CHASSIS.

TO AVOID SERIOUS INJURY, DO NOT OPERATE MACHINE IF ANY CONTROL LEVER OR TOGGLE SWITCH CONTROLLING PLATFORM MOVEMENT DOES NOT RETURN TO THE 'OFF' OR NEUTRAL POSITION WHEN RELEASED.

IF THE PLATFORM DOES NOT STOP WHEN A CONTROL SWITCH OR LEVER IS RELEASED, REMOVE FOOT FROM FOOTSWITCH OR USE EMERGENCY STOP SWITCH TO STOP THE MACHINE.

##### Swinging the Boom

To swing boom, use SWING control switch to select RIGHT or LEFT direction.

**NOTICE**

WHEN SWINGING THE BOOM MAKE SURE THERE IS AMPLE ROOM FOR THE BOOM TO CLEAR SURROUNDING WALLS, PARTITIONS AND EQUIPMENT.

##### Raising and Lowering the Lower and Mid Boom

To raise or lower the Lower Boom, use Lower Boom Lift switch to select UP or DOWN movement.

##### Raising and Lowering the Main (Upper) Boom

To raise or lower the Upper Boom, use Upper Boom Lift switch to select UP or DOWN movement.

##### Telescoping the Main Boom

To extend or retract the main boom, use the Main Telescope Control Switch to select IN or OUT movement.

3121179

-JLG Lift-

4-9

#### 4.8 FUNCTION SPEED CONTROL

This control affects the speed of all boom functions to the right of the control and Platform Rotate. When in the CCW maximum position, Drive is placed in creep speed.

#### 4.9 AUXILIARY PUMP

**NOTICE**

WHEN OPERATING ON AUXILIARY POWER, DO NOT OPERATE MORE THAN ONE FUNCTION AT THE SAME TIME. SIMULTANEOUS OPERATION CAN OVERLOAD THE AUXILIARY PUMP MOTOR.

The main function of auxiliary power is to lower the platform in the event of primary power failure. Determine the reason for primary power failure and have the problem corrected by a certified JLG service technician. Operate as follows:

1. Position Platform/Ground switch to Platform.
2. Position Power/Emergency Stop switch to the on position.
3. Depress and hold footswitch.
4. Position Auxiliary Power switch to the on position and hold.

5. Operate appropriate control switch or lever for desired function and hold.
6. Release Auxiliary Power switch, selected control switch or lever, and footswitch.
7. Position Power/Emergency Stop switch to the off position.

#### 4.10 OSCILLATING AXLE LOCKOUT TEST (IF EQUIPPED)

**NOTICE**

LOCKOUT SYSTEM TEST MUST BE PERFORMED QUARTERLY, ANY TIME A SYSTEM COMPONENT IS REPLACED, OR WHEN IMPROPER SYSTEM OPERATION IS SUSPECTED.

Refer to Section 2.3, Oscillating Axle Lockout Test (If Equipped) for procedure.

## SECTION 4 - MACHINE OPERATION

### 4.11 SHUT DOWN AND PARK

1. Drive machine to a reasonably well protected area.
2. Be sure the main boom is fully retracted and lowered over rear drive axle.
3. Remove all load and allow engine to operate 3-5 minutes at LOW setting to permit reduction of internal engine temperatures.
4. At Ground Controls, turn KEY SELECT switch to OFF. Push in the Emergency Stop. Remove key.
5. If necessary, cover Platform Control console to protect instruction placards, warning decals and operating controls from hostile environment.

### 4.12 LIFTING AND TIE DOWN

#### Lifting

1. Refer to the Serial Number Tag, call JLG Industries, or weigh the individual unit to find out the Gross Vehicle Weight.
2. Place the boom in the stowed position.
3. Remove all loose items from the machine.
4. Properly adjust the rigging to prevent damage to the machine and so the machine remains level.

#### Tie Down

##### NOTICE

WHEN TRANSPORTING THE MACHINE, THE BOOM MUST BE FULLY LOWERED INTO THE BOOM REST.

1. Place the boom in the stowed position.
2. Remove all loose items from the machine.
3. Secure the chassis and the platform using straps or chains of adequate strength.

3121179

-JLG Lift-

4-11

## SECTION 4 - MACHINE OPERATION




Figure 4-4. Lifting and Tie Down Chart

## SECTION 4 - MACHINE OPERATION

### 4.13 TOWING

#### **WARNING**

RUNAWAY VEHICLE/MACHINE HAZARD. MACHINE HAS NO TOWING BRAKES. TOWING VEHICLE MUST BE ABLE TO CONTROL MACHINE AT ALL TIMES. ON-HIGHWAY TOWING NOT PERMITTED. FAILURE TO FOLLOW INSTRUCTIONS COULD CAUSE SERIOUS INJURY OR DEATH.

MAXIMUM TOWING SPEED 5 M.P.H. (8 K.M.H.) FOR NO LONGER THAN 30-45 MINUTES.

MAXIMUM TOWING GRADE 25%.

#### Prior to Towing

Prior to towing the machine, complete the following:

#### **CAUTION**

DO NOT TOW MACHINE WITH ENGINE OPERATING OR DRIVE HUBS ENGAGED.

1. Retract, lower and position boom over rear drive wheels in line with direction of travel.

2. Disconnect drive hubs by inverting disconnect cap. (See Figure 4-5.) After towing the machine, complete the following:

3. Reconnect drive hubs by inverting disconnect cap. (See Figure 4-5.)




Figure 4-5. Drive Disconnect Hub

3121179

- JLG Lift -

4-13

## SECTION 4 - MACHINE OPERATION

### 4.14 DUAL FUEL SYSTEM (GAS ENGINE ONLY)

The dual fuel system enables the standard gasoline engine to run on either gasoline or LP gas.

#### **CAUTION**

IT IS POSSIBLE TO SWITCH FROM ONE FUEL SOURCE TO THE OTHER WITHOUT ALLOWING THE ENGINE TO STOP. EXTREME CARE MUST BE TAKEN AND THE FOLLOWING INSTRUCTIONS MUST BE FOLLOWED.

#### Changing From Gasoline to LP Gas

1. Start engine from Ground Control Station.
2. Open hand valve on LP gas supply tank by turning counter-clockwise.
3. While engine is operating on GASOLINE under a no-load condition, place FUEL SELECT switch at Platform Control Station to LP position.

#### Changing From LP Gas to Gasoline

1. With engine operating on LP under a no-load condition, position FUEL SELECT switch at Platform Control Station to GASOLINE position.
2. Close hand valve on LP gas supply tank by turning clockwise.

#### 4.15 SKYGUARD OPERATION

SkyGuard is used to provide enhanced control panel protection. When the SkyGuard sensor is activated, functions that were in use at the time of actuation will reverse or cutout. The table below outlines these functions.

Table 4-1. SkyGuard Function Table

Main Lift	Main Tele In	Main Tele Out	Swing	Drive Forward		Drive Reverse		Tower Lift Up	Tower Lift Down	Platform Level	Platform Rotate	Jib Lift
				DOS Enabled	DOS Not Enabled	DOS Enabled	DOS Not Enabled					
R	C	R	R	R	C*	R	R	R	C	C	C	C

R=Indicates Reversal is Activated  
C=Indicates Cutout is Activated  
\* Disregard when boom is in line and driving forward with or without steering and no other function active  
Note: When Soft Touch is enabled with SkyGuard all functions are cut out only.

3121179

- JLG Lift -

4-15

---

#### SECTION 4 - MACHINE OPERATION

---





Figure 4-6, Decal Installation - Sheet 1 of 3

**SECTION 4 - MACHINE OPERATION**




**Figure 4-7. Decal Installation - Sheet 2 of 6**

3121179

-JLG Lift-

**4-17**

**SECTION 4 - MACHINE OPERATION**



**Figure 4-8. Decal Installation - Sheet 3 of 5**

4-18

-JLG Lift-

3121179

**SECTION 4 - MACHINE OPERATION**




Figure 4-9. Decal Installation - Sheet 4 of 6

3121179

- JLG Lift -

**4-19**

**SECTION 4 - MACHINE OPERATION**




Figure 4-10. Decal Installation - Sheet 5 of 6

3121179

- JLG Lift -

3121179

---

**SECTION 4 - MACHINE OPERATION**

---




Figure 4-11. Decal Installation - Sheet 6 of 6

3121179

- JLG Lift -

4-21

---

**SECTION 4 - MACHINE OPERATION**

---

Table 4-2. Decal Legend - Prior to S/N 0300141424

Item #	ANSI 0272573-11	Australian 0272574-6	Japan 0272575-10	Korean 0272576-10	French/ 0272577-12	Chinese 0272578-10	Portuguese/ Spanish 0272579-11	CE 0273452-4	English/ Spanish 0271189-7
1	1703797	1703992	1703926	1703927	1703924	1703925	1703928	1705821	1703923
2	1703798	1705332	1703932	1703933	1703930	1703931	1703934	1705822	1703929
3	1703805	--	1703938	1703939	1703936	1703937	1703940	--	1703935
4	1703804	1701518	1703950	1703951	1703948	1703949	1703952	1701518	1703947
5	1001108493	--	--	--	1001108493	--	--	--	1001108493
6	1706941	--	--	--	1706941	--	--	--	1706941
7	--	--	--	--	--	--	--	--	--
8	--	--	--	--	--	--	--	--	--
9	--	--	--	--	--	--	--	--	--
10	--	--	--	--	--	--	--	--	--
11	1702868	--	--	--	1704000	--	1704002	--	1704001
12	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277
13	1701645	--	1001121808	1001121918	1001121803	1001121810	1001121920	--	1001121805
14	1707013	--	1001121821	1001121921	1001121816	1001121823	1001121923	--	1001121818
15	--	--	--	--	--	--	--	1705084	--
16	--	--	--	--	--	--	--	--	--

## SECTION 4 - MACHINE OPERATION

**Table 4-2. Decal Legend - Prior to S/N 0300141424**

Item #	ANSI 0272573-11	Australian 0272574-6	Japan 0272575-10	Korean 0272576-10	French/ 0272577-12	Chinese 0272578-10	Portuguese/ Spanish 0272579-11	CE 0273452-4	English/ Spanish 0271189-7
17	--	--	--	--	--	--	--	--	--
18	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504
19	--	--	--	--	1704006	--	1704008	--	1704007
20	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631
21	--	--	--	--	--	--	--	--	--
22	--	1702958	--	--	--	--	--	--	--
23	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509
24	1702300	1702300	1702300	1702300	1702300	1702300	1702300	1702300	1702300
25	1701500	1701500	1701500	1701500	1701500	1701500	1701500	1701500	1701500
26	1701529	1701529	1701529	1701529	1701529	1701529	1701529	1701529	1701529
27	--	--	--	--	--	--	--	--	--
28	--	--	--	--	--	--	--	--	--
29	--	--	--	--	--	--	--	--	--
30	--	--	--	--	--	--	--	--	--
31	--	--	--	--	--	--	--	--	--
32	--	--	--	--	--	--	--	--	--
33	--	--	--	--	--	--	--	--	--
34	3252347	--	1703980	1703981	1703984	1703982	1703985	1705828	1703983

3121179

-JLG Lift -

4-23

## SECTION 4 - MACHINE OPERATION

**Table 4-2. Decal Legend - Prior to S/N 0300141424**

Item #	ANSI 0272573-11	Australian 0272574-6	Japan 0272575-10	Korean 0272576-10	French/ 0272577-12	Chinese 0272578-10	Portuguese/ Spanish 0272579-11	CE 0273452-4	English/ Spanish 0271189-7
35	--	--	--	--	--	--	--	--	--
36	--	--	--	--	--	--	--	--	--
37	--	--	--	--	--	--	--	--	--
38	--	--	--	--	--	--	--	--	--
39	--	--	--	--	1705514	--	--	--	--
40	--	--	--	--	--	--	--	--	--
41	--	--	--	--	--	--	--	--	--
42	--	--	--	--	--	--	--	--	--
43	--	--	--	--	--	--	--	--	--
44	3252768	3252768	3252768	3252768	3252768	3252768	3252768	3252768	3252768
45	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885
46	--	--	--	--	--	--	--	--	--
47	--	--	--	--	--	--	--	--	--
48	--	--	--	--	--	--	--	--	--
49	--	--	--	--	--	--	--	--	--
50	1705351	--	1705426	1705427	1705429	1705430	1705905	--	1705910
	--	100112551	--	--	--	--	--	--	--

JLG

-JLG Lift -

4-23

## SECTION 4 - MACHINE OPERATION

**Table 4-3. Decal Legend - S/N 0300141424 to Present**

Item #	ANSI 0272573-12	Australian 0272574-7	Japan 0272575-10	Korean 0272576-10	French/ English 0272577-12	Chinese 0272578-10	Portuguese/ Spanish 0272579-B	CE 0273452-4	English/ Spanish 0271189-7
1	1703797	1703992	1703926	1703927	1703924	1703925	1703928	1705821	1703923
2	1703798	1705332	1703932	1703933	1703930	1703931	1703934	1705822	1703929
3	1703805	--	1703938	1703939	1703936	1703937	1703940	--	1703935
4	1703804	1701518	1703950	1703951	1703948	1703949	1703952	1701518	1703947
5	1001108493	--	--	--	1001108493	--	--	--	1001108493
6	1706941	--	--	--	1706941	--	--	--	1706941
7	--	--	--	--	--	--	--	--	--
8	--	--	--	--	--	--	--	--	--
9	--	--	--	--	--	--	--	--	--
10	--	--	--	--	--	--	--	--	--
11	1702868	--	--	--	1704000	--	1704002	--	1704001
12	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277	1704277
13	1001121801	--	1001121808	1001121918	1001121803	1001121810	1001121920	--	1001121805
14	1001121814	--	1001121821	1001121921	1001121816	1001121823	1001121923	--	1001121818
15	--	--	--	--	--	--	--	1705084	--
16	--	--	--	--	--	--	--	--	--

3121179

- JLG Lift -

4-25

## SECTION 4 - MACHINE OPERATION

**Table 4-3. Decal Legend - S/N 0300141424 to Present**

Item #	ANSI 0272573-12	Australian 0272574-7	Japan 0272575-10	Korean 0272576-10	French/ English 0272577-12	Chinese 0272578-10	Portuguese/ Spanish 0272579-B	CE 0273452-4	English/ Spanish 0271189-7
17	--	--	--	--	--	--	--	--	--
18	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504	1701504
19	--	--	--	--	1704006	--	--	--	1704007
20	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631	1702631
21	1700584	1700584	1700584	1700584	1700584	1700584	1700584	1700584	1700584
22	--	1702958	--	--	--	--	--	--	--
23	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509	1701509
24	1702300	1702300	1702300	1702300	1702300	1702300	1702300	1702300	1702300
25	1701500	1701500	1701500	1701500	1701500	1701500	1701500	1701500	1701500
26	1701529	1701529	1701529	1701529	1701529	1701529	1701529	1701529	1701529
27	--	--	--	--	--	--	--	--	--
28	--	--	--	--	--	--	--	--	--
29	--	--	--	--	--	--	--	--	--
30	--	--	--	--	--	--	--	--	--
31	--	--	--	--	--	--	--	--	--
32	--	--	--	--	--	--	--	--	--
33	--	--	--	--	--	--	--	--	--
34	170522278	17052247	1703980	1703981	1703984	1703982	1703985	1705823	1703983

## **SECTION 4 - MACHINE OPERATION**

**Table 4-3. Decal Legend - S/N 0300141424 to Present**

Item #	ANSI 0272573-12	Australian 0272574-7	Japan 0272575-10	Korean 0272576-10	French/ English 0272577-12	Chinese 0272578-10	Portuguese/ Spanish 0272579-8	CE 0273452-4	English/ Spanish 0271189-7
35	--	--	--	--	--	--	--	--	--
36	--	--	--	--	--	--	--	--	--
37	--	--	--	--	--	--	--	--	--
38	--	--	--	--	--	--	--	--	--
39	--	--	--	--	1705514	--	--	--	--
40	--	--	--	--	--	--	--	--	--
41	--	--	--	--	--	--	--	--	--
42	--	--	--	--	--	--	--	--	--
43	--	--	--	--	--	--	--	--	--
44	3252768	3252768	3252768	3252768	3252768	3252768	3252768	3252768	3252768
45	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885	1704885
46	--	--	--	--	--	--	--	--	--
47	--	--	--	--	--	--	--	--	--
48	--	--	--	--	--	--	--	--	--
49	--	--	--	--	--	--	--	--	--
50	1705351	--	1705426	1705427	1705429	1705430	1705905	--	1705910
51	--	1001112551	--	--	--	--	--	--	--

3121179

- JLG Lift -

**4-27**

## **SECTION 4 - MACHINE OPERATION**

---

## **SECTION 5 - EMERGENCY PROCEDURES**

---

### **SECTION 5. EMERGENCY PROCEDURES**

#### **5.1 GENERAL**

This section explains the steps to be taken in case of an emergency situation while operating.

Failure to notify the manufacturer of an incident involving a JLG Industries product within 48 hours of such an occurrence may void any warranty consideration on that particular machine.

#### **5.2 INCIDENT NOTIFICATION**

JLG Industries, Inc. must be notified immediately of any incident involving a JLG product. Even if no injury or property damage is evident, the factory should be contacted by telephone and provided with all necessary details.

**NOTICE**  
FOLLOWING ANY ACCIDENT, THOROUGHLY INSPECT THE MACHINE AND TEST ALL FUNCTIONS FIRST FROM THE GROUND CONTROLS, THEN FROM THE PLATFORM CONTROLS. DO NOT LIFT ABOVE 10 FT (3 M) UNTIL YOU ARE SURE THAT ALL DAMAGE HAS BEEN REPAIRED, IF REQUIRED, AND THAT ALL CONTROLS ARE OPERATING CORRECTLY.

In USA:

JLG Phone: 877-JLG-SAFE (554-7233)  
(8am till 4:45pm EST)

Outside USA:

240-420-2661

E-mail:

ProductSafety@JLG.com

3121179

- JLG Lift -

5-1

---

### **SECTION 5 - EMERGENCY PROCEDURES**

---

#### **5.3 EMERGENCY OPERATION**

##### **Operator Unable to Control Machine**

IF THE PLATFORM OPERATOR IS PINNED, TRAPPED OR UNABLE TO OPERATE OR CONTROL MACHINE:

1. Other personnel should operate the machine from ground controls only as required.
2. Other qualified personnel on the platform may use the platform controls. DO NOT CONTINUE OPERATION IF CONTROLS DO NOT FUNCTION PROPERLY.
3. Cranes, forklift trucks or other equipment can be used to remove platform occupants and stabilize motion of the machine.

##### **Platform or Boom Caught Overhead**

If the platform or boom becomes jammed or snagged in overhead structures or equipment, rescue platform occupants prior to freeing the machine.

#### **5.4 EMERGENCY TOWING PROCEDURES**

Towing this machine is prohibited, unless properly equipped. However, provisions for moving the machine have been incorporated. For specific procedures, refer to Section 4.

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### SECTION 6. GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

#### 6.1 INTRODUCTION

This section of the manual provides additional necessary information to the operator for proper operation and maintenance of this machine.

The maintenance portion of this section is intended as information to assist the machine operator to perform daily maintenance tasks only, and does not replace the more thorough Preventive Maintenance and Inspection Schedule included in the Service and Maintenance Manual.

#### Other Publications Available:

450A/450AJ Service and Maintenance Manual.....	3121180
510AJ Service and Maintenance Manual.....	3121181
450A/450AJ Illustrated Parts Manual (Prior to S/N 0300124000-USA, S/N 1300006000-Belgium) .....	3121243
450A/450AJ Illustrated Parts Manual (S/N 0300124000-USA, S/N 1300006000-Belgium to Present) .....	3121244
510AJ Illustrated Parts Manual .....	3121182

#### 6.2 OPERATING SPECIFICATIONS AND PERFORMANCE DATA

Table 6-1. Operating Specifications - 450A/450AJ - Prior to S/N 0300141424

Unrestricted Rated Capacity	500 lb (230 kg)
Maximum Capacity	500 lb (230 kg)
Maximum Travel Grade (Gradeability) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped). 2WD	30%
4WD	45%
Maximum Travel Grade (Sideslope) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped) - ANSI Markets.	5°
Maximum Travel Grade (Sideslope) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped) - CE & Australia Markets.	4°

3121179

- JLG Lift -

6-1

### SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

Table 6-1. Operating Specifications - 450A/450AJ - Prior to S/N 0300141424

Maximum Drive Speed:	4.5 mph (2.0 m/s)
Maximum Hyd. Operating Pressure	4500 psi (310 bar)
Electrical System Voltage	12 volts
Gross Machine Weight (450A)	14,500 lb (6577 kg)
(450AJ)	16,500 lb (7484 kg)

Table 6-2. Operating Specifications - 450A/450AJ - S/N 0300141424 to Present

Maximum Travel Grade (Sideslope) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped) - ANSI Markets.	5°
Maximum Travel Grade (Sideslope) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped) - CE & Australia Markets.	4°
Maximum Drive Speed:	4.5 mph (2.0 m/s)
Maximum Hyd. Operating Pressure	4500 psi (310 bar)
Electrical System Voltage	12 volts
Gross Machine Weight (450A)	14,500 lb (6577 kg)
(450AJ)	16,500 lb (7484 kg)

Table 6-2. Operating Specifications - 450A/450AJ - S/N 0300141424 to Present

Unrestricted Rated Capacity ANSI CE & Australia	500 lb (227 kg) 500 lb (230 kg)
Maximum Capacity ANSI CE & Australia	500 lb (227 kg) 500 lb (230 kg)
Maximum Travel Grade (Gradeability) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped). 2WD	30%
4WD	45%

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-3. Operating Specifications - 510AJ**

Unrestricted Rated Capacity	500lb (230kg)
Maximum Capacity	500lb (230kg)
Maximum Travel Grade (Gradeability) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped).	45%
Maximum Travel Grade (Sideslope) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped) - ANSI Markets.	5°
Maximum Travel Grade (Sideslope) with Boom retracted and approximately horizontal. Tower Boom fully lowered (if equipped) - CE & Australia Markets.	4°
Maximum Drive Speed:	4.5 mph (2.0 m/s)
Maximum Hyd. Operating Pressure	4500 psf (310 bar)
Electrical System Voltage	12 volts
Gross Machine Weight	16,104lb (7305 kg)

### Reach Specifications

**Table 6-4. Reach Specifications - 450**

Max. Platform Height	45ft (13.72m)
Max. Horizontal Reach	24.5ft (7.47m)
Up & Over Height	25 ft 2 in (7.7m)
Main Boom Up Angle	75°
Main Boom Down Angle	-24°

**Table 6-5. Reach Specifications - 510**

Max. Platform Height	51.8ft (15.81m)
Platform Rotation	180°
Max. Horizontal Reach	31.1ft (9.48m)
Up & Over Height	24.08ft (7.34m)
Jib Length	4.5ft (1.37m)
Jib Angle	135° (+70°, -65°)

3121179

- JLG Lift -

6-3

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### Dimensional Data

**Table 6-6. Dimensional Data - 450**

Overall Width (12x 16.5 tire) (33/1550 tire) (14x 16.1 tire)	6ft 6in (1.98m)
Tailswing	0
Stowed Height	7ft 4.4in (2.25m)
Stowed Length	21ft 4in (6.5m)
Wheel base	78in (1.98m)
Track Width (12x 16.5 tire) (33/1550 tire) (14x 16.1 tire)	65.3in (1.66m) 66.3in (1.69m) 66.6in (1.69m)
Ground Clearance	14in (0.36m)

**Table 6-7. Dimensional Data - 510**

Overall Width	7.4ft (2.26m)
Tailswing	0
Stowed Height	7.1ft (2.26m)
Stowed Length	25.1ft 7.58in
Wheel base	37ft 12.34in

**Table 6-7. Dimensional Data - 510**

Track Width (12x 16.5 tire) (33/1550 tire) (14x 16.1 tire)	65.3in (1.66m) 66.3in (1.69m) 66.6in (1.69m)
Ground Clearance	1.18ft (0.36m)

### Chassis

**Table 6-8. Chassis Specifications - 450**

Swing	360° non-continuous
Rated Gradeability	
2WD	30%
4WD	45%
Max. Tire Load	7900 lb (3583 kg)
Axle Oscillation	8in (0.2m)
System Voltage	12 Volts
Max. Hydraulic System Operating Pressure	4500 psi (310 bar)
Gross Machine Weight	
450ASII	14,500lb (6577 kg)
450AISII	16,500lb (7484 kg)

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-9. Chassis Specifications - 510**

Swing	357° non-continuous
Gradeability (boom in stowed position)	40%
Max. Tire Load	7900 lb (3583 kg)
Max. Ground Bearing Pressure	
12x16.5 Tire	48 psi (3.37 kg/cm <sup>2</sup> )
33/1550x16.5-Tire	36 psi (2.53 kg/cm <sup>2</sup> )
Drive Speed	4.5 mph (7.2 kph)
Axle Oscillation	4 in (0.1 m)
Turning Radius	
Inside	6.5 ft (2.0 m)
Outside	16.4 ft (5.0 m)
System Voltage	12 Volts
Max. Hydraulic System Operating Pressure	4500 psi (310 bar)
Gross Machine Weight	16,104 lb (7305 kg)

### Capacities

**Table 6-10. Capacities**

Fuel Tank	17 gal (64.3 L)
Hydraulic Tank (machines to S/N 0300070586)	28 gal (106 L)
Hydraulic Tank (S/N 0300070586 & SN 1300000001 to Present)	27 gal (102 L) 23.6 gal (89 L) to Full line on sight gauge
Drive Hub	23.75 oz (0.7 L)
Drive Brake	2.7 oz (0.08 L)

### Tires

**Table 6-11. Tires**

Size	Type	Pressure	Weight
12x16.5	Pneumatic	90 psi (6 bar)	128 lb (58 kg)
12x16.5	Foam-Filled	N/A	328 lb (149 kg)
33/1550x16.5	Pneumatic	90 psi (6 bar)	135 lb (61 kg)
33/1550x16.5	Foam-Filled	N/A	395 lb (179 kg)
14x16.1	Pneumatic	40 lbs. (3 bar)	91.5 lb (41.5 kg)
14x16.1	Foam-Filled	N/A	426 lb (193 kg)
33x6x11	Solid	N/A	280 lb (127 kg)

3121179

- JLG Lift -

6-5

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### Engine

**NOTE:** RPM Tolerances are  $\pm 100$ .

**Table 6-12. Caterpillar 3024/C2.2**

Fuel	Diesel
No. of Cylinders	4
BHP	46.5 hp (34 kW)
Bore	3.307 in (84 mm)
Stroke	3.9370 in (112 mm)
Displacement	134.3 cu. in (2.2L)
Oil Capacity	3.8 qt (3.6 L) crankcase only
Compression Ratio	19:1
Firing Order	1-3-4-2
Max. RPM	2800

**Table 6-13. Deutz D2.9L4 Specifications**

Type	Liquid Cooled
Number of Cylinders	4
Bore	3.6 in (92 mm)
Stroke	4.3 in (110 mm)
Total Displacement	178 cu. in (2925 cm <sup>3</sup> )
Firing Order	1-3-4-2
Output	74.2 hp (55.4 kW)
Oil Capacity	2.4 gal (8.9 L)
Coolant Capacity (System)	3.2 gal (12.1 L)
Average Fuel Consumption	1.2 gph (4.1 Lph)
Min. Low Engine RPM	1200
Mid Engine RPM	1800
Max. High Engine RPM	2500

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-14. Deutz F3M1011F**

Fuel	Diesel
No. of Cylinders	3
Bore	3.6 in (91 mm)
Stroke	4.4 in (112 mm)
Displacement	133 cu. in (2184 cm <sup>3</sup> )
BHP at Max. RPM	48
Oil Capacity	
crankcase	6.3 qt (6 L)
cooler	4.75 qt (4.5 L)
total capacity	11 qt (10.5 L)
Low RPM	1200
Mid RPM	
Tower Lift, Upper Lift, Tele	
Swing, Basket Level, Basket Rotate, Jib Lift	1800
	1500
High RPM	2800

**Table 6-15. Deutz F3M2011F/D2011L03**

Fuel	Diesel
No. of Cylinders	3
Bore	3.7 in (94 mm)
Stroke	4.4 in (112 mm)
Displacement	142 cu. in (2331 cm <sup>3</sup> )
Oil Capacity	
crankcase	6.3 qt (6 L)
cooler	4.75 qt (4.5 L)
total capacity	11 qt (10.5 L)
Low RPM	1200
Mid RPM	
Tower Lift, Upper Lift, Tele	
Swing, Basket Level, Basket	1800
Rotate, Jib Lift	1500
High RPM	2800

3121179

- JLG Lift -

6-7

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-16. Ford LRG-425 (Gas or Dual Fuel)**

Type	4 cylinder, 4 stroke, spark ignition
Fuel	Gasoline or Gasoline/LP Gas
Bore	3 in (96 mm)
Stroke	3.4 in (86.4 mm)
Displacement	153 cu. in (2.5 L)
Firing Order	1-3-4-2
BHP at Max. RPM	82
Oil Capacity	4.5 qt (4.26 L)
Low RPM	1000
Mid RPM	
Tower Lift, Upper Lift, Tele	
Swing, Basket Level, Basket Rotate, Jib Lift	1800
	1500
High RPM	3000
Spark Plug	AWSF-52-C
Spark Plug Gap	0.044 in (1.117 mm)

**Table 6-17. GM 3.0L**

Fuel	Gasoline or Gasoline/LP Gas
No. of Cylinders	4
BHP	
Gasoline	83 hp @ 3000 rpm
LP	75 hp @ 3000 rpm
Bore	4.0 in (101.6 mm)
Stroke	3.6 in (91.44 mm)
Displacement	181 cu. in (3.0 L, 2966 cc)
Oil Capacity w/filter	4.5 qts (4.25 L)
Minimum Oil Pressure	
Atidle	6 psi (0.4 bar) @ 1000 rpm
Hot	18 psi (1.2 bar) @ 2000 rpm
Compression Ratio	9.2:1
Firing Order	1-3-4-2
Max. RPM	2800

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-18. Perkins 404D-22**

Fuel	Diesel
No. of Cylinders	4
BHP	50HP (37.3 kW)
Bore	3.3 in (84 mm)
Stroke	3.9 in (100 mm)
Firing Order	1-3-4-2
Displacement	135 cu.in (2.2L)
Oil Capacity w/filter	10 qt (9.4 L)
Compression Ratio	23.3:1

3121179

- JLG Lift -

6-9

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### Major Component Weights

**Table 6-19. Component Weights - 450**

Component	lb	kg
Frame (Bare)	2325	1055
Turntable (Bare)	1500	680
Boom Link	180	82
Boom Timing Link	30	14
Upper Upright	217	98
Lower Upright	115	52
Lower Boom	497	225
Mid Boom	385	175
Upper Boom	1065	484
4 Wheel Drive Axle	200	91
2 Wheel Drive Axle	235	107

### Hydraulic Oil

**Table 6-21. Hydraulic Oil**

Hydraulic System Operating Temperature Range	SAE Viscosity Grade
+0° to +180°F (-18° to +83°C)	10W
+0° to +210°F (-18° to +99°C)	10W-20, 10W30
+50° to +210°F (+10° to +99°C)	20W-20

**NOTE:** Hydraulic oils must have anti-wear qualities at least to API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service. JLG Industries recommends Mobilfluid 424 hydraulic oil, which has an SAE viscosity index of 152.

**NOTE:** When temperatures remain consistently below 20 degrees F. (-7 degrees C.), JLG Industries recommends the use of Mobil DTE13.

**Table 6-20. Component Weights - 510**

Component	lb	kg
Engine Only	440	200
Upper Boom	1257	570
Frame (Bare)	2105	955
Turntable (Bare)	533	295

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

*Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. If use of hydraulic oil other than Mobilfluid 424 is desired, contact JLG Industries for proper recommendations.*

**Table 6-22. Mobilfluid 424 Specs**

SAE Grade	10W30
Gravity, API	29.0
Density, lb/Gal. 60°F	7.35
Pour Point, Max	-46°F (-43°C)
Flash Point, Min.	442°F (228°C)
<b>Viscosity</b>	
Brookfield, cP at -18°C	2700
at 40°C	55 cSt
at 100°C	9.3 cSt
Viscosity Index	152

**Table 6-23. Mobil DTE 13M Specs**

ISO Viscosity Grade	#32
Specific Gravity	0.877
Pour Point, Max	-40°F (-40°C)
Flash Point, Min.	330°F (166°C)
<b>Viscosity</b>	
at 40°C	33 cSt
at 100°C	6.6 cSt
at 100°F	169 SUS
at 210°F	48 SUS
cP at -20°F	6,200
Viscosity Index	140

3121179

- JLG Lift -

**6-11**

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-24. UCon Hydrolube HP-5046**

Type	Synthetic Biodegradable
Specific Gravity	1.082
Pour Point, Max	-58°F (-50°C)
pH	9.1
<b>Viscosity</b>	
at 0°C (32°F)	340 cSt (1600SUS)
at 40°C (104°F)	46 cSt (215SUS)
at 65°C (150°F)	22 cSt (106SUS)
Viscosity Index	170

**Table 6-25. Mobil EAL H 46 Specs**

Type	Synthetic Biodegradable
ISO Viscosity Grade	46
Specific Gravity	.910
Pour Point	-44°F (-42°C)
Flash Point	500°F (260°C)
Operating Temp.	0 to 180°F (-17 to 162°C)
Weight	7.64 lb per gal. (0.9 kg per liter)
<b>Viscosity</b>	
at 40°C	45 cSt
at 100°C	8.0 cSt
Viscosity Index	153

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**Table 6-26. Exxon Univis HVI 26 Specs**

Specific Gravity	32.1
Pour Point	-76°F (-60°C)
Flash Point	217°F (103°C)
Viscosity	
at 40°C	25.0 cSt
at 100°C	9.3 cSt
Viscosity Index	376

**NOTE:** Mobil/Exxon recommends that this oil be checked on a yearly basis for viscosity.

**Table 6-27. Quintolubric 888-46**

Density	0.91 @ 15°C (59°F)
Pour Point	<-20°C (<-4°F)
Flash Point	275°C (527°F)
Fire Point	325°C (617°F)
Autoignition Temperature	450°C (842°F)
Viscosity	
at 0°C (32°F)	360 cSt
at 20°C (68°F)	102 cSt
at 40°C (104°F)	46 cSt
at 100°C (212°F)	10 cSt
Viscosity Index	220

3121179

- JLG Lift -

6-13

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### Serial Number Location

A serial number plate is affixed to the left rear side of the frame. If the serial number plate is damaged or missing, the machine serial number is stamped on the left side of the frame.




Figure 6-1. Serial Number Locations

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-2. Engine Operating Temperature Specifications - Caterpillar - Sheet 1 of 2

3121179

- JLG Lift -

6-15

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-3. Engine Operating Temperature Specifications - Caterpillar - Sheet 2 of 2


5-13

- JLG Lift -

3121179

I15054B-6  
NOTE:  
RECOMMENDATIONS ARE FOR AMBIENT TEMPERATURES CONSISTENTLY WITHIN SHOWN LIMITS.  
All values are assumed to be at sea level.

**SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**



**Figure 6-4. Engine Operating Temperature Specifications - Deutz - Sheet 1 of 2**

3121179

- JLG Lift -

6-17

SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-5. Engine Operating Temperature Specifications - Deutz - Sheet 2 of 2

2-3

Galaxy

379

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-6. Engine Operating Temperature Specifications - Ford - Sheet 1 of 2

3121179

- JLG Lift -

6-19

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-7. Engine Operating Temperature Specifications - Ford - Sheet 2 of 2

1150548E

5-20

JLG Lift

3121179

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-8. Engine Operating Temperature Specifications - GM - Sheet 1 of 2

3121179

- JLG Lift -

6-21

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-9. Engine Operating Temperature Specifications - GM - Sheet 2 of 2

4150548-8

5-22

- JLG Lift -

3121179

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-10. Engine Operating Temperature Specifications - Perkins - Sheet 1 of 2

3121179

-JLG Lift-

6-23

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-11. Engine Operating Temperature Specifications - Perkins - Sheet 2 of 2


5-24

-JLG Lift-

1150548-E

3121179

**SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**



## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE




Figure 6-14. Operator Maintenance and Lubrication Diagram - GM Dual-Fuel

3121179

- JLG Lift -

6-27

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### 6.3 OPERATOR MAINTENANCE

**NOTE:** The following numbers correspond to those in Figures 6-12 through 6-14.

Table 6-28. Lubrication Specifications

KEY	SPECIFICATIONS
MPG	Multipurpose Grease having a minimum dripping point of 350° F (177° C). Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.)
EPL	Extreme Pressure Gear Lube (oil) meeting API service classification GL-5 or MIL-Spec MIL-L-2105
HO	Hydraulic Oil. API service classification GL-3, e.g. Mobilfluid 424.
EO	Engine (crankcase) Oil. Gas - API SF, SH, SG class; MIL-L-2104. Diesel - API CC/CD class; MIL-L-2104B/MIL-L-2104C.
DGL	Open Gear Lubricant - Mobiltaic 375 or equivalent.

#### NOTICE

LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

**NOTE:** It is recommended as a good practice to replace all filters at the same time.

1. Swing Bearing - Internal Ball Bearing

Lube Point(s) - 2 Grease Fittings

Capacity - A/R

Lube - MPG

Interval - Every 3 months or 150 hours of operation

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

2. A. Swing Bearing - Teeth  
(Prior to S/N 0300069337)


Lube Point(s) - Spray On  
Capacity - A/R  
Lube - OGL  
Interval - Every 3 months or 150 hours of operation  
Comments - More frequent lubrication intervals may be required

B. End Bearings - Worm Gear\*  
(Prior to S/N 0300069337)

Lube Point(s) - 2 Grease Fittings  
Capacity - A/R  
Lube - MPG  
Interval - Every 2 years or 1200 hours of operation  
Comments - Remove grease fittings and install plugs after greasing

\*If necessary install grease fittings into worm gear housing and grease bearings.

C. Swing Bearing/Worm Gear Teeth\*  
(S/N 0300069337 to 0300077285 USA and  
S/N 1300000001 to 1300000353 Belgium)



Lube Point(s) - Grease Fitting  
Capacity - A/R  
Lube - Mobil SHC 460  
Interval - A/R

**CAUTION**


DO NOT OVERGREASE END BEARINGS. OVERGREASING BEARINGS WILL RESULT IN BLOWING OUTER SEAL IN HOUSING.

3121179

- JLG Lift -


6-29

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE



Lube Point(s) - Grease Fitting  
Capacity - A/R  
Lube - Mobile SHC 007  
Interval - A/R

Swing Bearing/Worm Gear Teeth  
(S/N 0300077285 to Present USA and  
S/N 1300000353 to Present Belgium)



Lube Point(s) - Grease Fitting  
Capacity - A/R  
Lube - Lubriplate 930-AAA  
Interval - A/R

**CAUTION**

DO NOT OVERGREASE BEARINGS. OVERGREASING BEARINGS WILL RESULT IN DAMAGE TO OUTER SEAL IN HOUSING.

5-30

- JLG Lift -


3121179

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

### 3. Wheel Bearings (2WD Only)



Lube Point(s) - Grease Fitting\*  
Capacity - A/R  
Lube - Mobile SHC 007  
Interval - A/R

#### ⚠ CAUTION

DO NOT OVERGREASE BEARINGS. OVERGREASING BEARINGS WILL RESULT IN DAMAGE TO OUTER SEAL IN HOUSING.

\*If necessary install grease fitting into worm gear housing and grease. Replace fitting with pipe plug when complete.



Lube Point(s) - Repack  
Capacity - A/R  
Lube - MPG  
Interval - Every 2 years or 1200 hours of operation

### 4. Wheel Drive Hub

Lube Point(s) - Level/Fill Plug  
Capacity - 17 oz (0.5 L) - 1/2 Full  
Lube - EPG1  
Interval - Check level every 3 months or 150 hours of operation; change every 2 years or 1200 hours of operation

3121179

-JLG Lift-

6-31

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE


---

### 5. Hydraulic Return Filter



Interval - Change after first 50 hours and every 6 months or 300 hours thereafter or as indicated by Condition Indicator.

### 6. Hydraulic Charge Filter




Interval - Change after first 50 hours and every 6 months or 300 hours thereafter or as indicated by Condition Indicator.

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE


---

7. Hydraulic Tank



Lube Point(s) - Fill Cap  
Capacity - 27 gal (102 L); 23.6 gal (89 L) to  
the Full line on the sight gauge  
Lube - HO  
Interval - Check Level daily; Change every 2 years or  
1200 hours of operation.

8. Suction Strainers



Lube Point(s) - 2  
Interval - Every 2 years or 1200 hours of operation,  
remove and clean at time of hydraulic oil change.

3121179

- JLG Lift -

6-33

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

9. Oil Change w/Filter - Caterpillar


Lube Point(s) - Fill Cap/Spin-on Element (JLG P/N  
7026855)  
Capacity - 10 qt (9.4 L)  
Lube - EO  
Interval - Every Year or 500 hours of operation  
Comments - Check level daily/Change in accordance  
with engine manual.

10. Oil Change w/Filter - Deutz D2011



Fill Cap/Spin-on Element (JLG P/N  
7016641)  
Capacity - 11 qt (10.5 L) Crankcase; 5 qt (4.7 L)  
Cooler  
Lube - EO  
Interval - Every Year or 1200 hours of operation  
Comments - Check level daily/Change in accordance  
with engine manual.

**SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**



**Figure 6-15. Deutz D2011 Engine Dipsticks**


3121179

-JLG Lift-

**6-35**


**SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

**11. Oil Change w/Filter - Deutz 2.9 L4**



Lube Point(s) - Fill Cap/Spin-on Element  
Capacity - 2.4 gal (8.9 L)  
Lube - EO  
Interval - Every Year or 600 hours of operation  
Comments - Check level daily/Change in accordance with engine manual

**12. Oil Change w/Filter - Ford**



Lube Point(s) - Fill Cap/Spin-on Element (JLG P/N 7014501)  
Capacity - 4.5 qt (4.25 L)  
Lube - EO  
Interval - 3 Months or 150 hours of operation  
Comments - Check level daily/Change in accordance with engine manual.

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

13. Oil Change w/Filter - GM



Lube Point(s) - Fill Cap/Spin-on Element  
(JLG P/N 7027965)  
Capacity - 4.5 qt (4.25 L) w/filter  
Lube - EO  
Interval - 3 Months or 150 hours of operation  
Comments - Check level daily/Change in accordance with engine manual.

14. Oil Change w/Filter - Perkins



Lube Point(s) - Fill Cap/Spin-on Element (JLG P/N 7026855)  
Capacity - 10 qt (9.4 L)  
Lube - EO  
Interval - Every Year or 500 hours of operation  
Comments - Check level daily/Change in accordance with engine manual.

3121179

-JLG Lift -

6-37

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

15. Fuel Filter - Caterpillar

Lube Point(s) - Replaceable Element  
Interval - Every Year or 600 hours of operation

16. Fuel Pre-Filter - Deutz D2.9



Lube Point(s) - Replaceable Element  
Interval - Drain water daily; Every year or 600 hours of operation

17. Fuel Filter - Deutz D2.9




Lube Point(s) - Replaceable Element  
Interval - Every year or 600 hours of operation

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

18. Fuel Strainer - Deutz D2011



Lube Point(s) - Replaceable Element  
Interval - Every Year or 600 hours of operation

19. Fuel Filter - Deutz D2011



Lube Point(s) - Replaceable Element  
Interval - Every Year or 600 hours of operation

3121179

-JLG Lift-


6-39

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE


---

20. Fuel Filter - Ford



Lube Point(s) - Replaceable Element  
Interval - Every Year or 1200 hours of operation

21. Fuel Filter - GM




Lube Point(s) - Replaceable Element  
Interval - Every 6 months or 300 hours of operation

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

22. Fuel Filter - Perkins



Lube Point(s) - Replaceable Element  
Interval - Every Year or 600 hours of operation

23. Radiator Coolant Deutz 2.9



Lube Point(s) - Fill Cap  
Capacity - 3.2 Gallon (12.1 L)  
Lube - Anti-Freeze  
Interval - Check level daily; change every 1000 hours or 2 years,  
whichever comes first

3121179

- JLG Lift -



6-41

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

24. Air Filter




Lube Point(s) - Replaceable Element  
Interval - Every 6 months or 300 hours of operation or as indicated by the condition indicator (24B)

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

25. Electronic Pressure Regulator (LP only)



Interval - 3 Months or 150 hours of operation  
Comments - Drain oil build up. Refer to Section 6.5, DRAINING OIL BUILD UP FROM THE PROPANE REGULATOR (Prior to S/N 0300137808)

26. Fuel Filter (Propane) - GM Engine



Interval - 3 Months or 150 hours of operation  
Comments - Replace filter. Refer to Section 6.6, Propane Fuel Filter Replacement

3121179

- JLG Lift -

6-43

---

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

---

### 6.4 TIRES & WHEELS

#### Tire Inflation

The air pressure for pneumatic tires must be equal to the air pressure that is stenciled on the side of the JLG product or rim decal for safe and proper operational characteristics.

#### Tire Damage

For pneumatic tires, JLG Industries, Inc. recommends that when any cut, rip, or tear is discovered that exposes sidewall or tread area cords in the tire, measures must be taken to remove the JLG product from service immediately. Arrangements must be made for replacement of the tire or tire assembly.

For polyurethane foam filled tires, JLG Industries, Inc. recommends that when any of the following are discovered, measures must be taken to remove the JLG product from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- a smooth, even cut through the cord plies which exceeds 3 inches (7.5 cm) in total length
- any tears or rips (ragged edges) in the cord plies which exceeds 1 inch (2.5 cm) in any direction
- any punctures which exceed 1 inch in diameter
- any damage to the bead area cords of the tire

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to insure the damage has not propagated beyond the allowable criteria.

#### Tire Replacement

JLG recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Please refer to the JLG Parts Manual for the part number of the approved tires for a particular machine model. If not using a JLG approved replacement tire, we recommend that replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original
- Tire tread contact width equal or greater than original
- Wheel diameter, width, and offset dimensions equal to the original
- Approved for the application by the tire manufacturer (including inflation pressure and maximum tire load)

Unless specifically approved by JLG Industries Inc. do not replace a foam filled or ballast filled tire assembly with a pneumatic tire. When selecting and installing a replacement tire, ensure that all tires are inflated to the pressure recommended by JLG. Due to size variations between tire brands, both tires on the same axle should be the same.

5-6211

- 6-43-176 -

3121179

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### Wheel Replacement

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

### Wheel Installation

It is extremely important to apply and maintain proper wheel mounting torque.

#### WARNING

**WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.**

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels. The proper procedure for attaching wheels is as follows:

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.


3121179

- JLG Lift -

6-45

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

2. Tighten nuts in the following sequence:



3. The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque chart.

Table 6-29. Wheel Torque Chart

TORQUE SEQUENCE		
1st Stage	2nd Stage	3rd Stage
40 ft-lb (55 Nm)	100 ft-lb (130 Nm)	170 ft-lb (255 Nm)

4. Wheel nuts should be torqued after first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

### 6.5 DRAINING OIL BUILD UP FROM THE PROPANE REGULATOR (PRIOR TO S/N 0300137808)


During the course of normal operation oils may build inside the primary and secondary chambers of the propane pressure regulator. These oils may be a result of poor fuel quality, contamination of the fuel supply chain, or regional variation in the make up of the fuel. If the build up of the oil is significant this can effect the operation of the fuel control system. Refer to Section 6.3, Operator Maintenance for maintenance intervals. More frequent draining may be required if the fuel supply has been contaminated.

#### **NOTICE**


FOR BEST RESULTS WARM THE ENGINE TO OPERATING TEMPERATURE BEFORE DRAINING.  
THIS WILL ALLOW THE OILS TO FLOW FREELY FROM THE REGULATOR.

1. Move the equipment to a well ventilated area. Ensure there are no external ignition sources.
2. Start the engine and bring to operating temperature.
3. With the engine running, close the manual tank valve and run the engine out of fuel.

4. Push in the Emergency Switch once the engine stops.
5. Disconnect the electrical connection to the LPG fuel temperature sensor in the auxiliary fuel port of the EPR.



6. Remove the retainer clip for the LPG fuel temperature sensor and remove the sensor from the regulator body.



**NOTE:** Have a small container ready to collect oil that will drain freely from the regulator at this point.

7. Once all of the oil has been drained, reinstall the LPG fuel temperature sensor and reconnect the electrical connector.
8. Open the fuel tank manual valve.
9. Start the engine and verify all connections are secure.
10. Dispose of any drained oil per local regulations in a safe and proper fashion.

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

### 6.6 PROPANE FUEL FILTER REPLACEMENT

### Installation

#### Removal

1. Relieve the propane fuel system pressure. Refer to Propane Fuel System Pressure Relief.
2. Disconnect the negative battery cable.
3. Slowly loosen the Filter housing and remove it.
4. Pull the filter housing from the Electric lock off assembly.
5. Remove the filter from the housing.
6. Locate Filter magnet and remove it.
7. Remove and discard the housing seal.
8. If equipped, remove and discard the retaining bolt seal.
9. Remove and discard mounting plate to lock off O-ring seal.

#### NOTICE

BE SURE TO REINSTALL THE FILTER MAGNET INTO THE HOUSING BEFORE INSTALLING NEW SEAL


1. Install the mounting plate to lock off O-ring seal.
2. If equipped, install the retaining bolt seal.
3. Install the housing seal.
4. Drop the magnet into the bottom of the filter housing.
5. Install the filter into the housing.
6. If equipped, install the retaining bolt into the filter housing.
7. Install the filter up to the bottom of the electric lock off.
8. Tighten the filter bowl retainer to 106 in lbs (12 Nm).
9. Open manual shut-off valve. Start the vehicle and leak check the propane fuel system at each serviced fitting. Refer to Propane Fuel System Leak Test.

3121179

- JLG Lift -

6-49

## SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE



- |                               |                         |                    |
|-------------------------------|-------------------------|--------------------|
| 1. Electric Lock Off Solenoid | 6. Seal                 | 10. Filter         |
| 2. Mounting Plate             | 7. Electrical Connector | 11. Fuel Inlet     |
| 3. Housing Seal               | 8. Fuel Outlet          | 12. Retaining Bolt |
| 4. Filter Magnet              | 9. O-ring               | 13. Ring           |
| 5. Filter Housing             |                         |                    |

Figure 6-16. Filter Lock Assembly

## **SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE**

## **6.7 PROPANE FUEL SYSTEM PRESSURE RELIEF**

## **6.8 SUPPLEMENTAL INFORMATION**

**CAUTION**

**THE PROPANE FUEL SYSTEM OPERATES AT PRESSURES UP TO 312 PSI (21.5 BAR). TO MINIMIZE THE RISK OF FIRE AND PERSONAL INJURY, RELIEVE THE PROPANE FUEL SYSTEM PRESSURE (WHERE APPLICABLE) BEFORE SERVICING THE PROPANE FUEL SYSTEM COMPONENTS.**

To relieve propane fuel system pressure:

1. Close the manual shut-off valve on the propane fuel tank.
  2. Start and run the vehicle until the engine stalls.
  3. Turn the ignition switch OFF.

**CAUTION**

**RESIDUAL VAPOR PRESSURE WILL BE PRESENT IN THE FUEL SYSTEM. ENSURE THE WORK AREA IS WELL VENTILATED BEFORE DISCONNECTING ANY FUEL LINE.**

The following information is provided in accordance with the requirements of the European Machinery Directive 2006/42/EC and is only applicable to CE machines.

For electric powered machines, the equivalent continuous A-Weighted sound pressure level at the work platform is less than 70dB(A)

For combustion engine powered machines, guaranteed Sound Power Level (LWA) per European Directive 2000/14/EC (Noise Emission In the Environment by Equipment for Use Outdoors) based on test methods in accordance with Annex III, Part B, Method 1 and 0 of the directive, is 104 dB.

The vibration total value to which the hand-arm system is subjected does not exceed  $2,5 \text{ m/s}^2$ . The highest root mean square value of weighted acceleration to which the whole body is subjected does not exceed  $0,5 \text{ m/s}^2$ .

3121179

- UG Lift -

6-51

SECTION 6 - GENERAL SPECIFICATIONS & OPERATOR MAINTENANCE

**NOTES:**

**SECTION 7 - INSPECTION AND REPAIR LOG**

## **SECTION 7. INSPECTION AND REPAIR LOG**

**Machine Serial Number** \_\_\_\_\_

**Table 7-1. Inspection and Repair Log**

3121179

- JLG Lift -

7-1

**SECTION 7 - INSPECTION AND REPAIR LOG**

**Table 7-1. Inspection and Repair Log**

7-2

- 15 -

3129



## TRANSFER OF OWNERSHIP

No. 00000000000000000000000000000000

**To Product Owner:**

If you now own but ARE NOT the original purchaser of the product covered by this manual, we would like to know who you are. For the purpose of receiving safety-related bulletins, it is very important to keep JLG Industries, Inc. updated with the current ownership of all JLG products. JLG maintains owner information for each JLG product and uses this information in cases where owner notification is necessary.

Please use this form to provide JLG with updated information with regard to the current ownership of JLG products. Please return completed form to the JLG Product Safety & Reliability Department via facsimile or mail to address as specified below.

Thank You,

Product Safety & Reliability Department  
JLG Industries, Inc.

13224 Fountainhead Plaza

Hagerstown, MD 21742

USA


Telephone: +1-717-485-6591

Fax: +1-301-745-3713

**NOTE: Leased or rented units should not be included on this form.**

Mfg. Model: _____	Serial Number: _____	Country: _____	Telephone: (_____) _____
Previous Owner: _____	Address: _____	Date of Transfer: _____	Current Owner: _____
Address: _____		Address: _____	Address: _____
Country: _____		Telephone: (_____) _____	Telephone: (_____) _____
Who in your organization should we notify?			
Name: _____			
Title: _____			

## PROPOSITION 65 WARNING



- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.
- Batteries also contain other chemicals known to the State of California to cause cancer.
- Wash hands after handling.



An Oshkosh Corporation Company

### JLG Worldwide Locations

JLG Industries	JLG Ground Support Oude Bunder 1034 Broekwaterstraat 12A 3630 Maasmechelen Belgium	JLG Latino Americana LTDA Rua Antonia Martins Lutz, 580 Distrito Industrial Joao Nerezzi Indaiatuba-SP 13347-404 Brasil	Oshkosh-JLG (Tianjin) Equipment Technology LTD Shanghai Branch No 465 Xiap Nan Road Feng Xian District Shanghai 201204 China
+6 (12) 87186300 +6 (12) 65813058 Email: techservicesau@jlg.com	+32 (0) 89 84 82 26 Email: emeaservice@jlg.com	+55 (19) 3936 7664 (Parts) +55 (19) 3936 9049 (Service) Email: comercialpecas@jlg.com Email: servicos@jlg.com	+86 (21) 800 819 0050
JLG Industries Dubai	JLG France SAS Z.I. Guillaume Mon Amy 30204 Failliet 47400 Tonniens France	JLG Deutschland GmbH Max Planck Str. 21 27721 Ritterhude - Ihlpohl Germany	JLG Equipment Services Ltd. Rm 1107 Landmark North 39 Lung Sum Avenue Sheung Shui N.T. Hong Kong
Jafza View PO Box 262728, LB 19 20th Floor, Office 05 Jebel Ali, Dubai +971 (0) 4 884 1131 +971 (0) 4 884 7663 Email: emeaservice@jlg.com	+33 (0) 553 84 85 86 +33 (0) 553 84 85 74 Email: pieces@jlg.com	+49 (0) 421 69350-0 +49 (0) 421 69350-45 Email: german-parts@jlg.com	+852) 2639 5783 +852) 2639 5797
JLG Industries (Italy) S.R.L. Via Po, 22 20010 Pregnana Milanese (MI) Italy +39 (0) 2 9359 5210 +39 (0) 2 9359 5211 Email: ricambi@jlg.com	JLG EMEA B.V. Populieren 63 2132 JH Hoofddorp The Netherlands +31 (0) 23 565 5665 Email: emeaservice@jlg.com	JLG NZ Access Equipment & Services 20 Fisher Crescent Mt Wellington 1060 Auckland, New Zealand +61 (2) 87186300 +61 (2) 65813058 Email: techservicesaus@jlg.com	JLG Industries Vuhutinskoe shosse 24b, Khimki Moscow Region 141400 Russia Federation +7 (499) 922 06 99 +7 (499) 922 06 99
JLG Iberica SL Torre del Pinar, 2 Pol. Ind. Castellbisbal Sur 08755 Castellbisbal Barcelona Spain +34 (0) 93 77 17 90 +34 (0) 93 77 17 92 Email: ibero@jlg.com	JLG Industries (UK) Ltd. Bentley House Bentley Avenue Middleton, Greater Manchester M23 2GP United Kingdom +44 (0) 161 984 5900 +44 (0) 161 984 1902 Email: uk@jlg.com	JLG Sverige AB Enköpingsvägen 150 176 27 Järfälla Sweden +46 0 3 506 595 10 +46 0 3 506 595 10 Email: nordicsupport@jlg.com	



