Maintenance Procedure: Mechanical Seal Replacement, HX-200

Document No: MP-17 Revision: A Date: 2021-08-09

Purpose

This procedure describes replacement of the mechanical seal on HX-200 pumps using carbon vs silicon carbide seal faces.

Steps

1. Isolate and lock out the pump. 2. Drain the casing. 3. Remove the coupling guard and spacer. 4. Remove the seal gland. 5. Withdraw the old seal. 6. Clean the shaft sleeve. 7. Fit the new seal using the setting clips. 8. Torque gland bolts to 25 Nm. 9. Remove setting clips and reassemble.

Limits

Do not operate the pump above 90 deg C process temperature after seal replacement.