

Petunjuk Konfigurasi APRS di Baofeng UV-5RM Pro (oleh YD0NXX)

Asumsi:

- Hardware: 1.0.4
- Firmware: 2.0.09
- CPS: 1.21

APRS Panel

Fixed Time: 30s
Fixed Beacon: OFF
Fixed Height: m 0
Latitude: 0.00000
NS Latitude: South
Longitude: 0.00000
EW Longitude: East

Tx Freq1[MHz]: 144.39000
Tx Freq2[MHz]: 145.82500
Tx Freq3[MHz]:
Tx Freq4[MHz]:
Tx Freq5[MHz]:
Tx Freq6[MHz]:
Tx Freq7[MHz]:
Tx Freq8[MHz]:

Tx Interval[s]: 30
PTT ID: OFF
MIC-E Type: En Route
Encode Type: Position

PASS ALL: OFF
POSITION: Open
MIC_E: Open
OBJECT: Open
ITEM: Open
MESSAGE: Open
WX REPORT: Open
NMEA REPORT: Open
STATUS REPORT: Open
OTHER: Open

Target: APAT81
Target SSID: 0
Self: YD0NXX
Self SSID: -8
Table: / []
Icon: [Icon]

Precarrier Time[10ms]: 15
Code Delay Time[10ms]: 20
Tx Beep: ON
CTCSS/DCS: OFF
Tx Band: 25K
Tx Power: Low

Tx Text: Horee HT ngoprek nih v2

	Call Sign	SSID
1	WIDE2	-2
2	00	0
3		0
4		0
5		0
6		0
7		0
8		0

	Rx Call Sign	SSID	Receive Filter
1	APAT81	-8	on
2		0	off
3		0	off
4		0	off
5		0	off
6		0	off
7		0	off
8		0	off
9		0	off

TX Freq [MHz]: 144.390

TX Interval(s): 30

Target: APAT81 (this is TOCALL). Target SSID: 0

Self: operator callsgn, Self SSID: -7

Precarrier Time [10ms]: 15 (ini 150 ms, jangan lebih pendek)

Code Delay Time [10ms]: 20 ms