

ALPHABETICAL INDEX

AI
SECTION

0-9

4-WHEEL DRIVE LOCATION INDEX 03-18-1
4x4 INDICATOR SWITCH INSPECTION 03-18-2

A

A/C AMPLIFIER INSPECTION 07-40-9
A/C COMPRESSOR
REMOVAL/INSTALLATION 07-11-6
A/C SWITCH INSPECTION 07-40-10
A/C SWITCH REMOVAL/INSTALLATION 07-40-10
ABBREVIATIONS 00-00-32
ABS CONTROL MODULE (CM)
INSPECTION [REAR ABS] 04-13A-3
ABS CONTROL MODULE (CM)
REMOVAL/INSTALLATION [REAR ABS] 04-13A-3
ABS HU/CM INSPECTION [4W-ABS] 04-13B-5
ABS HU/CM REMOVAL/INSTALLATION
[4W-ABS] 04-13B-3
ABS HU/CM SYSTEM INSPECTION
[4W-ABS] 04-13B-2
ABS HYDRAULIC UNIT (HU)
INSPECTION [REAR ABS] 04-13A-2
ABS HYDRAULIC UNIT (HU)
REMOVAL/INSTALLATION [REAR ABS] 04-13A-2
ABS LOCATION INDEX [4W-ABS] 04-13B-1
ABS LOCATION INDEX [REAR ABS] 04-13A-1
ABS RELAY INSPECTION [REAR ABS] 04-13A-7
ABS RELAY REMOVAL/INSTALLATION
[REAR ABS] 04-13A-6
ABS SPEED SENSOR INSPECTION
[REAR ABS] 04-13A-5
ABS SPEED SENSOR
REMOVAL/INSTALLATION [REAR ABS] 04-13A-5
ABS SYSTEM WIRING DIAGRAM [4W-ABS] 04-02B-1
ACCELERATOR
PEDAL ADJUSTMENT [WL-3] 01-13A-9
ACCELERATOR PEDAL
ADJUSTMENT [WL-C, WE-C] 01-13B-12
ACCELERATOR PEDAL COMPONENT
REMOVAL/INSTALLATION [WL-3] 01-13A-9
ACCELERATOR PEDAL
COMPONENT REMOVAL/
INSTALLATION [WL-C, WE-C] 01-13B-11
ACCELERATOR PEDAL POSITION
(APP) SENSOR INSPECTION [WL-3] 01-40A-20
ACCELERATOR PEDAL POSITION
(APP) SENSOR INSPECTION
[WL-C, WE-C] 01-40B-28
ACCESSORY SOCKET INSPECTION 09-20-10
ACCESSORY SOCKET
REMOVAL/INSTALLATION 09-20-9
ADJUSTER ANCHOR
REMOVAL/INSTALLATION 08-11-5
AFTER REPAIR PROCEDURE [WL-3] 01-02A-9
AFTER REPAIR PROCEDURE [WL-3] 01-14A-5
AFTER REPAIR PROCEDURE
[WL-C, WE-C] 01-02B-10

AFTER REPAIR
PROCEDURE [WL-C, WE-C] 01-14B-4
AIR BAG MODULE AND
PRE-TENSIONER SEAT BELT
DEPLOYMENT PROCEDURES 08-10-9
AIR BAG MODULE AND
PRE-TENSIONER SEAT BELT
DISPOSAL PROCEDURES 08-10-18
AIR BAG SYSTEM WIRING DIAGRAM
(ON-BOARD DIAGNOSTIC) 08-02-1
AIR BAG SYSTEM WIRING DIAGRAM
(SYMPTOM TROUBLESHOOTING) 08-03-1
AIR BAG SYSTEM 08-03-1
AIR BLEEDING 04-11-3
AIR BLEEDING 06-14-3
AIR CLEANER ELEMENT
INSPECTION [WL-3] 01-13A-4
AIR CLEANER ELEMENT
INSPECTION [WL-C, WE-C] 01-13B-5
AIR OUTLET DUCT
DISASSEMBLY/ASSEMBLY 07-11-6
AIR OUTLET DUCT
REMOVAL/INSTALLATION 07-11-5
ANTILOCK BRAKE SYSTEM WIRING
DIAGRAM [REAR ABS] 04-02A-2
A-PILLAR TRIM
REMOVAL/INSTALLATION 09-17-14
AUDIO CD [REFERENCE] 09-03D-27
AUDIO UNIT DISASSEMBLY/ASSEMBLY
[TYPE A] 09-20-4
AUDIO UNIT REMOVAL/INSTALLATION
[TYPE B] 09-20-5
AXLE SHAFT REMOVAL/INSTALLATION 03-12-2

B

BACK LOWER TRIM
REMOVAL/INSTALLATION 09-17-19
BACK UPPER TRIM
REMOVAL/INSTALLATION 09-17-19
BACK-UP LIGHT SWITCH INSPECTION
[R15M-D] 09-18-9
BACK-UP LIGHT SWITCH INSPECTION
[S15M-D, S15MX-D] 09-18-9
BACK-UP LIGHT SWITCH
REMOVAL/INSTALLATION [R15M-D] 09-18-8
BACK-UP LIGHT SWITCH
REMOVAL/INSTALLATION
[S15M-D, S15MX-D] 09-18-8
BASIC POWER WINDOW SYSTEM
INSPECTION 09-03A-4
BATTERY INSPECTION 01-17-2
BATTERY RECHARGING 01-17-4
BATTERY REMOVAL/INSTALLATION 01-17-2
BEFORE REPAIR PROCEDURE [WL-3] 01-14A-4
BEFORE REPAIR
PROCEDURE [WL-C, WE-C] 01-14B-3
BLOWER MOTOR INSPECTION 07-40-2
BLOWER MOTOR
REMOVAL/INSTALLATION 07-40-2

AI

ALPHABETICAL INDEX

BLOWER UNIT DISASSEMBLY/ASSEMBLY07-11-2
BLOWER UNIT REMOVAL/INSTALLATION07-11-2
BODY & ACCESSORIES SST09-60-1
BODY AND ACCESSORIES
TECHNICAL DATE09-50-1
BODY PANEL LOCATION INDEX09-10-1
BONNET ADJUSTMENT09-10-3
BONNET LATCH AND RELEASE
LEVER REMOVAL/INSTALLATION09-14-5
BONNET REMOVAL/INSTALLATION09-10-2
BONNET SWITCH INSPECTION09-14-19
BONNET SWITCH
REMOVAL/INSTALLATION09-14-18
BOOST SENSOR INSPECTION [WL-3]01-40A-19
BOOST SENSOR INSPECTION
[WL-C, WE-C]01-40B-27
B-PILLAR LOWER TRIM
REMOVAL/INSTALLATION09-17-16
B-PILLAR TRIM REMOVAL/INSTALLATION09-17-15
B-PILLAR UPPER TRIM
REMOVAL/INSTALLATION09-17-16
BRAKE FLUID LEVEL SENSOR INSPECTION04-11-7
BRAKE PEDAL INSPECTION04-11-4
BRAKE PEDAL REMOVAL/INSTALLATION04-11-5
BRAKE SWITCH INSPECTION04-11-6
BRAKE SWITCH REMOVAL/INSTALLATION04-11-5
BRAKE TECHNICAL DATA04-50-1
BRAKES SST04-60-1
BUCKLE REMOVAL/INSTALLATION08-11-7

C

CALIPER (FRONT) DISASSEMBLY/ASSEMBLY
[4x2 (EXCEPT Hi-Rider)]04-11-20
CALIPER (FRONT) DISASSEMBLY/ASSEMBLY
[Hi-Rider, 4x4]04-11-21
CAMSHAFT POSITION (CMP) SENSOR
INSPECTION [WL-C, WE-C]01-40B-37
CAMSHAFT POSITION (CMP)
SENSOR REMOVAL/
INSTALLATION [WL-C, WE-C]01-40B-36
CENTER PANEL REMOVAL/INSTALLATION09-17-13
CENTER PANEL UNIT
DISASSEMBLY/ASSEMBLY [TYPE A]09-20-4
CENTER PANEL UNIT
REMOVAL/INSTALLATION [TYPE A]09-20-3
CHARGING SYSTEM LOCATION INDEX01-17-1
CHECK VALVE (TWO-WAY)
INSPECTION [WL-3]01-16A-7
CIGARETTE LIGHTER INSPECTION09-20-9
CIGARETTE LIGHTER
REMOVAL/INSTALLATION09-20-8
CLEARING DTC08-02-2
CLIMATE CONTROL UNIT WIRE
ADJUSTMENT07-40-8
CLIMATE CONTROL UNIT
DISASSEMBLY/ASSEMBLY07-40-8
CLIMATE CONTROL UNIT INSTALLATION07-40-7
CLIMATE CONTROL UNIT REMOVAL07-40-7
CLOCK SPRING ADJUSTMENT08-10-7
CLOCK SPRING INSPECTION08-10-8
CLOCK SPRING REMOVAL/INSTALLATION08-10-7
CLUTCH COVER INSPECTION05-10-16
CLUTCH DISC INSPECTION05-10-17

CLUTCH FLUID AIR
BLEEDING/REPLACEMENT05-10-3
CLUTCH FLUID INSPECTION05-10-3
CLUTCH LOCATION INDEX05-10-2
CLUTCH MASTER CYLINDER
DISASSEMBLY/ASSEMBLY05-10-8
CLUTCH MASTER CYLINDER
REMOVAL/INSTALLATION05-10-6
CLUTCH PEDAL ADJUSTMENT05-10-4
CLUTCH PEDAL POSITION (CPP)
SWITCH INSPECTION [WL-3]01-40A-33
CLUTCH PEDAL POSITION (CPP)
SWITCH INSPECTION [WL-C, WE-C]01-40B-42
CLUTCH PEDAL DISASSEMBLY/ASSEMBLY05-10-6
CLUTCH PEDAL REMOVAL/INSTALLATION05-10-5
CLUTCH RELEASE COLLAR INSPECTION05-10-17
CLUTCH RELEASE CYLINDER
DISASSEMBLY/ASSEMBLY05-10-11
CLUTCH RELEASE CYLINDER
REMOVAL/INSTALLATION05-10-10
CLUTCH UNIT REMOVAL/INSTALLATION05-10-12
CODE WORD INPUT PROCEDURE09-14-31
COIL REMOVAL/INSTALLATION09-14-23
COLUMN COVER REMOVAL/INSTALLATION09-17-8
COMBINATION SWITCH
DISASSEMBLY/ASSEMBLY09-18-10
COMBINATION SWITCH
REMOVAL/INSTALLATION09-18-9
COMMON RAIL
INSPECTION [WL-C, WE-C]01-14B-14
COMPRESSION INSPECTION [WL-3]01-10A-6
COMPRESSION INSPECTION
[WL-C, WE-C]01-10B-6
CONDENSER INSPECTION07-11-8
CONDENSER REMOVAL/INSTALLATION07-11-8
CONFIRMATION STEP 1: RECEPTION
CONDITION SYMPTOM (EXAMPLE)09-03D-10
CONFIRMATION STEP 1:
AUDIO PANEL SWITCH
CONFIRMATION09-03D-3
CONFIRMATION STEP 2: ANTENNA
SYSTEM SYMPTOM (EXAMPLE)09-03D-11
CONFIRMATION STEP 3: ANTENNA
SYSTEM SIMPLE INSPECTION09-03D-11
CONSOLE DISASSEMBLY/ASSEMBLY09-17-13
CONSOLE ILLUMINATION BULB
REMOVAL/INSTALLATION09-18-16
CONSOLE REMOVAL/INSTALLATION09-17-12
CONTROL BOX
DISASSEMBLY/ASSEMBLY03-18-13
CONTROL BOX
REMOVAL/INSTALLATION03-18-12
CONTROL SLEEVE (CS) SENSOR
INSPECTION [WL-3]01-40A-27
CONTROL SYSTEM DIAGRAM [WL-3]01-40A-6
CONTROL SYSTEM
DIAGRAM [WL-C, WE-C]01-40B-8
CONTROL SYSTEM
LOCATION INDEX [WL-3]01-40A-2
CONTROL SYSTEM
LOCATION INDEX [WL-C, WE-C]01-40B-2
CONTROL SYSTEM
WIRING DIAGRAM [WL-3]01-40A-4
CONTROL SYSTEM
WIRING DIAGRAM [WL-C, WE-C]01-40B-4

ALPHABETICAL INDEX

CONVENTIONAL BRAKE SYSTEM		
LOCATION INDEX	04-11-2	
COOLANT RESERVE TANK		
REMOVAL/INSTALLATION [WL-3]	01-12A-6	
COOLANT RESERVE TANK		
REMOVAL/INSTALLATION [WL-C, WE-C]	01-12B-6	
COOLING FAN INSPECTION [WL-3]	01-12A-9	
COOLING FAN INSPECTION [WL-C, WE-C]	01-12B-8	
COOLING FAN		
REMOVAL/INSTALLATION [WL-3]	01-12A-8	
COOLING FAN REMOVAL/		
INSTALLATION [WL-C, WE-C]	01-12B-8	
COOLING SYSTEM		
CAP INSPECTION [WL-3]	01-12A-5	
COOLING SYSTEM CAP		
INSPECTION [WL-C, WE-C]	01-12B-5	
COOLING SYSTEM		
LOCATION INDEX [WL-3]	01-12A-1	
COOLING SYSTEM		
LOCATION INDEX [WL-C, WE-C]	01-12B-1	
COOLING SYSTEM		
SERVICE WARNINGS [WL-3]	01-12A-2	
COOLING SYSTEM SERVICE WARNINGS		
[WL-C, WE-C]	01-12B-2	
COOLING UNIT DISASSEMBLY/ASSEMBLY	07-11-4	
COOLING UNIT REMOVAL/INSTALLATION	07-11-3	
COWL GRILLE REMOVAL/INSTALLATION	09-16-2	
C-PILLAR TRIM REMOVAL/INSTALLATION	09-17-17	
CRANKSHAFT POSITION (CKP)		
SENSOR INSPECTION [WL-3]	01-40A-31	
CRANKSHAFT POSITION (CKP)		
SENSOR INSPECTION [WL-C, WE-C]	01-40B-39	
CRANKSHAFT POSITION (CKP)		
SENSOR REMOVAL/		
INSTALLATION [WL-3]	01-40A-31	
CRANKSHAFT POSITION (CKP)		
SENSOR REMOVAL/INSTALLATION		
[WL-C, WE-C]	01-40B-38	
CYLINDER HEAD GASKET		
REPLACEMENT [WL-3]	01-10A-8	
CYLINDER HEAD GASKET		
REPLACEMENT [WL-C, WE-C]	01-10B-9	
D		
DASHBOARD DISASSEMBLY/ASSEMBLY	09-17-6	
DASHBOARD MEMBER		
REMOVAL/INSTALLATION	09-17-7	
DASHBOARD REMOVAL/INSTALLATION	09-17-4	
DIAGNOSTIC ASSIST FUNCTION	09-02B-4	
DISC PAD (FRONT) REPLACEMENT		
[4x2 (EXCEPT Hi-Rider)]	04-11-19	
DISC PAD (FRONT) REPLACEMENT		
[Hi-Rider, 4x4]	04-11-20	
DOOR ADJUSTMENT	09-11-2	
DOOR LOCATION INDEX	09-11-1	
DOOR LOCK CONTROL MODULE		
INSPECTION	09-14-11	
DOOR LOCK CONTROL MODULE		
REMOVAL/INSTALLATION	09-14-11	
DOOR LOCK STRIKER		
REMOVAL/INSTALLATION	09-14-10	
DOOR SASH FILM INSTALLATION	09-16-6	
DOOR SASH FILM REMOVAL	09-16-6	
DOOR SWITCH INSPECTION	09-18-15	
DOOR SWITCH REMOVAL/INSTALLATION	09-18-15	
DRIVE BELT ADJUSTMENT [WL-3]	01-10A-4	
DRIVE BELT ADJUSTMENT [WL-C, WE-C]	01-10B-4	
DRIVE BELT INSPECTION [WL-3]	01-10A-3	
DRIVE BELT INSPECTION [WL-C, WE-C]	01-10B-3	
DRIVE SHAFT LOCATION INDEX	03-13-1	
DRIVELINE/AXLE SST	03-60-1	
DRIVELINE/AXLE TECHNICAL DATA	03-50-1	
DRIVER-SIDE AIR BAG MODULE		
REMOVAL/INSTALLATION	08-10-4	
DTC 01	09-02A-2	
DTC 02	09-02A-3	
DTC 03	09-02A-3	
DTC 10 [REAR ABS]	04-02A-9	
DTC 11 [REAR ABS]	04-02A-10	
DTC 11	09-02A-4	
DTC 12 [REAR ABS]	04-02A-10	
DTC 13 [REAR ABS]	04-02A-11	
DTC 2 [REAR ABS]	04-02A-4	
DTC 21	09-02A-4	
DTC 24	09-02A-5	
DTC 3 [REAR ABS]	04-02A-4	
DTC 30	09-02A-5	
DTC 4 [REAR ABS]	04-02A-5	
DTC 5 [REAR ABS]	04-02A-6	
DTC 6 [REAR ABS]	04-02A-7	
DTC 7 [REAR ABS]	04-02A-8	
DTC 8 [REAR ABS]	04-02A-8	
DTC 9 [REAR ABS]	04-02A-9	
DTC B1231	08-02-8	
DTC B1317, B1318 [4W-ABS]	04-02B-7	
DTC B1317, B1318	08-02-8	
DTC B1342 [4W-ABS]	04-02B-8	
DTC B1342	08-02-9	
DTC B1484 [4W-ABS]	04-02B-8	
DTC B1869, B1870	08-02-10	
DTC B1877, B1878, B1879, B1885	08-02-12	
DTC B1881, B1882, B1883, B1886	08-02-14	
DTC B1913, B1916, B1932, B1934	08-02-16	
DTC B1913, B1925, B1933, B1935	08-02-18	
DTC B1992, B1993, B1994, B1995	08-02-20	
DTC B1996, B1997, B1998, B1999	08-02-22	
DTC B2444, U2017	08-02-24	
DTC B2445, U2018	08-02-25	
DTC B2867	08-02-27	
DTC C1095, C1096 [4W-ABS]	04-02B-9	
DTC C1145, C1155, C1165, C1175		
[4W-ABS]	04-02B-11	
DTC C1186 [4W-ABS]	04-02B-12	
DTC C1194, C1198, C1202, C1206,		
C1210, C1214 [4W-ABS]	04-02B-13	
DTC C1222 [4W-ABS]	04-02B-14	
DTC C1233, C1234, C1235, C1236		
[4W-ABS]	04-02B-16	
DTC C1414 [4W-ABS]	04-02B-17	
DTC C1730, C1949, C1950 [4W-ABS]	04-02B-18	
DTC DISPLAY	08-02-2	
DTC P0016 [WL-C, WE-C]	01-02B-15	
DTC P0045 [WL-C, WE-C]	01-02B-16	
DTC P0046 [WL-C, WE-C]	01-02B-18	
DTC P0047 [WL-C, WE-C]	01-02B-19	
DTC P0048 [WL-C, WE-C]	01-02B-21	
DTC P0088 [WL-C, WE-C]	01-02B-23	
DTC P0093 [WL-C, WE-C]	01-02B-24	

ALPHABETICAL INDEX

DTC P0097 [WL-C, WE-C]	01-02B-25	DTC P0663 [WL-C, WE-C]	01-02B-128
DTC P0098 [WL-C, WE-C]	01-02B-27	DTC P0664 [WL-C, WE-C]	01-02B-130
DTC P0100 [WL-3]	01-02A-13	DTC P0665 [WL-C, WE-C]	01-02B-132
DTC P0102 [WL-C, WE-C]	01-02B-29	DTC P0685 [WL-C, WE-C]	01-02B-134
DTC P0103 [WL-C, WE-C]	01-02B-31	DTC P0698 [WL-C, WE-C]	01-02B-136
DTC P0105 [WL-3]	01-02A-15	DTC P0699 [WL-C, WE-C]	01-02B-138
DTC P0106 [WL-C, WE-C]	01-02B-33	DTC P1110 [WL-3]	01-02A-38
DTC P0107 [WL-C, WE-C]	01-02B-35	DTC P1182 [WL-3]	01-02A-40
DTC P0108 [WL-C, WE-C]	01-02B-38	DTC P1189 [WL-3]	01-02A-42
DTC P0110 [WL-3]	01-02A-18	DTC P1195 [WL-3]	01-02A-44
DTC P0112 [WL-C, WE-C]	01-02B-41	DTC P1196 [WL-C, WE-C]	01-02B-141
DTC P0113 [WL-C, WE-C]	01-02B-42	DTC P1226 [WL-3]	01-02A-44
DTC P0115 [WL-3]	01-02A-20	DTC P1259 [WL-C, WE-C]	01-02B-142
DTC P0117 [WL-C, WE-C]	01-02B-44	DTC P1260 [WL-C, WE-C]	01-02B-144
DTC P0118 [WL-C, WE-C]	01-02B-46	DTC P1312 [WL-3]	01-02A-46
DTC P0120 [WL-3]	01-02A-22	DTC P1318 [WL-3]	01-02A-49
DTC P0122 [WL-C, WE-C]	01-02B-48	DTC P1391 [WL-C, WE-C]	01-02B-144
DTC P0123 [WL-C, WE-C]	01-02B-50	DTC P1392 [WL-C, WE-C]	01-02B-147
DTC P0180 [WL-3]	01-02A-26	DTC P1402 [WL-3]	01-02A-51
DTC P0182 [WL-C, WE-C]	01-02B-52	DTC P1602 [WL-C, WE-C]	01-02B-149
DTC P0183 [WL-C, WE-C]	01-02B-54	DTC P1603 [WL-C, WE-C]	01-02B-149
DTC P0191 [WL-C, WE-C]	01-02B-56	DTC P1604 [WL-C, WE-C]	01-02B-150
DTC P0192 [WL-C, WE-C]	01-02B-57	DTC P1621, P1622, P1623, P1624 [WL-C, WE-C]	01-02B-150
DTC P0193 [WL-C, WE-C]	01-02B-59	DTC P1649 [WL-3]	01-02A-54
DTC P0201 [WL-C, WE-C]	01-02B-61	DTC P1675 [WL-C, WE-C]	01-02B-151
DTC P0202 [WL-C, WE-C]	01-02B-62	DTC P1676 [WL-C, WE-C]	01-02B-152
DTC P0203 [WL-C, WE-C]	01-02B-64	DTC P1812	03-02-2
DTC P0204 [WL-C, WE-C]	01-02B-66	DTC P1813	03-02-4
DTC P0222 [WL-C, WE-C]	01-02B-68	DTC P1814	03-02-6
DTC P0223 [WL-C, WE-C]	01-02B-71	DTC P1815	03-02-8
DTC P0227 [WL-C, WE-C]	01-02B-74	DTC P1878	03-02-10
DTC P0228 [WL-C, WE-C]	01-02B-76	DTC P1879	03-02-11
DTC P0251 [WL-3]	01-02A-28	DTC P1880	03-02-12
DTC P0300 [WL-C, WE-C]	01-02B-78	DTC P1885	03-02-14
DTC P0301, P0302, P0303, P0304 [WL-C, WE-C]	01-02B-80	DTC P2135 [WL-C, WE-C]	01-02B-152
DTC P0335 [WL-3]	01-02A-31	DTC P2136 [WL-C, WE-C]	01-02B-153
DTC P0335 [WL-C, WE-C]	01-02B-81	DTC P2143 [WL-C, WE-C]	01-02B-154
DTC P0340 [WL-C, WE-C]	01-02B-84	DTC P2144 [WL-C, WE-C]	01-02B-156
DTC P0380 [WL-C, WE-C]	01-02B-86	DTC P2145 [WL-C, WE-C]	01-02B-158
DTC P0400 [WL-3]	01-02A-33	DTC P2146 [WL-C, WE-C]	01-02B-160
DTC P0403 [WL-C, WE-C]	01-02B-89	DTC P2147 [WL-C, WE-C]	01-02B-160
DTC P0405 [WL-C, WE-C]	01-02B-91	DTC P2148 [WL-C, WE-C]	01-02B-162
DTC P0406 [WL-C, WE-C]	01-02B-93	DTC P2149 [WL-C, WE-C]	01-02B-164
DTC P0489 [WL-C, WE-C]	01-02B-95	DTC P2150 [WL-C, WE-C]	01-02B-165
DTC P0490 [WL-C, WE-C]	01-02B-96	DTC P2151 [WL-C, WE-C]	01-02B-167
DTC P0500 [WL-3]	01-02A-34	DTC P2227 [WL-C, WE-C]	01-02B-170
DTC P0500 [WL-C, WE-C]	01-02B-98	DTC P2228 [WL-C, WE-C]	01-02B-170
DTC P0510 [WL-3]	01-02A-36	DTC P2229 [WL-C, WE-C]	01-02B-171
DTC P0563 [WL-C, WE-C]	01-02B-100	DTC TABLE [AUDIO SYSTEM]	09-02B-2
DTC P0602 [WL-C, WE-C]	01-02B-102	DTC TABLE [WL-3]	01-02A-11
DTC P0606 [WL-3]	01-02A-37	DTC TABLE [WL-C, WE-C]	01-02B-11
DTC P0606, P2530 [WL-C, WE-C]	01-02B-102	DTC TABLE	08-02-3
DTC P0607 [WL-C, WE-C]	01-02B-102	DTC TABLE [IMMOBILIZER SYSTEM]	09-02A-2
DTC P0610 [WL-C, WE-C]	01-02B-103	DUAL-MASS FLYWHEEL INSPECTION [S15M-D, S15MX-D]	05-10-19
DTC P0627 [WL-C, WE-C]	01-02B-104		
DTC P0628 [WL-C, WE-C]	01-02B-106		
DTC P0629 [WL-C, WE-C]	01-02B-107		
DTC P0642 [WL-C, WE-C]	01-02B-109		
DTC P0643 [WL-C, WE-C]	01-02B-112		
DTC P0652 [WL-C, WE-C]	01-02B-116		
DTC P0653 [WL-C, WE-C]	01-02B-119		
DTC P0660 [WL-C, WE-C]	01-02B-123		
DTC P0661 [WL-C, WE-C]	01-02B-125		
DTC P0662 [WL-C, WE-C]	01-02B-127		

E

EGR CONTROL SOLENOID VALVE INSPECTION [WL-3]	01-16A-6
EGR CONTROL SOLENOID VALVE INSPECTION [WL-C, WE-C]	01-16B-6

ALPHABETICAL INDEX

EGR SOLENOID VALVE (VACUUM)	
INSPECTION [WL-3]	01-16A-5
EGR SOLENOID VALVE (VENT)	
INSPECTION [WL-3]	01-16A-5
EGR SOLENOID VALVE	
INSPECTION [WL-C, WE-C]	01-16B-5
EGR SYSTEM	
REMOVAL/INSTALLATION [WL-3]	01-16A-4
EGR SYSTEM REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-16B-4
EGR VALVE INSPECTION [WL-3]	01-16A-5
EGR VALVE INSPECTION [WL-C, WE-C]	01-16B-5
EGR VALVE POSITION SENSOR	
INSPECTION [WL-3]	01-40A-32
EGR VALVE POSITION SENSOR	
INSPECTION [WL-C, WE-C]	01-40B-40
ELECTRICAL SYSTEM	00-00-19
ELECTRONIC GOVERNOR	
INSPECTION [WL-3]	01-14A-15
EMISSION SYSTEM DIAGRAM [WL-3]	01-16A-3
EMISSION SYSTEM	
DIAGRAM [WL-C, WE-C]	01-16B-3
EMISSION SYSTEM	
LOCATION INDEX [WL-3]	01-16A-1
EMISSION SYSTEM	
LOCATION INDEX [WL-C, WE-C]	01-16B-1
ENGINE CONTROL SYSTEM	
OPERATION INSPECTION [WL-3]	01-03A-35
ENGINE CONTROL SYSTEM OPERATION	
INSPECTION [WL-C, WE-C]	01-03B-62
ENGINE COOLANT	
LEAKAGE INSPECTION [WL-3]	01-12A-5
ENGINE COOLANT LEAKAGE	
INSPECTION [WL-C, WE-C]	01-12B-5
ENGINE COOLANT	
LEVEL INSPECTION [WL-3]	01-12A-2
ENGINE COOLANT	
LEVEL INSPECTION [WL-C, WE-C]	01-12B-2
ENGINE COOLANT	
PROTECTION INSPECTION [WL-3]	01-12A-2
ENGINE COOLANT	
PROTECTION INSPECTION [WL-C, WE-C]	01-12B-2
ENGINE COOLANT REPLACEMENT [WL-3]	01-12A-3
ENGINE COOLANT	
REPLACEMENT [WL-C, WE-C]	01-12B-3
ENGINE COOLANT TEMPERATURE	
(ECT) SENSOR INSPECTION [WL-3]	01-40A-26
ENGINE COOLANT TEMPERATURE	
(ECT) SENSOR INSPECTION	
[WL-C, WE-C]	01-40B-35
ENGINE COOLANT TEMPERATURE	
(ECT) SENSOR REMOVAL/	
INSTALLATION [WL-3]	01-40A-26
ENGINE COOLANT TEMPERATURE	
(ECT) SENSOR REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-40B-34
ENGINE DISASSEMBLY/ASSEMBLY	
[WL-3]	01-10A-20
ENGINE DISASSEMBLY/	
ASSEMBLY [WL-C, WE-C]	01-10B-21
ENGINE OIL LEVEL INSPECTION [WL-3]	01-11A-2
ENGINE OIL LEVEL INSPECTION	
[WL-C, WE-C]	01-11B-2
ENGINE OIL REPLACEMENT [WL-3]	01-11A-3

ENGINE OIL REPLACEMENT
[WL-C, WE-C]01-11B-3

ENGINE REMOVAL/
INSTALLATION [WL-C, WE-C]01-10B-19

ENGINE REMOVAL/INSTALLATION [WL-3]...01-10A-1

ENGINE SST [WL-3]01-60A-1

ENGINE SST [WL-C, WE-C]01-60B-1

ENGINE SWITCH INSPECTION09-21-3

ENGINE SWITCH REMOVAL/INSTALLATION...09-21-2

ENGINE TECHNICAL DATA [WL-3]01-00-1

ENGINE TECHNICAL DATA [WL-3]01-50A-1

ENGINE TECHNICAL DATA [WL-C, WE-C] ...01-50B-1

ENGINE TUNE-UP [WL-3]01-10A-20

ENGINE TUNE-UP [WL-C, WE-C]01-10B-21

ENTERTAINMENT LOCATION INDEX09-20-2

EVAPORATIVE CHAMBER
INSPECTION [WL-3]01-16A-7

EVAPORATOR INSPECTION07-11-5

EXHAUST SYSTEM INSPECTION [WL-3]01-15A-1

EXHAUST SYSTEM
INSPECTION [WL-C, WE-C]01-15B-1

EXHAUST SYSTEM
REMOVAL/INSTALLATION [WL-3]01-15A-2

EXHAUST SYSTEM
REMOVAL/INSTALLATION [WL-C, WE-C] ...01-15B-2

EXTERIOR TRIM LOCATION INDEX09-16-1

F

FAN SWITCH INSPECTION	07-40-10
FILAMENT INSPECTION.....	09-12-18
FILAMENT REPAIR	09-12-18
FILAMENT SWITCH	
REMOVAL/INSTALLATION.....	09-12-18
FLASHER UNIT INSPECTION.....	09-18-12
FLASHER UNIT REMOVAL/INSTALLATION	09-18-12
FLOOR COVERING	
REMOVAL/INSTALLATION	09-17-23
FLYWHEEL INSPECTION [R15M-D].....	05-10-18
FOREWORD [4W-ABS]	04-03B-2
FOREWORD [RADIO]	09-03D-9
FOREWORD [REAR ABS].....	04-03A-1
FOREWORD [WL-3].....	01-02A-4
FOREWORD [WL-C, WE-C]	01-02B-6
FOREWORD	03-03-1
FOREWORD	07-03-1
FOREWORD	08-02-1
FOREWORD	09-03A-2
FOREWORD	09-03B-1
FOREWORD [CD PLAYER/CHANGER]	09-03D-17
FOREWORD [ENTIRE AUDIO SYSTEM]	09-03D-1
FOREWORD [IMMOBILIZER SYSTEM]	09-02A-1
FREEZE FRAME DATA [WL-C, WE-C]	01-02B-6
FRONT ABS WHEEL-SPEED SENSOR	
INSPECTION	04-13B-9
FRONT ABS WHEEL-SPEED SENSOR	
REMOVAL/INSTALLATION	
[4W-ABS (4x2 (EXCEPT Hi-Rider))]	04-13B-7
FRONT ABS WHEEL-SPEED SENSOR	
REMOVAL/INSTALLATION	
[4W-ABS (Hi-Rider, 4x4)].....	04-13B-8
FRONT AXLE LOCATION INDEX	
[4x2 (EXCEPT Hi-Rider)]	03-11-1
FRONT AXLE LOCATION INDEX [4x4].....	03-11-2

ALPHABETICAL INDEX

FRONT AXLE LOCATION INDEX [Hi-Rider]03-11-2
 FRONT BELTLINE MOLDING
 REMOVAL/INSTALLATION09-16-5
 FRONT BRAKE (DISC) INSPECTION04-11-15
 FRONT BRAKE (DISC)
 REMOVAL/INSTALLATION
 [4x2 (EXCEPT Hi-Rider)]04-11-16
 FRONT BRAKE (DISC)
 REMOVAL/INSTALLATION [Hi-Rider, 4x4]04-11-17
 FRONT BUMPER REINFORCEMENT
 REMOVAL/INSTALLATION09-10-9
 FRONT BUMPER DISASSEMBLY/ASSEMBLY09-10-7
 FRONT BUMPER REMOVAL/INSTALLATION09-10-6
 FRONT COMBINATION LIGHT
 REMOVAL/INSTALLATION09-18-3
 FRONT DIFFERENTIAL ASSEMBLY03-14A-8
 FRONT DIFFERENTIAL DISASSEMBLY03-14A-4
 FRONT DIFFERENTIAL LOCATION INDEX03-14A-1
 FRONT DIFFERENTIAL OIL INSPECTION03-14A-1
 FRONT DIFFERENTIAL OIL REPLACEMENT03-14A-2
 FRONT DIFFERENTIAL
 REMOVAL/INSTALLATION03-14A-2
 FRONT DOOR GLASS
 REMOVAL/INSTALLATION09-12-3
 FRONT DOOR INNER HANDLE
 REMOVAL/INSTALLATION09-14-6
 FRONT DOOR LATCH AND LOCK
 ACTUATOR INSPECTION09-14-7
 FRONT DOOR LATCH AND
 LOCK ACTUATOR
 REMOVAL/INSTALLATION09-14-7
 FRONT DOOR TRIM
 REMOVAL/INSTALLATION09-17-17
 FRONT DOOR UNIT
 REMOVAL/INSTALLATION09-11-4
 FRONT DOOR REMOVAL/INSTALLATION09-11-2
 FRONT DRIVE SHAFT
 DISASSEMBLY/ASSEMBLY03-13-4
 FRONT DRIVE SHAFT INSPECTION03-13-1
 FRONT DRIVE SHAFT
 REMOVAL/INSTALLATION03-13-2
 FRONT FENDER PANEL
 REMOVAL/INSTALLATION09-10-9
 FRONT FLAP REMOVAL/INSTALLATION09-16-4
 FRONT FOG LIGHT AIMING09-18-5
 FRONT FOG LIGHT BULB
 REMOVAL/INSTALLATION09-18-6
 FRONT FOG LIGHT
 REMOVAL/INSTALLATION09-18-5
 FRONT FOG LIGHT SWITCH INSPECTION09-18-10
 FRONT LOWER ARM INSPECTION02-13-13
 FRONT MANUAL WINDOW REGULATOR
 REMOVAL/INSTALLATION09-12-6
 FRONT OIL SEAL REPLACEMENT [WL-3]01-10A-15
 FRONT OIL SEAL
 REPLACEMENT [WL-C, WE-C]01-10B-16
 FRONT OUTER HANDLE
 REMOVAL/INSTALLATION09-14-5
 FRONT POWER WINDOW MOTOR
 REMOVAL/INSTALLATION09-12-7
 FRONT POWER WINDOW REGULATOR
 REMOVAL/INSTALLATION09-12-5
 FRONT SCUFF PLATE
 REMOVAL/INSTALLATION09-17-20
 FRONT SEAT DISASSEMBLY/ASSEMBLY09-13-4

FRONT SEAT REMOVAL/INSTALLATION 09-13-4
 FRONT SHOCK ABSORBER DISPOSAL 02-13-5
 FRONT SHOCK ABSORBER INSPECTION 02-13-4
 FRONT SHOCK ABSORBER
 REMOVAL/INSTALLATION 02-13-4
 FRONT SIDE TRIM
 REMOVAL/INSTALLATION 09-17-14
 FRONT SIDE TURN LIGHT
 REMOVAL/INSTALLATION 09-18-6
 FRONT SPEAKER INSPECTION 09-20-5
 FRONT SPEAKER
 REMOVAL/INSTALLATION 09-20-5
 FRONT STABILIZER AND TENSION
 ROD REMOVAL/INSTALLATION
 [4x2 (EXCEPT Hi-Rider)] 02-13-16
 FRONT STABILIZER REMOVAL/INSTALLATION
 [Hi-Rider, 4x4] 02-13-17
 FRONT SUSPENSION LOCATION
 INDEX [4x2 (EXCEPT Hi-Rider)] 02-13-1
 FRONT SUSPENSION LOCATION
 INDEX [4x4] 02-13-3
 FRONT SUSPENSION LOCATION
 INDEX [Hi-Rider] 02-13-2
 FRONT TURN LIGHT BULB
 REMOVAL/INSTALLATION 09-18-5
 FRONT UPPER ARM INSPECTION 02-13-16
 FRONT UPPER ARM
 REMOVAL/INSTALLATION 02-13-14
 FRONT WHEEL ALIGNMENT [4x2] 02-11-3
 FRONT WHEEL ALIGNMENT [4x4] 02-11-5
 FUEL CUT SOLENOID VALVE
 INSPECTION [WL-3] 01-14A-21
 FUEL CUT SOLENOID VALVE
 REMOVAL/INSTALLATION [WL-3] 01-14A-21
 FUEL FILTER
 REMOVAL/INSTALLATION [WL-3] 01-14A-10
 FUEL FILTER REMOVAL/
 INSTALLATION [WL-C, WE-C] 01-14B-9
 FUEL GAUGE SENDER UNIT INSPECTION 09-22-12
 FUEL INJECTION PUMP
 INSPECTION [WL-3] 01-14A-13
 FUEL INJECTION PUMP
 REMOVAL/INSTALLATION [WL-3] 01-14A-12
 FUEL INJECTOR CODE PROGRAM
 [WL-C, WE-C] 01-40B-21
 FUEL INJECTOR
 INSPECTION [WL-C, WE-C] 01-14B-16
 FUEL INJECTOR REMOVAL/
 INSTALLATION [WL-C, WE-C] 01-14B-15
 FUEL METERING
 VALVE INSPECTION [WL-C, WE-C] 01-14B-13
 FUEL PRESSURE SENSOR
 INSPECTION [WL-C, WE-C] 01-40B-33
 FUEL PUMP SPEED SENSOR
 INSPECTION [WL-3] 01-40A-24
 FUEL SYSTEM DIAGRAM [WL-3] 01-14A-4
 FUEL SYSTEM DIAGRAM [WL-C, WE-C] 01-14B-3
 FUEL SYSTEM LOCATION INDEX [WL-3] 01-14A-2
 FUEL SYSTEM
 LOCATION INDEX [WL-C, WE-C] 01-14B-1
 FUEL TANK INSPECTION [WL-3] 01-14A-9
 FUEL TANK INSPECTION [WL-C, WE-C] 01-14B-8
 FUEL TANK
 REMOVAL/INSTALLATION [WL-3] 01-14A-5

ALPHABETICAL INDEX

FUEL TANK REMOVAL/ INSTALLATION [WL-C, WE-C]	01-14B-4
FUEL TEMPERATURE SENSOR INSPECTION [WL-3]	01-40A-23
FUEL TEMPERATURE SENSOR INSPECTION [WL-C, WE-C]	01-40B-32
FUEL-FILLER LID ADJUSTMENT	09-10-2
FUEL-FILLER LID AND OPENER REMOVAL/INSTALLATION	09-14-17
FUEL-FILLER LID REMOVAL/INSTALLATION	09-10-2
FUEL-INLET FILTER REMOVAL/INSTALLATION [WL-3]	01-14A-16
FUEL-INLET FILTER REMOVAL/INSTALLATION [WL-C, WE-C]	01-14B-14
FUSE SERVICE CAUTIONS	09-21-2

G

G SENSOR INSPECTION [4W-ABS]	04-13B-13
G SENSOR REMOVAL/INSTALLATION [4W-ABS]	04-13B-12
GENERAL PRECAUTION (STEERING)	06-10-1
GENERAL PROCEDURES (BRAKE)	04-10-1
GENERAL PROCEDURES (FRONT AND REAR AXLES)	03-10-1
GENERAL PROCEDURES (SUSPENSION)	02-10-1
GENERAL PROCEDURES (CLUTCH)	05-10-3
GENERATOR DISASSEMBLY/ASSEMBLY	01-17-8
GENERATOR INSPECTION	01-17-5
GENERATOR REMOVAL/INSTALLATION	01-17-4
GLASS/WINDOWS/MIRRORS LOCATION INDEX	09-12-2
GLOVE COMPARTMENT LIGHT BULB REMOVAL/INSTALLATION	09-18-15
GLOVE COMPARTMENT REMOVAL/INSTALLATION	09-17-9
GLOVE COMPARTMENT UPPER REMOVAL/INSTALLATION	09-17-9
GLOW PLUG CORD INSPECTION [WL-3]	01-13A-8
GLOW PLUG CORD INSPECTION [WL-C, WE-C]	01-13B-11
GLOW PLUG INSPECTION [WL-3]	01-13A-6
GLOW PLUG INSPECTION [WL-C, WE-C]	01-13B-9
GLOW PLUG RELAY INSPECTION [WL-3]	01-13A-7
GLOW PLUG RELAY INSPECTION [WL-C, WE-C]	01-13B-9
GLOW PLUG RELAY REMOVAL/INSTALLATION [WL-3]	01-13A-7
GLOW PLUG RELAY REMOVAL/ INSTALLATION [WL-C, WE-C]	01-13B-9
GLOW PLUG REMOVAL/INSTALLATION [WL-3]	01-13A-6
GLOW PLUG REMOVAL/ INSTALLATION [WL-C, WE-C]	01-13B-8
GUIDE BLADE ACTUATOR INSPECTION [WL-C, WE-C]	01-13B-6

H

HAZARD WARNING SWITCH INSPECTION	09-18-10
HAZARD WARNING SWITCH REMOVAL/INSTALLATION	09-18-10
HEADLIGHT AIMING	09-18-4

HEADLIGHT BULB REMOVAL/INSTALLATION	09-18-4
HEADLINER REMOVAL/INSTALLATION	09-17-21
HEATER, VENTILATION & AIR CONDITIONING (HVAC) SST	07-60-1
HIGH-MOUNT BRAKE LIGHT REMOVAL/INSTALLATION	09-18-7
HORN RELAY INSPECTION	09-22-14
HORN RELAY REMOVAL/INSTALLATION	09-22-14
HORN REMOVAL/INSTALLATION	09-22-14
HOW TO USE THIS MANUAL	00-00-2
HVAC BASIC SYSTEM LOCATION INDEX	07-11-1
HVAC CONTROL SYSTEM LOCATION INDEX	07-40-1
HVAC TECHNICAL DATA	07-50-1

I

IDENTIFICATION NUMBER LOCATIONS	00-00-29
IDLE SWITCH INSPECTION [WL-3]	01-40A-22
IDLE SWITCH INSPECTION [WL-C, WE-C]	01-40B-30
IG KEY ILLUMINATION BULB REMOVAL/INSTALLATION	09-18-16
IMMOBILIZER SYSTEM LOCATION INDEX	09-14-4
IMMOBILIZER SYSTEM REPROGRAM PROCEDURE	09-14-24
IMMOBILIZER UNIT INSPECTION	09-14-22
IMMOBILIZER UNIT REMOVAL/INSTALLATION	09-14-22
INJECTION NOZZLE DISASSEMBLY/ASSEMBLY [WL-3]	01-14A-18
INJECTION NOZZLE INSPECTION [WL-3]	01-14A-19
INJECTION NOZZLE REMOVAL/INSTALLATION [WL-3]	01-14A-17
INJECTION PUMP EPROM INSPECTION [WL-3]	01-40A-29
INNER GARNISH REMOVAL/INSTALLATION	09-17-11
INSPECTION AFTER TRANSMISSION INSTALLATION [R15M-D]	05-11A-6
INSPECTION AFTER TRANSMISSION INSTALLATION [S15M-D]	05-11B-12
INSPECTION AFTER TRANSMISSION AND TRANSFER INSTALLATION [S15MX-D]	05-11B-12
INSPECTION OF SST (DEPLOYMENT TOOL)	08-10-19
INSTALLATION OF RADIO SYSTEM	00-00-18
INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY	09-22-2
INSTRUMENT CLUSTER INPUT/OUTPUT CHECK MODE	09-22-4
INSTRUMENT CLUSTER INSPECTION	09-22-2
INSTRUMENT CLUSTER REMOVAL/INSTALLATION	09-22-2
INSTRUMENTATION/DRIVER INFO. LOCATION INDEX	09-22-1
INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 INSPECTION [WL-3]	01-40A-18
INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 INSPECTION [WL-C, WE-C]	01-40B-26
INTAKE SHUTTER SOLENOID VALVE (FULL) INSPECTION [WL-C, WE-C]	01-16B-7
INTAKE SHUTTER SOLENOID VALVE (HALF) INSPECTION [WL-C, WE-C]	01-16B-6

ALPHABETICAL INDEX

INTAKE SHUTTER VALVE	
INSPECTION [WL-C, WE-C]	01-16B-7
INTAKE-AIR SYSTEM	
LOCATION INDEX [WL-3]	01-13A-1
INTAKE-AIR SYSTEM	
LOCATION INDEX [WL-C, WE-C]	01-13B-1
INTAKE-AIR SYSTEM	
REMOVAL/INSTALLATION [WL-3]	01-13A-2
INTAKE-AIR SYSTEM	
REMOVAL/INSTALLATION [WL-C, WE-C]	01-13B-3
INTAKE-AIR SYSTEM VACUUM	
HOSE ROUTING DIAGRAM [WL-3]	01-13A-2
INTAKE-AIR SYSTEM VACUUM HOSE	
ROUTING DIAGRAM [WL-C, WE-C]	01-13B-2
INTERIOR LIGHT INSPECTION	09-18-14
INTERIOR LIGHT REMOVAL/INSTALLATION ...	09-18-13
INTERIOR TRIM LOCATION INDEX	09-17-2
INTERMITTENT CONCERN	
TROUBLESHOOTING [WL-3]	01-03A-33
INTERMITTENT CONCERN	
TROUBLESHOOTING [WL-C, WE-C]	01-03B-60

J

JACKING POSITIONS	00-00-25
JOINT SHAFT COMPONENT ASSEMBLY	03-18-9
JOINT SHAFT COMPONENT DISASSEMBLY ...	03-18-7
JOINT SHAFT COMPONENT	
REMOVAL/INSTALLATION	03-18-5

K

KEY REMINDER SWITCH INSPECTION	09-21-3
KEY REMINDER SWITCH	
REMOVAL/INSTALLATION	09-21-3
KEYLESS CONTROL MODULE	
DISASSEMBLY/ASSEMBLY	09-14-13
KEYLESS CONTROL MODULE INSPECTION ...	09-14-13
KEYLESS CONTROL MODULE	
REMOVAL/INSTALLATION	09-14-12
KEYLESS ENTRY SYSTEM CHECK SHEET ...	09-03B-2
KEYLESS ENTRY SYSTEM	
PRELIMINARY INSPECTION	09-03B-3
KEYLESS ENTRY SYSTEM	
WIRING DIAGRAM	09-03B-1
KOEO/KOER SELF TEST [WL-3]	01-02A-10
KOEO/KOER SELF TEST [WL-C, WE-C]	01-02B-10

L

LICENSE PLATE LIGHT	
REMOVAL/INSTALLATION	09-18-8
LIGHT SWITCH INSPECTION	09-18-11
LIGHT SWITCH REMOVAL/INSTALLATION	09-18-11
LIGHTING SYSTEMS LOCATION INDEX	09-18-2
LOAD SENSING PROPORTIONING	
VALVE (LSPV) ADJUSTMENT	04-11-13
LOAD SENSING PROPORTIONING	
VALVE (LSPV) INSPECTION	04-11-12
LOAD SENSING PROPORTIONING	
VALVE (LSPV) REMOVAL/INSTALLATION ...	04-11-14
LOCATION INDEX [WL-3]	01-11A-1
LOCATION INDEX [WL-C, WE-C]	01-11B-1

LOCATION INDEX	08-10-1
LOCATION INDEX	08-11-1
LOCK AND FREE SOLENOID	
VALVES INSPECTION	03-18-4
LOWER PANEL REMOVAL/INSTALLATION	09-17-10

M

MAGNETIC CLUTCH ADJUSTMENT	07-40-4
MAGNETIC CLUTCH INSPECTION	07-40-5
MAGNETIC CLUTCH	
DISASSEMBLY/ASSEMBLY	07-40-3
MAIN FUSE REMOVAL/INSTALLATION	09-21-2
MAIN RELAY INSPECTION [WL-3]	01-40A-14
MAIN RELAY INSPECTION [WL-C, WE-C]	01-40B-23
MANUAL TRANSMISSION LOCATION	
INDEX [R15M-D]	05-11A-1
MANUAL TRANSMISSION LOCATION	
INDEX [S15M-D, S15MX-D]	05-11B-2
MASS AIR FLOW (MAF) SENSOR	
DATA RESET [WL-C, WE-C]	01-40B-22
MASS AIR FLOW (MAF) SENSOR/ INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.2 INSPECTION [WL-3]	01-40A-15
MASS AIR FLOW (MAF) SENSOR/ INTAKE AIR TEMPERATURE (IAT)	
SENSOR NO.2 INSPECTION	
[WL-C, WE-C]	01-40B-23
MASTER CYLINDER	
DISASSEMBLY/ASSEMBLY	04-11-8
MASTER CYLINDER	
REMOVAL/INSTALLATION	04-11-6
MECHANICAL LOCATION INDEX [WL-3]	01-10A-2
MECHANICAL LOCATION	
INDEX [WL-C, WE-C]	01-10B-2
MEMORY CLEARING PROCEDURE	09-02B-2
METER HOOD REMOVAL/INSTALLATION	09-17-8

N

NEUTRAL SWITCH INSPECTION [WL-3]	01-40A-34
NEUTRAL SWITCH INSPECTION	
[WL-C, WE-C]	01-40B-43
NEUTRAL SWITCH REMOVAL/INSTALLATION	
[R15M-D]	05-11A-2
NEUTRAL SWITCH REMOVAL/INSTALLATION	
[S15M-D, S15MX-D]	05-11B-3
NEW STANDARDS	00-00-30
NO. 1 ON-BOARD DIAGNOSTIC	
FUNCTION INOPERATIVE	09-03B-5
NO. 1 THE AUTO OPEN/CLOSE	
FUNCTION ON THE DRIVER'S SIDE	
POWER WINDOW IS INOPERATIVE	
[WITH AUTOMATIC DOOR GLASS	
RETURN FUNCTION]	09-03A-7
NO. 2 THE DRIVER'S SIDE POWER	
WINDOW INOPERATIVE	09-03A-7
NO. 2 TRANSMITTER ID CODE	
CANNOT BE REPROGRAMMED	09-03B-7
NO. 3 POWER WINDOWS OTHER	
THAN DRIVER'S SIDE DO NOT	
OPERATE BY SUBSWITCH	09-03A-9

ALPHABETICAL INDEX

NO. 4 POWER WINDOWS OTHER THAN DRIVER'S SIDE DO NOT OPERATE BY MAIN SWITCH.	09-03A-9
NO. 5 POWER WINDOWS OTHER THAN DRIVER'S SIDE DO NOT OPERATE BY MAIN SWITCH AND SUBSWITCH.	09-03A-9
NO. 6 THE DRIVER'S SIDE POWER WINDOW AUTOMATICALLY OPENS IN THE CLOSING OPERATION	09-03A-11
NO. 7 ABNORMAL NOISE DURING THE POWER WINDOW OPERATION.....	09-03A-13
NO.1 ABS WARNING LIGHT DOES NOT ILLUMINATE WHEN ENGINE SWITCH IS TURNED ON. [REAR ABS]	04-03A-3
NO.1 ABS WARNING LIGHT ILLUMINATE WHEN THE ENGINE SWITCH IS TURNED TO THE ON POSITION [4W-ABS].	04-03B-6
NO.1 AF NOISE OR POP NOISE ON ALL SOURCES (RADIO, CD)	09-03D-3
NO.1 AIR BAG SYSTEM WARNING LIGHT DOES NOT ILLUMINATE	08-03-1
NO.1 CD PLAYER/CHANGER DOES NOT LOAD THE CD OR EJECTS THE CD IMMEDIATELY	09-03D-19
NO.1 INSUFFICIENT AIR (OR NO AIR) BLOWN FROM VENTS.	07-03-1
NO.1 MELTING OF MAIN OR OTHER FUSES [WL-3]	01-03A-8
NO.1 MELTING OF MAIN OR OTHER FUSES [WL-C, WE-C]	01-03B-14
NO.1 NO RADIO RECEPTION (AM/FM)/NO OR LOW VOLUME.	09-03D-11
NO.1 NO RFW OPERATION FROM FREE TO LOCK (RFW INDICATOR LIGHT DOES NOT ILLUMINATE)	03-03-3
No.1 SECURITY LIGHT DISPLAY IS NOT NORMAL.	09-03C-1
NO.10 CD PLAYER DOES NOT PLAY THE AUDIO DATA (CDDA).....	09-03D-24
NO.10 LACK/LOSS OF POWER [WL-3]	01-03A-20
NO.10 LOW IDLE/STALLS DURING DECELERATION [WL-C, WE-C].	01-03B-30
NO.11 ENGINE STALLS/QUITS, ENGINE RUNS ROUGH, MISSES, BUCK/JERK, HESITATION/STUMBLE, SURGES [WL-C, WE-C].	01-03B-32
NO.11 POOR FUEL ECONOMY [WL-3]	01-03A-22
NO.11 TRACK CHANGE IS INOPERATIVE	09-03D-25
NO.12 HIGH OIL CONSUMPTION/ LEAKAGE [WL-3]	01-03A-24
NO.12 LACK/LOSS OF POWER-ACCELERATION/CRUISE [WL-C, WE-C].	01-03B-35
NO.13 COOLING SYSTEM CONCERNS-OVERHEATING [WL-3].	01-03A-25
NO.13 KNOCKING/PINGING [WL-C, WE-C] ...	01-03B-38
NO.14 COOLING SYSTEM CONCERNS-RUNS COLD [WL-3]	01-03A-26
NO.14 POOR FUEL ECONOMY [WL-C, WE-C]	01-03B-41
NO.15 EMISSION COMPLIANCE [WL-C, WE-C].	01-03B-44
NO.15 EXCESSIVE BLACK SMOKE [WL-3]	01-03A-26
NO.16 ENGINE NOISE [WL-3].	01-03A-27
NO.16 HIGH OIL CONSUMPTION/ LEAKAGE [WL-C, WE-C].	01-03B-47
NO.17 COOLING SYSTEM CONCERNS-OVERHEATING [WL-C, WE-C]	01-03B-48
NO.17 VIBRATION CONCERNS (ENGINE) [WL-3]	01-03A-29
NO.18 A/C DOES NOT WORK SUFFICIENTLY [WL-3].	01-03A-29
NO.18 COOLING SYSTEM CONCERNS-RUNS COLD [WL-C, WE-C]	01-03B-50
NO.19 A/C ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY [WL-3].	01-03A-30
NO.19 EXCESSIVE BLACK SMOKE [WL-C, WE-C]	01-03B-50
NO.2 ABS WARNING LIGHT REMAINS ILLUMINATED WITH THE ENGINE SWITCH IS TURNED ON. [REAR ABS]	04-03A-4
NO.2 ABS WARNING LIGHT DOES NOT ILLUMINATE WHEN THE ENGINE SWITCH IS TURNED TO THE ON POSITION [4W-ABS].	04-03B-7
NO.2 AIR BAG SYSTEM WARNING LIGHT ILLUMINATES CONSTANTLY	08-03-3
NO.2 AMOUNT OF AIR BLOWN FROM VENTS DOES NOT CHANGE	07-03-2
NO.2 CD PLAYER/CHANGER DOES NOT EJECT THE CD	09-03D-19
NO.2 ENGINE CHECK LAMP ILLUMINATES [WL-C, WE-C].	01-03B-15
NO.2 NO POWER ON THE ENTIRE AUDIO SYSTEM	09-03D-4
NO.2 NO RFW OPERATION FROM LOCK TO FREE (RFW INDICATOR LIGHT DOES NOT GO OFF).....	03-03-5
NO.2 NOISE FROM RADIO (AM ONLY)	09-03D-13
NO.2 WILL NOT CRANK [WL-3]	01-03A-9
NO.20 FUEL ODOR (IN ENGINE COMPARTMENT) [WL-C, WE-C].	01-03B-53
NO.20 INTERMITTENT CONCERNS [WL-3]. ...	01-03A-31
NO.21 CONSTANT VOLTAGE [WL-3].	01-03A-31
NO.21 ENGINE NOISE [WL-C, WE-C]	01-03B-54
NO.22 VIBRATION CONCERNS (ENGINE) [WL-C, WE-C]	01-03B-56
NO.23 A/C DOES NOT WORK SUFFICIENTLY [WL-C, WE-C]	01-03B-57
NO.24 A/C ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY [WL-C, WE-C]	01-03B-59
NO.25 A/C DOES NOT CUT OFF UNDER WIDE OPEN THROTTLE CONDITIONS [WL-C, WE-C].	01-03B-59
NO.3 ABS WARNING LIGHT STAYS ON 4 S OR MORE WHEN THE ENGINE SWITCH IS TURNED TO THE ON POSITION [4W-ABS].	04-03B-7
NO.3 CD PLAYER/CHANGER DOES NOT PLAY THE CD/NO SOUND	09-03D-20
NO.3 HARD TO START/LONG CRANK/ERRATIC START/ERRATIC CRANK [WL-3]	01-03A-10

ALPHABETICAL INDEX

NO.3 NO SOUND FROM ALL THE
SPEAKERS 09-03D-5

NO.3 NO TEMPERATURE CONTROL
WITH CLIMATE CONTROL UNIT 07-03-3

NO.3 NOISE FROM RADIO (FM ONLY) 09-03D-14

NO.3 NOISE 03-03-7

NO.3 WHEN THE ENGINE SWITCH IS
TURNED ON THE ABS WARNING
LIGHT BLINKS ONCE AND THEN
REMAINS ILLUMINATED. [REAR ABS] 04-03A-6

NO.3 WILL NOT CRANK [WL-C, WE-C] 01-03B-15

NO.4 ABS WARNING LIGHT FLASHES
ON AND OFF WHEN ENGINE SWITCH
IS TURNED ON OR VEHICLE IS
DRIVEN. [REAR ABS] 04-03A-6

NO.4 AIR FROM VENTS COLD ENOUGH 07-03-4

NO.4 CANNOT TUNE
(SEEK DOES NOT STOP) 09-03D-16

NO.4 ENGINE STALLS-AFTER
START/AT IDLE [WL-3] 01-03A-11

NO.4 HARD START/LONG CRANK/
ERRATIC START/ERRATIC
CRANK [WL-C, WE-C] 01-03B-17

NO.4 NO SOUND FROM SOME
SPEAKERS 09-03D-6

NO.4 OIL LEAKAGE 03-03-8

NO.4 SOUND JUMPS 09-03D-20

NO.4 THERE IS MALFUNCTION IN
THE SYSTEM EVEN THOUGH ABS
WARNING LIGHT, DO NOT
ILLUMINATE [4W-ABS] 04-03B-8

NO.5 ABS WARNING LIGHT
INDICATES ABS IS NORMAL,
HOWEVER, ABS DOES NOT
OPERATE CORRECTLY. [REAR ABS] 04-03A-7

NO.5 BROKEN SOUND OR POOR
SOUND QUALITY 09-03D-7

NO.5 CANNOT PRESET
(PRESET FUNCTION DOES NOT
OPERATE) 09-03D-16

NO.5 CD PLAYER/CHANGER
SCRATCHES ON THE CD. 09-03D-21

NO.5 CRANKS NORMALLY BUT
WILL NOT START [WL-3] 01-03A-13

NO.5 ENGINE STALLS-AFTER START/
AT IDLE [WL-C, WE-C] 01-03B-19

NO.5 NO COOL AIR. 07-03-6

NO.6 BRAKE SYSTEM WARNING
LIGHT REMAINS ILLUMINATED
WHEN ENGINE IS STARTED. [REAR ABS] 04-03A-8

NO.6 CRANKS NORMALLY BUT
WILL NOT START [WL-C, WE-C] 01-03B-22

NO.6 DISC CHANGER IS INOPERATIVE. 09-03D-21

NO.6 NOISE WHILE OPERATING A/C
SYSTEM. 07-03-8

NO.6 RECEPTION FREQUENCY OF
RADIO SLIPS. 09-03D-17

NO.6 SLOW RETURN TO IDLE/
FAST IDLE [WL-3] 01-03A-15

NO.6 SOUND BECOMES LOUDLY OR
WEAKLY WHILE DRIVING THE VEHICLE 09-03D-7

NO.7 ALC FUNCTION IS INOPERATIVE 09-03D-8

NO.7 CD PLAYER DOES NOT PLAY
THE MP3-FORMATTED FILE 09-03D-22

NO.7 ENGINE RUNS ROUGH/
ROLLING IDLE [WL-3] 01-03A-16

NO.7 SLOW RETURN TO IDLE
[WL-C, WE-C] 01-03B-24

NO.8 AUDIO SYSTEM ILLUMINATION
DOES NOT ILLUMINATE AT ALL 09-03D-8

NO.8 ENGINE RUNS ROUGH/
ROLLING IDLE [WL-C, WE-C] 01-03B-26

NO.8 MP3-FORMATTED FILE FOLDER
SELECTION IS INOPERATIVE/TRACK
SEARCH IS INOPERATIVE 09-03D-23

NO.8 RUNS ON [WL-3]. 01-03A-17

NO.9 CD PLAYER DOES NOT
INDICATE THE MP3 TITLE TEXT 09-03D-24

NO.9 ENGINE STALLS/QUITS,
ENGINE RUNS ROUGH, MISSES,
BUCK/JERK, HESITATION/
STUMBLE, SURGES [WL-3] 01-03A-18

NO.9 FAST IDLE/RUNS ON [WL-C, WE-C] 01-03B-28

NO.9 LCD DOES NOT DISPLAY AT ALL. 09-03D-9

O

OIL COOLER BODY INSPECTION [WL-3]. 01-11A-5

OIL COOLER BODY INSPECTION
[WL-C, WE-C] 01-11B-5

OIL COOLER REMOVAL/
INSTALLATION [WL-3]. 01-11A-4

OIL COOLER REMOVAL/
INSTALLATION [WL-C, WE-C]. 01-11B-4

OIL FILTER REPLACEMENT [WL-3] 01-11A-3

OIL FILTER REPLACEMENT [WL-C, WE-C] 01-11B-3

OIL PAN REMOVAL/INSTALLATION [WL-3] 01-11A-5

OIL PAN REMOVAL/INSTALLATION
[WL-C, WE-C] 01-11B-5

OIL PRESSURE INSPECTION [WL-3]. 01-11A-2

OIL PRESSURE INSPECTION [WL-C, WE-C] ... 01-11B-2

OIL PRESSURE SWITCH INSPECTION 09-22-13

OIL PUMP INSPECTION [WL-3]. 01-11A-9

OIL PUMP INSPECTION [WL-C, WE-C] 01-11B-10

OIL PUMP REMOVAL/INSTALLATION [WL-3] .. 01-11A-7

OIL PUMP REMOVAL/
INSTALLATION [WL-C, WE-C]. 01-11B-7

OIL SEAL (EXTENSION HOUSING)
REPLACEMENT [R15M-D]. 05-11A-3

OIL SEAL (EXTENSION HOUSING)
REPLACEMENT [S15M-D]. 05-11B-4

ON-BOARD DIAGNOSTIC
WIRING DIAGRAM [WL-3]. 01-02A-2

ON-BOARD DIAGNOSTIC
WIRING DIAGRAM [WL-C, WE-C] 01-02B-2

ON-BOARD DIAGNOSTIC FUNCTION 09-03B-4

ONE-WAY CHECK VALVE INSPECTION 03-18-4

ON-BOARD DIAGNOSIS [4W-ABS] 04-02B-2

ON-BOARD DIAGNOSIS [REAR ABS]. 04-02A-2

ON-BOARD DIAGNOSTIC TEST [WL-3] 01-02A-4

ON-BOARD DIAGNOSTIC TEST
[WL-C, WE-C] 01-02B-7

OUTER MIRROR GLASS
REMOVAL/INSTALLATION 09-12-19

OUTER MIRROR
REMOVAL/INSTALLATION 09-12-19

OVER FENDER REMOVAL/INSTALLATION. 09-16-4

ALPHABETICAL INDEX

P

PARAMETER IDENTIFICATION	
(PID) ACCESS [WL-3]	01-02A-4
PARAMETER IDENTIFICATION	
(PID) ACCESS [WL-C, WE-C]	01-02B-6
PARKING BRAKE CABLE	
REMOVAL/INSTALLATION [WL-3]	04-12-5
PARKING BRAKE CABLE	
REMOVAL/INSTALLATION	
[WL-C (EXCEPT Hi-Rider)]	04-12-6
PARKING BRAKE CABLE	
REMOVAL/INSTALLATION	
[WL-C (Hi-Rider), WE-C]	04-12-7
PARKING BRAKE LEVER	
REMOVAL/INSTALLATION	04-12-4
PARKING BRAKE LEVER ADJUSTMENT	04-12-3
PARKING BRAKE LEVER INSPECTION	04-12-3
PARKING BRAKE SWITCH INSPECTION	04-12-8
PARKING BRAKE SYSTEM LOCATION INDEX	04-12-2
PARKING LIGHT BULB	
REMOVAL/INSTALLATION	09-18-5
PASSENGER-SIDE AIR BAG MODULE	
REMOVAL/INSTALLATION	08-10-5
PCM CONFIGURATION [WL-C, WE-C]	01-40B-20
PCM DATA RESET [WL-C, WE-C]	01-40B-22
PCM INSPECTION [WL-3]	01-40A-7
PCM INSPECTION [WL-C, WE-C]	01-40B-10
PCM REMOVAL/INSTALLATION [WL-3]	01-40A-6
PCM REMOVAL/INSTALLATION	
[WL-C, WE-C]	01-40B-9
PENDING TROUBLE CODES [WL-C, WE-C]	01-02B-6
PID/DATA MONITOR DISPLAY	08-02-5
PID/DATA MONITOR TABLE	08-02-6
PILOT BEARING INSPECTION	05-10-18
POWER BRAKE UNIT INSPECTION	04-11-9
POWER BRAKE UNIT	
REMOVAL/INSTALLATION	04-11-10
POWER DOOR LOCK SYSTEM	
AND KEYLESS ENTRY SYSTEM	
LOCATION INDEX	09-14-2
POWER OUTER MIRROR SWITCH	
INSPECTION	09-12-21
POWER OUTER MIRROR SWITCH	
REMOVAL/INSTALLATION	09-12-20
POWER OUTER MIRROR INSPECTION	09-12-20
POWER STEERING FLUID INSPECTION	06-14-3
POWER STEERING OIL PUMP	
DISASSEMBLY/ASSEMBLY	06-14-15
POWER STEERING OIL PUMP	
REMOVAL/INSTALLATION	06-14-14
POWER SYSTEM LOCATION INDEX	09-21-1
POWER WINDOW MAIN SWITCH	
INSPECTION	09-12-8
POWER WINDOW MAIN SWITCH	
REMOVAL/INSTALLATION	09-12-8
POWER WINDOW MOTOR INSPECTION	09-12-7
POWER WINDOW SUBSWITCH	
INSPECTION	09-12-11
POWER WINDOW SUBSWITCH	
REMOVAL/INSTALLATION	09-12-11
POWER WINDOW SYSTEM INITIAL	
SETTING	09-12-11

POWER WINDOW SYSTEM	
TROUBLESHOOTING QUESTIONNAIRE	09-03A-3
POWER WINDOW SYSTEM	
WIRING DIAGRAM	09-03A-1
PRECAUTION [4W-ABS]	04-03B-2
PRECAUTION [REAR ABS]	04-03A-2
PRECAUTION	03-03-2
PRE-DELIVERY INSPECTION	00-00-33
PROPELLER SHAFT INSPECTION	03-15-4
PROPELLER SHAFT LOCATION INDEX	03-15-1
PROPELLER SHAFT	
REMOVAL/INSTALLATION	03-15-2

R

RADIATOR GRILLE	
REMOVAL/INSTALLATION	09-16-3
RADIATOR REMOVAL/	
INSTALLATION [WL-3]	01-12A-6
RADIATOR REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-12B-6
RADIO [REFERENCE]	09-03D-25
READ/CLEAR DIAGNOSTIC	
TEST RESULTS [WL-3]	01-02A-4
READ/CLEAR DIAGNOSTIC	
TEST RESULTS [WL-C, WE-C]	01-02B-6
REAR ABS WHEEL-SPEED SENSOR	
INSPECTION [4W-ABS]	04-13B-11
REAR ABS WHEEL-SPEED SENSOR	
REMOVAL/INSTALLATION	
[4W-ABS (4x2 (EXCEPT Hi-Rider))]	04-13B-10
REAR ABS WHEEL-SPEED SENSOR	
REMOVAL/INSTALLATION	
[4W-ABS (Hi-Rider, 4x4)]	04-13B-11
REAR ACCESS PANEL STRIKER	
REMOVAL/INSTALLATION	09-14-10
REAR ACCESS PANEL TRIM	
REMOVAL/INSTALLATION	09-17-18
REAR ACCESS PANEL	
DISASSEMBLY/ASSEMBLY	09-10-11
REAR ACCESS PANEL	
REMOVAL/INSTALLATION	09-10-10
REAR AXLE ADJUSTMENT	03-12-2
REAR AXLE INSPECTION	03-12-1
REAR AXLE LOCATION INDEX	03-12-1
REAR BELTLINE MOLDING	
REMOVAL/INSTALLATION	09-16-6
REAR BRAKE (DRUM) INSPECTION	04-11-22
REAR BRAKE (DRUM)	
REMOVAL/INSTALLATION	04-11-23
REAR BUMPER DISASSEMBLY/ASSEMBLY	09-10-8
REAR BUMPER REMOVAL/INSTALLATION	09-10-8
REAR COMBINATION LIGHT	
REMOVAL/INSTALLATION	09-18-7
REAR DIFFERENTIAL ASSEMBLY	
[LSD (LIMITED SLIP DIFFERENTIAL)]	03-14B-18
REAR DIFFERENTIAL ASSEMBLY	
[STANDARD DIFFERENTIAL]	03-14B-7
REAR DIFFERENTIAL DISASSEMBLY	
[LSD (LIMITED SLIP DIFFERENTIAL)]	03-14B-16
REAR DIFFERENTIAL DISASSEMBLY	
[STANDARD DIFFERENTIAL]	03-14B-4
REAR DIFFERENTIAL LOCATION INDEX	03-14B-1
REAR DIFFERENTIAL OIL INSPECTION	03-14B-2

ALPHABETICAL INDEX

REAR DIFFERENTIAL OIL REPLACEMENT . . . 03-14B-2
 REAR DIFFERENTIAL
 REMOVAL/INSTALLATION . . . 03-14B-3
 REAR DOOR GLASS AND REAR
 WINDOW REGULATOR
 REMOVAL/INSTALLATION . . . 09-12-4
 REAR DOOR INNER HANDLE
 REMOVAL/INSTALLATION . . . 09-14-7
 REAR DOOR LATCH AND
 LOCK ACTUATOR INSPECTION . . . 09-14-9
 REAR DOOR LATCH AND LOCK ACTUATOR
 REMOVAL/INSTALLATION . . . 09-14-9
 REAR DOOR TRIM
 REMOVAL/INSTALLATION . . . 09-17-18
 REAR DOOR UNIT REMOVAL/INSTALLATION . . 09-11-4
 REAR DOOR REMOVAL/INSTALLATION . . . 09-11-2
 REAR FLAP REMOVAL/INSTALLATION . . . 09-16-4
 REAR OIL SEAL REPLACEMENT [WL-3] . . . 01-10A-17
 REAR OIL SEAL
 REPLACEMENT [WL-C, WE-C] . . . 01-10B-18
 REAR OUTER HANDLE
 REMOVAL/INSTALLATION . . . 09-14-6
 REAR POWER WINDOW MOTOR
 REMOVAL/INSTALLATION . . . 09-12-7
 REAR QUARTER WINDOW GLASS
 REMOVAL/INSTALLATION . . . 09-12-5
 REAR SCUFF PLATE
 REMOVAL/INSTALLATION . . . 09-17-21
 REAR SEAT DISASSEMBLY/ASSEMBLY . . . 09-13-5
 REAR SEAT REMOVAL/INSTALLATION . . . 09-13-5
 REAR SHOCK ABSORBER AND LEAF
 SPRING REMOVAL/INSTALLATION
 [4x2 (EXCEPT Hi-Rider)] . . . 02-14-2
 REAR SHOCK ABSORBER AND LEAF
 SPRING REMOVAL/INSTALLATION
 [Hi-Rider, 4x4] . . . 02-14-3
 REAR SHOCK ABSORBER DISPOSAL . . . 02-14-4
 REAR SHOCK ABSORBER INSPECTION . . . 02-14-4
 REAR SIDE TRIM REMOVAL/INSTALLATION . . 09-17-14
 REAR SPEAKER INSPECTION . . . 09-20-6
 REAR SPEAKER REMOVAL/INSTALLATION . . . 09-20-6
 REAR STABILIZER REMOVAL/
 INSTALLATION [WL-C, WE-C] . . . 02-14-5
 REAR SUSPENSION LOCATION INDEX . . . 02-14-1
 REAR WINDOW GLASS REMOVAL . . . 09-12-16
 REAR WINDOW GLASS INSTALLATION . . . 09-12-17
 REARVIEW MIRROR
 REMOVAL/INSTALLATION . . . 09-12-21
 RECOVERY . . . 07-10-3
 REFRIGERANT CHARGING . . . 07-10-3
 REFRIGERANT LINES
 REMOVAL/INSTALLATION . . . 07-11-8
 REFRIGERANT PRESSURE SWITCH
 INSPECTION . . . 07-40-6
 REFRIGERANT PRESSURE SWITCH
 REMOVAL/INSTALLATION . . . 07-40-6
 REFRIGERANT PRESSURE CHECK . . . 07-10-3
 REFRIGERANT SYSTEM GENERAL
 PROCEDURES . . . 07-10-2
 REFRIGERANT SYSTEM SERVICE
 CAUTIONS . . . 07-10-1
 REFRIGERANT SYSTEM SERVICE
 WARNINGS . . . 07-10-1
 REFRIGERANT SYSTEM
 PERFORMANCE TEST . . . 07-10-2

REGULATOR HANDLE REMOVAL . . . 09-12-6
 REGULATOR HANDLE INSTALLATION . . . 09-12-6
 RESISTOR INSPECTION . . . 07-40-3
 RESISTOR REMOVAL/INSTALLATION . . . 07-40-3
 RESTRAINTS SST . . . 08-60-1
 RFW (REMOTE FREEWHEEL)
 ON-BOARD DIAGNOSIS . . . 03-02-1
 RFW (REMOTE FREEWHEEL)
 SYSTEM WIRING DIAGRAM . . . 03-02-1
 RFW ACTUATOR INSPECTION . . . 03-18-5
 RFW MAIN SWITCH INSPECTION . . . 03-18-4
 RFW MAIN SWITCH
 REMOVAL/INSTALLATION . . . 03-18-3
 RFW SWITCH INSPECTION . . . 03-18-3
 ROCKER ARM
 REMOVAL/INSTALLATION [WL-3] . . . 01-10A-12
 ROCKER ARM REMOVAL/
 INSTALLATION [WL-C, WE-C] . . . 01-10B-16
 ROLLOVER VALVE INSPECTION [WL-3] . . . 01-16A-6
 ROLLOVER VALVE INSPECTION
 [WL-C, WE-C] . . . 01-16B-8
 ROOF ANTENNA INSPECTION . . . 09-20-8
 ROOF ANTENNA INSTALLATION . . . 09-20-8
 ROOF ANTENNA REMOVAL . . . 09-20-7
 ROOF SIDE TRIM
 REMOVAL/INSTALLATION . . . 09-17-21
 ROPE HOOK REMOVAL/INSTALLATION . . . 09-16-3

S

SAS CONTROL MODULE
 REMOVAL/INSTALLATION . . . 08-10-6
 SCHEDULED MAINTENANCE . . . 00-00-34
 SEAT BELT INSPECTION . . . 08-11-6
 SEAT BELT REMOVAL/INSTALLATION . . . 08-11-1
 SEAT DISASSEMBLY/ASSEMBLY . . . 09-13-3
 SEAT LOCATION INDEX . . . 09-13-1
 SEAT REMOVAL/INSTALLATION . . . 09-13-2
 SEDIMENTOR SWITCH INSPECTION [WL-3] . . 01-14A-11
 SEDIMENTOR SWITCH
 INSPECTION [WL-C, WE-C] . . . 01-14B-10
 SEDIMENTOR WATER DRAINING [WL-3] . . . 01-14A-10
 SEDIMENTOR
 WATER DRAINING [WL-C, WE-C] . . . 01-14B-9
 SERVICE CAUTIONS . . . 00-00-12
 SERVICE CAUTIONS . . . 08-10-3
 SERVICE WARNINGS . . . 08-10-2
 SHIFT FORK INSPECTION . . . 03-18-14
 SIDE AIR BAG MODULE
 REMOVAL/INSTALLATION . . . 08-10-5
 SIDE AIR BAG SENSOR
 REMOVAL/INSTALLATION . . . 08-10-6
 STARTER DISASSEMBLY/ASSEMBLY . . . 01-19-8
 STARTER INSPECTION . . . 01-19-3
 STARTER REMOVAL/INSTALLATION [WL-3] . . . 01-19-2
 STARTER REMOVAL/
 INSTALLATION [WL-C, WE-C] . . . 01-19-2
 STARTING PROCEDURE FOR
 ON-BOARD DIAGNOSTIC TEST MODE . . . 09-02B-1
 STARTING SYSTEM LOCATION INDEX . . . 01-19-1
 STEERING GEAR AND LINKAGE
 DISASSEMBLY/ASSEMBLY . . . 06-14-11
 STEERING GEAR AND LINKAGE
 INSPECTION . . . 06-14-13

ALPHABETICAL INDEX

STEERING GEAR AND LINKAGE	
REMOVAL/INSTALLATION	06-14-10
STEERING LOCATION INDEX	
STEERING SHAFT INSPECTION	06-14-9
STEERING SST	06-60-1
STEERING TECHNICAL DATA	
STEERING WHEEL AND COLUMN	
INSPECTION	06-14-5
STEERING WHEEL AND COLUMN	
REMOVAL/INSTALLATION	06-14-6
SUPPLIER IDENTIFICATION PROCEDURE	
SUPPLY PUMP INSPECTION [WL-C, WE-C]	01-14B-13
SUPPLY PUMP REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-14B-11
SUSPENSION TECHNICAL DATA	
SUSPENSION	02-60-1
SYMPTOM DIAGNOSTIC INDEX [WL-3]	
SYMPTOM DIAGNOSTIC INDEX	
[WL-C, WE-C]	01-03B-6
SYMPTOM QUICK DIAGNOSIS	
CHART [WL-3]	01-03A-5
SYMPTOM QUICK DIAGNOSIS CHART	
[WL-C, WE-C]	01-03B-8
SYMPTOM TROUBLESHOOTING	
WIRING DIAGRAM [WL-3]	01-03A-2
SYMPTOM TROUBLESHOOTING	
WIRING DIAGRAM [WL-C, WE-C]	01-03B-2
SYMPTOM TROUBLESHOOTING	
SYMPTOM TROUBLESHOOTING [4W-ABS]	04-03B-5
SYMPTOM TROUBLESHOOTING	
[REAR ABS]	04-03A-2
SYMPTOM TROUBLESHOOTING	
CHART [IMMOBILIZER SYSTEM]	09-03C-1
SYMPTOM TROUBLESHOOTING CHART	
SYSTEM WIRING DIAGRAM [4W-ABS]	04-03B-1
SYSTEM WIRING DIAGRAM [REAR ABS]	

T

TAIL GATE STRIKER	
REMOVAL/INSTALLATION	09-14-11
TAILGATE ADJUSTMENT	
TAILGATE DISASSEMBLY/ASSEMBLY	09-16-2
THEFT-DETERRENT CONTROL	
MODULE INSPECTION	09-14-20
THEFT-DETERRENT HORN	
REMOVAL/INSTALLATION	09-14-21
THEFT-DETERRENT SYSTEM	
LOCATION INDEX	09-14-3
THEFT-DETERRENT CONTROL MODULE	
REMOVAL/INSTALLATION	09-14-19
THERMISTOR INSPECTION	
THERMISTOR REMOVAL/INSTALLATION	07-40-5
THERMOSTAT INSPECTION [WL-3]	
THERMOSTAT INSPECTION [WL-C, WE-C]	01-12A-8
THERMOSTAT REMOVAL/	
INSTALLATION [WL-3]	01-12A-7
THERMOSTAT REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-12B-7
TIMER CONTROL VALVE (TCV)	
INSPECTION [WL-3]	01-14A-15
TIMER POSITION SENSOR	
INSPECTION [WL-3]	01-40A-28

TIMING BELT	
REMOVAL/INSTALLATION [WL-3]	01-10A-7
TIMING BELT REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-10B-7
TORSION BAR SPRING AND LOWER	
ARM REMOVAL/INSTALLATION	
[4x2 (EXCEPT Hi-Rider)]	02-13-5
TORSION BAR SPRING AND LOWER	
ARM REMOVAL/INSTALLATION	
[Hi-Rider, 4x4]	02-13-9
TOWING	
TRANSFER LOCATION INDEX	03-16-1
TRANSFER NEUTRAL SWITCH INSPECTION	
TRANSFER OIL INSPECTION	03-16-1
TRANSFER OIL REPLACEMENT	
TRANSMISSION AND TRANSFER	
REMOVAL/INSTALLATION [S15MX-D]	05-11B-10
TRANSMISSION OIL INSPECTION [R15M-D]	
TRANSMISSION OIL INSPECTION	
[S15M-D, S15MX-D]	05-11B-3
TRANSMISSION OIL REPLACEMENT	
[R15M-D]	05-11A-2
TRANSMISSION OIL REPLACEMENT	
[S15M-D, S15MX-D]	05-11B-4
TRANSMISSION SST	
TRANSMISSION/TRANSAXLE	05-50-1
TRANSMISSION REMOVAL/INSTALLATION	
[R15M-D]	05-11A-5
TRANSMISSION REMOVAL/INSTALLATION	
[S15M-D]	05-11B-5
TRANSMITTER BATTERY INSPECTION	
TRANSMITTER BATTERY REPLACEMENT	09-14-16
TRANSMITTER ID CODE REGISTRATION	
TROUBLESHOOTING INDEX	07-03-1
TROUBLESHOOTING INDEX	
TROUBLESHOOTING INDEX	09-03B-4
TROUBLESHOOTING NOTE [REAR ABS]	
TURBOCHARGER INSPECTION [WL-3]	01-13A-5
TURBOCHARGER	
INSPECTION [WL-C, WE-C]	01-13B-5
TWEETER INSPECTION	
TWEETER REMOVAL/INSTALLATION	09-20-7

U

UNITS	00-00-11
-------------	----------

V

VACUUM CHECK VALVE	
INSPECTION [WL-C, WE-C]	01-13B-8
VACUUM LINE INSPECTION	
VACUUM PUMP INSPECTION	04-11-11
VACUUM PUMP REMOVAL/INSTALLATION	
VALVE CLEARANCE ADJUSTMENT [WL-3]	01-10A-5
VALVE CLEARANCE	
ADJUSTMENT [WL-C, WE-C]	01-10B-5
VALVE CLEARANCE INSPECTION [WL-3]	
VALVE CLEARANCE INSPECTION	
[WL-C, WE-C]	01-10B-5
VARIABLE BOOST CONTROL (VBC)	
SOLENOID VALVE INSPECTION	
[WL-C, WE-C]	01-13B-6
VEHICLE HEIGHT ADJUSTMENT [4x2]	
VEHICLE HEIGHT ADJUSTMENT [4x4]	02-11-2

ALPHABETICAL INDEX

VEHICLE IDENTIFICATION NUMBER	
(VIN) CODE	00-00-1
VEHICLE IDENTIFICATION NUMBERS (VIN)	00-00-1
VEHICLE LIFT (2 SUPPORTS) AND	
SAFETY STAND (RIGID RACK) POSITION	00-00-26
VEHICLE SPEED SENSOR (VSS)	
INSPECTION [S15MX-D]	03-16-2
VEHICLE SPEED SENSOR (VSS)	
REMOVAL/INSTALLATION [S15MX-D]	03-16-2
VEHICLE SPEED SENSOR (VSS)	
INSPECTION [R15M-D]	05-11A-4
VEHICLE SPEED SENSOR (VSS)	
INSPECTION [S15M-D]	05-11B-5
VEHICLE SPEED SENSOR (VSS)	
REMOVAL/INSTALLATION [R15M-D]	05-11A-3
VEHICLE SPEED SENSOR (VSS)	
REMOVAL/INSTALLATION [S15M-D]	05-11B-5
VENTILATOR GRILLE	
REMOVAL/INSTALLATION	09-17-10

W

WATER PUMP	
REMOVAL/INSTALLATION [WL-3]	01-12A-9
WATER PUMP REMOVAL/	
INSTALLATION [WL-C, WE-C]	01-12B-9
WATER TEMPERATURE SENDER UNIT	
INSPECTION	09-22-13
WATER TEMPERATURE SENDER UNIT	
INSTALLATION [WL-3]	09-22-13
WATER TEMPERATURE SENDER UNIT	
REMOVAL [WL-3]	09-22-12
WHEEL ALIGNMENT PRE-INSPECTION	02-11-2
WHEEL AND TIRE SPECIFICATION	02-12-1
WHEEL CYLINDER	
DISASSEMBLY/ASSEMBLY	04-11-25
WHEEL HUB BOLT REPLACEMENT	
[Hi-Rider, 4x4]	03-11-3
WHEEL HUB, STEERING KNUCKLE	
INSPECTION [4x2 (EXCEPT Hi-Rider)]	03-11-3
WHEEL HUB, STEERING KNUCKLE	

INSPECTION [Hi-Rider, 4x4]	03-11-4
WHEEL HUB, STEERING KNUCKLE	
REMOVAL/INSTALLATION	
[4x2 (EXCEPT Hi-Rider)]	03-11-4
WHEEL HUB, STEERING KNUCKLE	
REMOVAL/INSTALLATION [4x4]	03-11-14
WHEEL HUB, STEERING KNUCKLE	
REMOVAL/INSTALLATION [Hi-Rider]	03-11-8
WINDSHIELD GARNISH	
REMOVAL/INSTALLATION	09-16-2
WINDSHIELD INSTALLATION	09-12-14
WINDSHIELD REMOVAL	09-12-12
WINDSHIELD WASHER HOSE	
REMOVAL/INSTALLATION	09-19-6
WINDSHIELD WASHER	
MOTOR INSPECTION	09-19-5
WINDSHIELD WASHER MOTOR	
REMOVAL/INSTALLATION	09-19-5
WINDSHIELD WASHER NOZZLE	
ADJUSTMENT	09-19-6
WINDSHIELD WASHER	
NOZZLE INSTALLATION	09-19-6
WINDSHIELD WASHER NOZZLE REMOVAL	09-19-5
WINDSHIELD WASHER TANK	
REMOVAL/INSTALLATION	09-19-5
WINDSHIELD WIPER AND WASHER	
SWITCH INSPECTION	09-19-7
WINDSHIELD WIPER AND WASHER SWITCH	
REMOVAL/INSTALLATION	09-19-7
WINDSHIELD WIPER ARM AND	
BLADE ADJUSTMENT	09-19-4
WINDSHIELD WIPER ARM AND BLADE	
REMOVAL/INSTALLATION	09-19-3
WINDSHIELD WIPER LINK	
REMOVAL/INSTALLATION	09-19-3
WINDSHIELD WIPER MOTOR INSPECTION	09-19-4
WINDSHIELD WIPER MOTOR	
REMOVAL/INSTALLATION	09-19-4
WIPER/WASHER	
SYSTEM LOCATION INDEX	09-19-2