

ALPHABETICAL INDEX

4	4X4 INDICATOR SWITCH	54	F	FILAMENT	68
A	A/C AMPLIFIER	60		FLASHER CONTROL MODULE	94
	A/C RELAY	60		FOG LIGHT	92
	A/C SWITCH	60		FOG LIGHT RELAY	92
	ABBREVIATION	12		FOG LIGHT SWITCH	92
	ABS CM	58		FREE SOLENOID VALVE	52
	ABS HU	58		FRONT FOG LIGHT	92
	ABS HU/CM	56		FRONT FOG LIGHT RELAY	92
	ABS RELAY	58		FRONT FOG LIGHT SWITCH	92
	ABS SPEED SENSOR	58		FRONT POWER WINDOW REGULATOR	70
	ABS WHEEL-SPEED SENSOR	56		FRONT SIDE TURN LIGHT	94
	ACCELERATOR PEDAL			FRONT SPEAKER	108
	POSITION SENSOR	38, 50		FRONT TURN LIGHT	94
	ACCESSORY SOCKET	106		FUEL GAUGE SENDER UNIT	112
	AIR BAG MODULE	64		FUEL INJECTION PUMP	38, 40
	AUDIO UNIT	108		FUEL INJECTOR	44
B				FUEL METERING VALVE	44
	BACK-UP LIGHT	96		FUEL PRESSURE SENSOR	46
	BACK-UP LIGHT SWITCH	96		FUEL PUMP SPEED SENSOR	36
	BLOWER MOTOR	60		FUEL TEMPERATURE SENSOR	48
	BLOWER RELAY	60		FUSE BOX	20
	BLOWER UNIT	60	G		
	BONNET SWITCH	84		G SENSOR	56
	BOOST SENSOR	38, 48		GENERAL INFORMATION	2
	BRAKE FLUID LEVEL SENSOR	114		GENERATOR	32
	BRAKE LIGHT	98		GLOVE COMPARTMENT LIGHT	100
	BRAKE SWITCH	98		GLOW PLUG	36, 42
C				GLOW PLUG RELAY	36, 42
	CAMSHAFT POSITION SENSOR	46		GROUND POINT	26
	CIGARETTE LIGHTER	106	H		
	CKP SENSOR	40		HAZARD WARNING SWITCH	94
	CLIMATE CONTROL UNIT	60		HEADLIGHT	88
	CLOCK SPRING	64		HEADLIGHT RELAY	88
	CLUTCH PEDAL POSITION SWITCH	36, 42		HEADLIGHT SWITCH	88
	COIL	82		HIGH-MOUNT BRAKE LIGHT	98
	COMMON CONNECTOR LIST	22		HORN	118
	CRANKSHAFT POSITION SENSOR	48		HORN RELAY	118
D				HORN SWITCH	118
	DATA LINK CONNECTOR	30	I		
	DATA LINK CONNECTOR-2	30		IDLE SWITCH	36, 48
	DOOR KEY CYLINDER SWITCH	84		ILLUMINATION	
	DOOR LOCK ACTUATOR	78		A/C SWITCH	100
	DOOR LOCK CONTROL MODULE	76		AUDIO UNIT	100
	DOOR LOCK-LINK SWITCH	76, 86		CONSOLE	100
	DOOR SWITCH	102		HAZARD WARNING SWITCH	100
	DRIVER-SIDE AIR BAG MODULE	64		HEATER CONTROL	100
	DRIVER-SIDE PRE-TENSIONER SEAT BELT	66		IGNITION KEY	112
	DRIVER-SIDE SIDE AIR BAG MODULE	66		INSTRUMENT CLUSTER	100
	DRIVER-SIDE SIDE AIR BAG SENSOR	66		REAR WINDOW DEFROSTER SWITCH	100
E				RFW MAIN SWITCH	100
	EGR CONTROL SOLENOID VALVE	36, 46		IMMOBILIZER UNIT	82
	EGR SOLENOID VALVE	36, 46		INSTRUMENT CLUSTER	112
	EGR VALVE POSITION SENSOR	38, 46		INTAKE AIR TEMPERATURE	
	ELECTRICAL WIRING SCHEMATIC	18		SENSOR	38, 40, 44, 48
	ENGINE COOLANT			INTAKE SHUTTER SOLENOID VALVE	44
	TEMPERATURE SENSOR	38, 48		INTERIOR LIGHT	102
K					
	KEY REMINDER SWITCH	112			
	KEYLESS CONTROL MODULE	80			

ALPHABETICAL INDEX

L

LICENSE PLATE LIGHT	90
LOCK SOLENOID VALVE	52

M

MAGNETIC CLUTCH	60
MAIN RELAY	36, 42
MASS AIR FLOW SENSOR	40, 44

N

NEUTRAL SWITCH	36, 42
----------------------	--------

O

OIL PRESSURE SWITCH	116
---------------------------	-----

P

PARKING BRAKE SWITCH	114
PARKING LIGHT	90
PASSENGER-SIDE AIR BAG MODULE	64
PASSENGER-SIDE PRE-TENSIONER SEAT BELT	66
PASSENGER-SIDE SIDE AIR BAG MODULE	66
PASSENGER-SIDE SIDE AIR BAG SENSOR	66
PCM	36, 42, 52
POWER OUTER MIRROR	74
POWER OUTER MIRROR SWITCH	74
POWER WINDOW MAIN SWITCH	70
POWER WINDOW REGULATOR (FRONT)	70
(REAR)	72
POWER WINDOW SUBSWITCH	70
PRE-TENSIONER SEAT BELT	66

R

REAR POWER WINDOW REGULATOR	72
REAR SPEAKER	110
REAR TURN LIGHT	94
REAR WINDOW DEFROSTER RELAY	68
REAR WINDOW DEFROSTER SWITCH	68
REFRIGERANT PRESSURE SWITCH	60
RESISTOR	60
RETRACT/RETURN MOTOR	74
RFW LOCK SWITCH	54
RFW MAIN SWITCH	52

S

SAS CONTROL MODULE	64
SEDIMENTOR SWITCH	116
SIDE AIR BAG MODULE	66
SIDE AIR BAG SENSOR	66
SIDE TURN LIGHT	94
SPEAKER (FRONT)	108
(REAR)	110
STARTER	34

T

TAILLIGHT	90
TEST CONNECTOR	58
THEFT-DETERRENT CONTROL MODULE	84
THEFT-DETERRENT HORN	86
THEFT-DETERRENT HORN RELAY	86
THERMISTOR	60
TNS RELAY	88

TRANSFER NEUTRAL SWITCH	54
TURN LIGHT	94
TURN SWITCH	94
TWEETER	108

V

VARIABLE BOOST CONTROL SOLENOID VALVE	46
VARIABLE SWIRL CONTROL SOLENOID VALVE	46
VEHICLE IDENTIFICATION NUMBERS (VIN)	3
VEHICLE SPEEDOMETER SENSOR	112

W

WATER TEMPERATURE SENDER UNIT	112
WINDOW DEFROSTER RELAY	68
WINDOW DEFROSTER SWITCH	68
WINDSHIELD WASHER MOTOR	104
WINDSHIELD WIPER AND WASHER SWITCH	104
WINDSHIELD WIPER MOTOR	104
WIRING COLOR CODE	9