SPECIFICATIONS: T-3

The T-3 can be used with any amplifier or receiver having 4, 8 or 16 ohms as the source impedance available from the


Weight

- 31/2" x 2-1/8" x 11/4". Cord Length - 2@36"

- 4 ounces Shipping Weight

Description

- The T-3 is provided with two sets of leads. Four spade lugs are one set, These connect to the speaker terminals. (Color-coding must be observed to insure proper connections.) The second set is connected to the speaker wires. (Wire nuts are furnished for quick and



Operation

- After hookup is completed, be sure volume control is turned down. Turn speakers off with switch on T-3. Plug stereophones into T-3. Turn on amplifier or receiver and increase volume to desired level

To play speakers, throw T-3 speaker switch to on position, UNPLUG PHONES, and adjust volume to desired level.

CAUTION

- Always turn down volume before plugging in sensitive stereophones. UNPLUG PHONES when not in use in order to avoid accidents.

Some stereo amplifiers do not have a common grounded connection, especially those with a phase reversal switch or provision for a center channel output. If your receiver or amplifier does not have a front panel phone lack, special care must be taken in connecting the phones to the speaker terminals. Before conhecting to an amplifier with a phase reversal switch, be sure the speakers are in phase, with the switch in the normal position. This switch will not function properly with a common ground in the system, so it should never be moved from normal position. This will also avoid doing serious damage to the output stages of such equipment. If you have any questions about the proper connection of the phones to your system, be sure to consult with your dealer, or write to the Koss Customer Service Department at the factory for further information.



SPECIFICATIONS: T-3

The T-3 can be used with any amplifier or receiver having 4, 8 or 16 ohms as the source impedance available from the output taps.

Color

Size Cord Length

Weight Shipping Weight Description


- Black with brushed aluminum trim and gray or black cord.

- 3½" x 2·1/8" x 1¼". - 2@36"

4 ounces.

12 ounces.

- The T-3 is provided with two sets of leads. Four spade lugs are one set. These connect to the speaker terminals. (Color-coding must be observed to insure proper connections.) The second set is connected to the speaker wires. (Wire nuts are furnished for quick and positive splices.)



Operation

 After hookup is completed, be sure volume control is turned down. Turn speakers off with switch on T-3. Plug stereophones into T-3. Turn on amplifier or receiver and increase volume to desired level.

To play speakers, throw T-3 speaker switch to on position, UNPLUG PHONES, and adjust volume to desired level.

CAUTION

- Always turn down volume before plugging in sensitive stereophones. UNPLUG PHONES when not in use in order to avoid accidents.

Some stereo amplifiers do not have a common grounded connection, especially those with a phase reversal switch or provision for a center channel output. If your receiver or amplifier does not have a front panel phone lack, special care must be taken in connecting the phones to the speaker terminals. Before connecting to an amplifier with a phase reversal switch, be sure the speakers are in phase, with the switch in the normal position. This switch will not function properly with a common ground in the system, so it should never be moved from normal position. This will also avoid doing serious damage to the output stages of such equipment. If you have any questions about the proper connection of the phones to your system, be sure to consult with your dealer, or write to the Koss Customer Service Department at the factory for further information.

