

Control instructions


A couple of Swl, Swr (in any order) can be used to load a word from any (unaligned) location

```
Swl Rt, imd+3 (Rs) Swr Rt, imd (Rs)
Swr Rt, imd (Rs) Or Swl Rt, imd+3 (Rs)
```



Pirouz Bazargan Sabet

December 2008



☐ Computation instructions ☐ Memory access instructions ☐ Control instructions ☐ System instructions ☐ Pirouz Bazargan Sabet December 2008

