140/home/deck/Documents/OpenScad/TimerKnob.scad

-60

-80

-100

-140
Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tic