

# CONFIGURATION REFERENCE

---

## Table of contents

This document is under construction.

- [

# CONFIGURATION REFERENCE

](#h1configuration-referenceh1)

- [Main speakers' settings](#)
  - [Front speakers](#)
  - [Fill speakers](#)
  - [Coffee shop speakers](#)
  - [Rhode link settings](#)
- [Streaming](#)
  - [OBS](#)
  - [OSCBridge](#)
  - [Live](#)
- [Hardware](#)
  - [Camera](#)
  - [Baby-room TV](#)
- [Streaming PC](#)

# Main speakers' settings

## Front speakers

- Ch 2 Level at **9 o'clock**
- DSP D-contour **OFF**
- DSP HPF **OFF**
- Gray button **NOT** pressed in



## Fill speakers

- Level at 9 o'clock
- High at 0
- Low at 0



## Coffee shop speakers

- Volume at 9 o'clock
- DSP preset button NOT pressed in



## Rhode link settings

- The receiver (the one on the wall) should be on 0db gain.
- The transmitter (the one with the mic) should be on 10db gain.



## Streaming

### OBS

Todo... \* Disable taskbar peeking in windows, as it messes with the live projectors.

### OSCBridge

Todo... ## Live Todo...

# **Hardware**

## **Camera**

Todo... ## Baby-room TV Todo...

## **Streaming PC**

- Disable “peeking” in performance settings
  - Open Visual Effects Performance Options (SystemPropertiesPerformance.exe)
  - Disable “Enable peek”
  - Reason: live screens might be disturbed during services
- Enable the automatic start of “Windows Time service” so time would be synced always.
  - Reason: the service live stream is timed, and have started at the wrong minute.