

CONFIGURATION REFERENCE

This document is under construction.

- [Main speakers' settings](#)
 - [Front speakers](#)
 - [Fill speakers](#)
 - [Coffee shop speakers](#)
 - [Rhode link settings](#)
- [Streaming](#)
 - [OBS](#)
 - [OSCBridge](#)
 - [Live](#)
- [Hardware](#)
 - [Camera](#)
 - [Baby-room TV](#)

Main speakers' settings

Front speakers

- Ch 2 Level at **9 o'clock**
- DSP D-contour **OFF**
- DSP HPF **OFF**
- Gray button **NOT** pressed in



Fill speakers

- Level at 9 o'clock
- High at 0
- Low at 0



Coffee shop speakers

- Volume at 9 o'clock
- DSP preset button NOT pressed in



Rhode link settings

- The receiver (the one on the wall) should be on 0db gain.
- The transmitter (the one with the mic) should be on 10db gain.



Streaming

OBS

Todo... * Disable taskbar peeking in windows, as it messes with the live projectors.

OSCBridge

Todo... ## Live Todo...

Hardware

Camera

Todo... ## Baby-room TV Todo...