

CONFIGURATION REFERENCE

This document is under construction.

Main speakers' settings

Front speakers

- Ch 2 Level at **9 o'clock**
- DSP D-contour **OFF**
- DSP HPF **OFF**
- Gray button **NOT** pressed in



Fill speakers

- Level at 9 o'clock
- High at 0
- Low at 0



Coffee shop speakers

- Volume at 9 o'clock
- DSP preset button NOT pressed in



Rhode link settings

- The receiver (the one on the wall) should be on 0db gain.
- The transmitter (the one with the mic) should be on 10db gain.



Streaming

OBS

Todo... ## OSCBridge Todo... ## Live Todo...

Hardware

Camera

Todo... ## Babyroom TV Todo...