# Mult MSO C SDK API 使用手册

Version 1.20

微目电子科技

2025-08-12

### 升级记录

V1.20 (2025.8.1)

初始版本(跟随 MSO C SDK 版本)

### 目录

| 1.   | 简介              |                                       | 1 |
|------|-----------------|---------------------------------------|---|
|      | 与 MSO C SDK 的区别 |                                       |   |
|      | 流模式使用           |                                       |   |
|      |                 | 上函数                                   |   |
|      |                 |                                       |   |
|      |                 | <b>殳备插入回调函数</b>                       | 1 |
| 3.3. | 娄               | 数据回调函数                                | 2 |
| 4.   | 流模式 API 说明      |                                       |   |
|      |                 | · · · · · · · · · · · · · · · · · · · |   |
|      | 4.2.            | <del>采</del> 样率                       |   |
|      | 4.3.            | <b>采集</b>                             |   |
|      |                 |                                       |   |
|      | 4.4.            | 采集完成通知                                | 4 |

### 1. 简介

Mult MOS C SDK 是在 MSO C SDK 的基础上增加了多设备支持 API 的标准动态库。该接口支持 widows 系统(X86, X64 和 ARM64)和 linux 系统(X64, ARM32 和 ARM64)。

### 2. 与 MSO C SDK 的区别

设备控制、示波器、DDS 和 IO 的功能 API, 命名和使用方法都跟 MSO C SDK 的相同, 唯一的区别就是增加了,设备 ID 参数 unsigned int dev id。

相比 MSO C SDK,Mult MOS C SDK 增加了流模式功能,该文档主要介绍流模式的 API 和使用方法。

### 3. 流模式使用

流模式需要更快的处理数据,防止数据堆积到内存中,所有流模式仅支持回调函数模式。

```
3.1.主函数
```

```
int main()
   //初始化
   InitDll(1, 1);
   //设置设备和数据回调函数
    SetDevNoticeCallBack(NULL, mDevNoticeAddCallBack,
mDevNoticeRemoveCallBack);
   SetStreamDataReadyCallBack(NULL, mStreamDataReadyCallBack);
  //扫描已经插入的设备
   ScanDevice();
  //主循环
   while (true)
       std::this thread::sleep for(std::chrono::milliseconds(100));
       //采集完成就退出
       if(capture ok)
           break;
   };
   //释放资源
   FinishDll();
   return 0;
3.2.设备插入回调函数
void CALLBACK mDevNoticeAddCallBack(void* ppara, unsigned int dev id)
{
    //DDS 初始化
   DDSInit(dev id, 0, DDS_OUT_MODE_CONTINUOUS);
    //IO 初始化
    IOInit(dev id);
```

```
SetOscCaptureMode(dev id, 1);
    //设置采集范围
    SetStreamChannelRangemV(dev id, 0, -10000, 10000);
    SetStreamChannelRangemV(dev id, 1, -10000, 10000);
    //采样率设置
    int sample num = GetStreamSupportSampleRateNum(dev id);
    if (sample != NULL)
        delete[]sample;
        sample = NULL;
    sample = new unsigned int[sample num];
    //读取支持的采样率
    if (GetStreamSupportSampleRates(dev id, sample, sample num))
        for (int i = 0; i < \text{sample num}; i++)
            std::cout << std::dec << sample[i] << '\n';
        std::cout << std::endl;
    }
    //记录设备和初始化采集状态
    m dev id = dev id;
    capture ok = false;
    capture ok mask = 0;
    //使用 1M 采样率,采集 10M 数据
    uint64 t length = 1024*1024*10; //10M
    StreamCapture(m dev id, length/1024, capture channel mask, 1000000);//1M 采样率
3.3.数据回调函数
void CALLBACK mStreamDataReadyCallBack(void* ppara, unsigned int dev id, unsigned
char channel index, double* buffer, unsigned int buffer length, unsigned int failed, unsigned
int success, unsigned long long int need_total_sample, unsigned long long int total_sample,
unsigned long long int menoryuse)
{
    //Note: The callback function should not handle complex tasks, and if it takes too long,
    //it will cause the watchdog to reset and the USB to reconnect
    /*说明
        buffer 当次的缓冲区,回调完成缓冲区将销毁,所以需要将该缓冲区的数据自
己拷贝走
        buffer length 当次的缓冲区长度
        failed 采集是否失败
```

//选择工作模式

```
success 采集是否完成
need_total_sample 一共需要采集的数据
total_sample 已经采集完成的数据
menoryuse 目前 dll 使用了多少缓冲区(越多,代表 dll 堆积的数据越多)
*/

//根据需求处理 buffer 中数据......

//最后一个通道回调完成,准备退出
if(success)
{
    capture_ok_mask |= (0x01<<<channel_index);
    if(capture_ok_mask==capture_channel_mask)
        capture_ok = true; //标志完成,主函数退出
    }
}
```

### 4. 流模式 API 说明

### 4.1.工作模式

#### int SetOscCaptureMode(unsigned int dev\_id, int is\_stream\_mode);

Description This routines set the osc capture mode.

Input: dev\_id the dev id

is stream mode enable the stream mode or not

Output Return value 1 Success

0 Failed

#### 4.2. 采集范围设置

设备的前级带有程控增益放大器,当采集的信号小于 AD 量程的时候,增益放大器可以把信号放大,更多的利用 AD 的位数,提高采集信号的质量。Dll 会根据设置的采集范围,自动的调整前级的增益放大器。

### int GetStreamRangeMinmV(unsigned int dev\_id);

#### int GetStreamRangeMaxmV(unsigned int dev\_id);

Description This routines set the range of input signal.

Output Return value

minmv the minimum voltage of the input signal (mV) maxmv the maximum voltage of the input signal (mV)

# int SetStreamChannelRangemV(unsigned int dev\_id, int channel, int minmv, int maxmv);

Description This routines set the range of input signal.

Input: channel the set channel

0 channel 11 channel 2

minmv the minimum voltage of the input signal (mV)

maxmv the maximum voltage of the input signal (mV)

Output Return value 1 Success

0 Failed

说明:最大的采集范围为探头 X1 的时候,示波器可以采集的最大电压。比如 MSO20 为 [-12000mV,12000mV]。

注意:为了达到更好波形效果,一定要根据自己被测波形的幅度,设置采集范围。必要时,可以动态变化采集范围。

### 4.3. 采样率

#### int GetStreamSupportSampleRateNum(unsigned int dev\_id);

Description This routines get the number of samples that the equipment support.

Input: -

Output Return value the sample number

# int GetStreamSupportSampleRates(unsigned int dev\_id, unsigned int\* sample, int maxnum);

Description This routines get support samples of equipment.

Input: sample the array store the support samples of the equipment

maxnum the length of the array

Output Return value the sample number of array stored

#### 4.4. 采集

# int StreamCapture(unsigned int dev\_id, unsigned long long int length\_kb, unsigned short capture\_channel, unsigned int sample\_rate);

Description This routines set the capture length and start capture.

Input: length capture length(KB)

capture\_channel: //ch1=0x0001 ch2=0x0020 ch3=0x0040 ch4=0x0080

logic=0x0100

ch1+ch2 0x03 ch1+ch2+ch3 0x07 ch1+ch2+ch3+ch4 0x0F

Output Return 1 success

-1 sample\_rate error-2 device id error

### void StreamStopCapture(unsigned int dev\_id);

Description This routines stop the capture

Input:

Output Return

### 4.5. 采集完成通知

当数据采集完成时,回掉函数会回调通知,并提供相应的采集缓冲区和采集状态。

# Void SetStreamDataReadyCallBack(void\* ppara, StreamDataReadyCallBack datacallback);

Description This routines sets the callback function of capture complete.

Input: **ppara** the parameter of the callback function

datacallback a pointer to a function with the

#### **StreamDataReadyCallBack** prototype:

Output

void CALLBACK StreamDataReadyCallBack(void\* ppara, unsigned int dev\_id, unsigned char channel\_index, double\* buffer, unsigned int buffer\_length, unsigned int failed, unsigned int success, unsigned long long int need\_total\_sample, unsigned long long int total\_sample, unsigned long long int menoryuse);

说明:

buffer 当次的缓冲区,回调完成缓冲区将销毁,所以需要将该缓冲区的数据自己拷贝走

buffer\_length 当次的缓冲区长度
failed 采集是否失败
success 采集是否完成
need\_total\_sample 一共需要采集的数据
total\_sample 已经采集完成的数据
menoryuse 目前动态库使用了多少缓冲区(越多,代表dll堆积的数据越多)