

PJD5126_PJD5226_PJD5226w_ PJD6223_PJD6253_PJD6353_ PJD6353s_PJD6383_PJD6383s_ PJD6553w_PJD6653w_ PJD6653ws_PJD6683w_ PJD6683ws DLP Projector User Guide

IMPORTANT: Please read this User Guide to obtain important information on installing and using your product in a safe manner, as well as registering your product for future service. Warranty information contained in this User Guide will describe your limited coverage from ViewSonic Corporation, which is also found on our web site at http://www.viewsonic.com in English, or in specific languages using the Regional selection box in the upper right corner of our website. "Antes de operar su equipo lea cu idadosamente las instrucciones en este manual"

Model No. VS14295/VS14551/VS14552/VS14191/VS14193 / VS14555/VS14553/VS14195/VS14554/VS14550

Compliance Information

FCC Statement

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

For Canada

- This Class B digital apparatus complies with Canadian ICES-003.
- Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.


CE Conformity for European Countries



The device complies with the EMC Directive 2004/108/EC and Low Voltage Directive 2006/95/EC.

Following information is only for EU-member states:

The mark is in compliance with the Waste Electrical and Electronic Equipment Directive 2002/96/EC (WEEE).





If the batteries, accumulators and button cells included with this equipment, display the chemical symbol Hg, Cd, or Pb, then it means that the battery has a heavy metal content of more than 0.0005% Mercury or more than, 0.002% Cadmium, or more than 0.004% Lead.



Important Safety Instructions

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this unit near water.
- 6. Clean with a soft, dry cloth.
- 7. Do not block any ventilation openings. Install the unit in accordance with the manufacturer's instructions.
- 8. Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade and the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10. Protect the power cord from being walked on or pinched particularly at plugs.

 Convenience receptacles and the point where they exit from the unit. Be sure that the power outlet is located near the unit so that it is easily accessible.
- 11. Only use attachments/accessories specified by the manufacturer.
- 12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the unit. When a cart is used, use caution when moving the cart/unit combination to avoid injury from tipping over.



- 13. Unplug this unit when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as: if the power-supply cord or plug is damaged, if liquid is spilled onto or objects fall into the unit, if the unit is exposed to rain or moisture, or if the unit does not operate normally or has been dropped.

Declaration of RoHS Compliance

This product has been designed and manufactured in compliance with Directive 2002/95/EC of the European Parliament and the Council on restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS Directive) and is deemed to comply with the maximum concentration values issued by the European Technical Adaptation Committee (TAC) as shown below:

Substance	Proposed Maximum Concentration	Actual Concentration
Lead (Pb)	0.1%	< 0.1%
Mercury (Hg)	0.1%	< 0.1%
Cadmium (Cd)	0.01%	< 0.01%
Hexavalent Chromium (Cr ⁶⁺)	0.1%	< 0.1%
Polybrominated biphenyls (PBB)	0.1%	< 0.1%
Polybrominated diphenyl ethers (PBDE)	0.1%	< 0.1%

Certain components of products as stated above are exempted under the Annex of the RoHS Directives as noted below:

Examples of exempted components are:

- 1. Mercury in compact fluorescent lamps not exceeding 5 mg per lamp and in other lamps not specifically mentioned in the Annex of RoHS Directive.
- 2. Lead in glass of cathode ray tubes, electronic components, fluorescent tubes, and electronic ceramic parts (e.g. piezoelectronic devices).
- 3. Lead in high temperature type solders (i.e. lead-based alloys containing 85% by weight or more lead).
- 4. Lead as an allotting element in steel containing up to 0.35% lead by weight, aluminium containing up to 0.4% lead by weight and as a cooper alloy containing up to 4% lead by weight.

Copyright Information

Copyright© ViewSonic® Corporation, 2012. All rights reserved.

Macintosh and Power Macintosh are registered trademarks of Apple Inc.

Microsoft, Windows, Windows NT, and the Windows logo are registered trademarks of Microsoft Corporation in the United States and other countries.

ViewSonic, the three birds logo, OnView, ViewMatch, and ViewMeter are registered trademarks of ViewSonic Corporation.

VESA is a registered trademark of the Video Electronics Standards Association. DPMS and DDC are trademarks of VESA.

PS/2, VGA and XGA are registered trademarks of International Business Machines Corporation. Disclaimer: ViewSonic Corporation shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from furnishing this material, or the performance or use of this product.

In the interest of continuing product improvement, ViewSonic Corporation reserves the right to change product specifications without notice. Information in this document may change without notice. No part of this document may be copied, reproduced, or transmitted by any means, for any purpose without prior written permission from ViewSonic Corporation.

Product Registration

To meet your future needs, and to receive any additional product information as it becomes available, please register your product on the Internet at: www.viewsonic.com. The ViewSonic[®] Wizard DVD-ROM also provides an opportunity for you to print the registration form, which you may mail or fax to ViewSonic.

For Your Records

Product Name: PJD5126_PJD5226_PJD5226w_PJD6223_PJD6253_PJD6353_PJD6353s_

PJD6383_PJD6383s_PJD6553w_PJD6653w_PJD6653ws_PJD6683ws

ViewSonic DLP Projector

Model Number: VS14295/VS14551/VS14552/VS14191/VS14193/ VS14555/VS14553/VS14195/

VS14554/VS14550

Document Number: PJD5126/PJD5226/PJD5226w/PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383/

PJD6383s/PJD6553w/PJD6653w/PJD6653ws/PJD6683ws_UG_ENG

Rev. 1C 04-25-12

Serial Number:

Purchase Date:

Product disposal at end of product life

The lamp in this product contains mercury which can be dangerous to you and the environment. Please use care and dispose of in accordance with local, state or federal laws.

ViewSonic respects the environment and is committed to working and living green. Thank you for being part of Smarter, Greener Computing. Please visit ViewSonic website to learn more.

USA & Canada: http://www.viewsonic.com/company/green/recycle-program/

Europe: http://www.viewsoniceurope.com/uk/kbase/article.php?id=639

Taiwan: http://recycle.epa.gov.tw/recycle/index2.aspx

Table of contents

Important safety
instructions2
Introduction4
Projector features4
Shipping contents5
Projector exterior view6
Controls and functions7
Positioning your
projector12
Choosing a location
Projection dimensions
Connection17
Connecting a computer or monitor 18
Connecting Video source devices 19
Operation22
Starting up the projector22
Using the menus
Utilizing the password function24
Cumzing the password rametion21
Switching input signal
Switching input signal27
Switching input signal

Controlling the projector through	
a LAN environment	39
Using the projector in standby mode	. 45
Shutting down the projector	45
Menu operation	46
Maintenance	.56
Care of the projector	56
Lamp information	
Troubleshooting	.63
Specifications	.64
Projector specifications	64
Dimensions	66
Ceiling mount installation	66
Timing chart	67
Copyright information	.69
Appendix	.70
IR control table	70
RJ45 response table	72
RS232 command table	

Important safety instructions

Your projector is designed and tested to meet the latest standards for safety of information technology equipment. However, to ensure safe use of this product, it is important that you follow the instructions mentioned in this manual and marked on the product.

Safety Instructions

- 1. **Please read this manual before you operate your projector.** Save it for future reference.
- 2. **Do not look straight at the projector lens during operation.** The intense light beam may damage your eyes.
- 3. Refer servicing to qualified service personnel.
- 4. Always open the lens shutter or remove the lens cap when the projector lamp is on.
- 5. In some countries, the line voltage is NOT stable. This projector is designed to operate safely within a mains voltage between 100 to 240 volts AC, but could fail if power cuts or surges of ± 10 volts occur. In areas where the mains voltage may fluctuate or cut out, it is recommended that you connect your projector through a power stabilizer, surge protector or uninterruptible power supply (UPS).
- 6. Do not block the projection lens with any objects when the projector is under operation as this could cause the objects to become heated and deformed or even cause a fire. To temporarily turn off the lamp, press BLANK on the projector or remote control.
- 7. The lamp becomes extremely hot during operation. Allow the projector to cool for approximately 45 minutes prior to removing the lamp assembly for replacement.
- 8. Do not operate lamps beyond the rated lamp life. Excessive operation of lamps beyond the rated life could cause them to break on rare occasions.
- 9. Never replace the lamp assembly or any electronic components unless the projector is unplugged.
- 10. Do not place this product on an unstable cart, stand, or table. The product may fall, sustaining serious damage.
- 11. Do not attempt to disassemble this projector. There are dangerous high voltages inside which may cause death if you should come into contact with live parts. The only user serviceable part is the lamp which has its own removable cover.
 - Under no circumstances should you ever undo or remove any other covers. Refer servicing only to suitably qualified professional service personnel.
- 12. Do not place this projector in any of the following environments.
 - Space that is poorly ventilated or confined. Allow at least 50 cm clearance from walls and free flow of air around the projector.
 - Locations where temperatures may become excessively high, such as the inside of a car with all windows rolled up.
 - Locations where excessive humidity, dust, or cigarette smoke may contaminate optical components, shortening the projector's life span and darkening the picture.
 - Locations near fire alarms
 - Locations with an ambient temperature above 40°C / 104°F
 - Locations where the altitudes are higher than 3000 m (10000 feet).

- 13. Do not block the ventilation holes. If the ventilation holes are seriously obstructed, overheating inside the projector may result in a fire.
 - Do not place this projector on a blanket, bedding or any other soft surface.
 - Do not cover this projector with a cloth or any other item.
 - Do not place inflammables near the projector.
- 14. Always place the projector on a level, horizontal surface during operation.
 - Do not use if tilted at an angle of more than 10 degrees left to right, nor at angle of more than 15 degrees front to back. Using the projector when it is not fully horizontal may cause a malfunction of, or damage to, the lamp.
- 15. Do not stand the projector on end vertically. Doing so may cause the projector to fall over, causing injury or resulting in damage to the projector.
- 16. Do not step on the projector or place any objects upon it. Besides probable physical damage to the projector, doing so may result in accidents and possible injury.
- 17. Do not place liquids near or on the projector. Liquids spilled into the projector may cause it to fail. If the projector does become wet, disconnect it from the power supply's wall socket and call your local service center to have the projector serviced.
- 18. This product is capable of displaying inverted pictures for ceiling mount installation.
- Use only qualified ceiling mount kit for mounting the projector and ensure it is securely installed.
- 19. When the projector is under operation, you may sense some heated air and odor from its ventilation grill. It is a normal phenomenon and not a product defect.
- 20. Do not use the Security bar for transporting or installation. It should be used with a commercially available theft prevention cable.

Safety instructions for ceiling mounting of the projector

We want you to have a pleasant experience using your projector, so we need to bring this safety matter to your attention to prevent damage to person and property.

If you intend to mount your projector on the ceiling, we strongly recommend that you use a proper fitting projector ceiling mount kit and that you ensure it is securely and safely installed.

If you use an inappropriate projector ceiling mount kit, there is a safety risk that the projector may fall from the ceiling due to an improper attachment through the use of the wrong gauge or length screws.

You can purchase a projector ceiling mount kit from the place you purchased your projector. We recommends that you also purchase a separate Kensington lock compatible security cable and attach it securely to both the Kensington lock slot on the projector and the base of the ceiling mount bracket. This will perform the secondary role of restraining the projector should its attachment to the mounting bracket become loose.


Introduction

Projector features

The projector integrates high-performance optical engine projection and a user-friendly design to deliver high reliability and ease of use.

The projector offers the following features.

- Dynamic PC and Dynamic Movie function adjusting the power consumption of the lamp according to the brightness of the image being projected
- DynamicEco Timer function decreasing the power consumption of the lamp by up to 70% when no input signal can be detected for a set period of time.
- Presentation timer for better control of time during presentations
- Support 3D DLP Link
- Color management allowing color adjustments to your liking
- · Less than 1W power consumption when power saving mode is turned on
- Screen Color correction allowing projection on surfaces of several predefined colors
- Quick auto search speeding up the signal detecting process
- Up to 10 sets of picture modes providing multiple choices for different projection purposes
- Selectable quick power off function
- One-key auto-adjustment to display the best picture quality
- Digital keystone correction to correct distorted images
- Adjustable color balance control for data/video display
- High brightness projection lamp
- Ability to display 1.07 billion colors
- Multi-language On-Screen Display (OSD) menus
- Switchable normal and economic modes to reduce the power consumption
- Component HDTV compatibility (YPbPr)




 The lamp brightness will decline over time and may vary within the lamp manufacturers specifications. This is normal and expected behavior.

Shipping contents

Carefully unpack and verify that you have all of the items shown below. If any of these items are missing, please contact your place of purchase.

Standard accessories

The supplied accessories will be suitable for your region, and may differ from those illustrated.




Optional accessories

- 1. Replacement lamp
- 2. Soft carry case
- 3. VGA-Component adapter


Projector exterior view

Front/upper side

PJD5126/PJD5226/PJD5226w/ PJD6223/PJD6253/PJD6553w




PJD6353/PJD6353s/PJD6383/PJD6383s PJD6653w/PJD6653ws/PJD6683w PJD6683ws




Rear/lower side

PJD5126/PJD5226/PJD5226w



PJD6223/PJD6253/PJD6353/PJD6353s/PJD638 PJD6383s/PJD6653w/PJD6653ws/PJD6553w/ PJD6683w/PJD6683ws



- **Warning**
- THIS APPARATUS MUST BE EARTHED.
- When installing the unit, incorporate a readily accessible disconnect device in the fixed wiring, or connect the power plug to an easily accessible socket-outlet near the unit. If a fault should occur during operation of the unit, operate the disconnect device to switch the power supply off, or disconnect the power plug.


- 1. External control panel (See "Projector" on page 7 for details.)
- 2. Lamp cover
- 3. Vent (heated air exhaust)
- 4. Quick-release button
- 5. Focus and Zoom ring
- 6. Front IR remote sensor
- 7. Projection lens
- 8. Type B USB port
- 9. RJ45 LAN input port
- 10. RS-232 control port
- 11. HDMI port
- 12. RGB signal output socket
- 13. RGB (PC)/Component video (YPbPr/YCbCr) signal input socket-1/2
- 14. S-Video input socket
- 15. Video input socket
- 16. Audio signal input socket Audio signal output socket
- 17. Kensington anti-theft lock slot
- 18. AC power cord inlet
- 19. Rear adjuster foot
- 20. Ouick-release foot
- 21. Security bar

Connects a commercially available theft prevention cable.

Controls and functions

Projector

PJD5126/PJD5226/PJD5226w/ PJD6223/PJD6253/PJD6553w



1. Focus ring

Adjusts the focus of the projected image.

2. Zoom ring

Adjusts the size of the image.

3. Keystone/Arrow keys (▼ / ^ Up, ▲ / ∨ Down)

Manually corrects distorted images resulting from an angled projection.

4. < Left/Blank

Hides the screen picture.

5. POWER indicator light

Lights up or flashes when the projector is under operation.

() POWER

Toggles the projector between standby mode and on.

6. SOURCE

Displays the source selection bar.


7. Top IR remote sensor

Not available for the PJD5126/PJD5226/PJD5226w.

8. MENU/EXIT

Turns on the On-Screen Display (OSD) menu. Goes back to previous OSD menu, exits and saves menu settings.

PJD6353/PJD6353s/PJD6383/PJD6383s/ PJD6653w/PJD6653ws/PJD6683w/PJD6683ws



9. Right

Activates panel key lock.

When the On-Screen Display (OSD) menu is activated, the #3, #4, and #9 keys are used as directional arrows to select the desired menu items and to make adjustments.

10. LAMP indicator light

Indicates the status of the lamp. Lights up or flashes when the lamp has developed a problem.

11. AUTO

Automatically determines the best picture timings for the displayed image.

12. TEMPerature indicator light

Lights up red if the projector's temperature becomes too high.


13. MODE/ENTER


Selects an available picture setup mode. Enacts the selected On-Screen Display (OSD) menu item.

Remote control

PJD5126/PJD5226/PJD5226w/ PJD6223/PJD6353/PJD6353s PJD6653w/PJD6653ws

PJD6253/PJD6383/PJD6383s/ PJD6553w/PJD6683w PJD6683ws





1. (†) POWER

Toggles the projector between standby mode and on.

2. Source selection keys (VGA 1/VGA 2/Video)

Selects an input source for display.

Video/


Selects **Video**, **S-Video** or **HDMI** source for display.

Performs the same function as the right mouse button when the mouse mode is activated.

3. Source

Displays the source selection bar.

Manually corrects distorted images resulting from an angled projection.



5. </^/>/>

Selects the desired menu items and makes adjustments.

6. Enter/

Enacts the selected On-Screen Display (OSD) menu item.

Performs the same function as the left mouse button when the mouse mode is activated.

7. My Button

Allows user to define a short cut key on the remote control, and the function item is selected in OSD menu.

8. Menu

Turns on the On-Screen Display (OSD) menu.

9. Mouse

Switches between the normal and mouse modes.

Page Up, Page Down, . : active after pressing Mouse. An icon appears on the screen to indicate the activation of the mouse mode.

10. Lock

Activates or deactivates panel key lock.

11. Aspect

Selects the display aspect ratio.

12. Magnify

Displays the zoom bar that magnifies or reduces the projected picture size.

13. Info

Displays the INFORMATION menu.

14. Freeze

Freezes the projected image.

15. Pattern

Displays embedded test pattern.

16. Blank

Hides the screen picture.

17. DynamicEcoTM

Decreases the power consumption of the lamp by up to 70%.



It takes some time to initiate this function. Make sure the projector has been turned on for more than 4 minutes.

If the projector is resumed by using the Smart Restart feature, this function can be executed immediately.

18. Auto Sync

Automatically determines the best picture timings for the displayed image.

19. Exit

Goes back to previous OSD menu, exits and saves menu settings.

20. PgUp (Page Up)/PgDn (Page Down)

Operates your display software program (on a connected PC) which responds to page up/down commands (like Microsoft PowerPoint) when the mouse mode is activated.

21. Volume keys (+, -)

Magnifies or reduces the volume level.

22.

Toggles the projector audio between on and off.

23. Color Mode

Selects an available picture setup mode.

24. Timer

Displays the presentation timer settings menu.

25. Laser

Emits visible laser pointer light for presentation purposes.

Operating the Laser pointer

The Laser Pointer is a presentation aid for professionals. It emits red colored light when you press it and the indicator lights up red.



The laser beam is visible. It is necessary to press and hold **LASER** for continuous output.

The laser pointer is not a toy. Parents should be mindful of the dangers of laser energy and keep this remote control out of the reach of children.



Do not look into the laser light window or shine the laser light beam on yourself or others. See the warning messages on the back of the remote control prior to using it.

Remote control code

The projector can be assigned to two different remote control codes, A or B. When several adjacent projectors are in operation at the same time, switching the remote control codes can prevent interference from other remote controls. Set the remote control code for the projector first before changing that for the remote control.

To switch the code for the projector, select **A** or **B** in the **SYSTEM SETUP: Advanced** > **Remote Control Code** menu.

To switch the code for the remote control, press **PgUp** and **PgDn** buttons on the remote control together for 5 seconds or more. The initial code is set to A.

If different codes are set on the projector and remote control, there will be no response from the remote control. When that happens, switch the code for the remote control again.

Using the remote mouse control

The capability of operating your computer with the remote control gives you more flexibility when delivering presentations.


- 1. Connect the projector to your PC or notebook with a USB cable prior to using the remote control in place of your computer's mouse. See "Connecting a computer" on page 18 for details.
- 2. Set the input signal to **D-Sub / Comp. 1**, **D-Sub / Comp. 2** or **HDMI**.
- 3. Press **Mouse** on the remote control to switch from the normal mode to the mouse mode. An icon appears on the screen to indicate the activation of the mouse mode.
- 4. Perform the desired mouse controls on your remote control.
 - To move the cursor on the screen, press $\langle / \wedge / \vee / \rangle$.
 - To left-click, press ■.
 - To right-click, press 🖰.
 - To operate your display software program (on a connected PC) which responds to page up/down commands (like Microsoft PowerPoint), press **PgUp/PgDn**.
 - To return to the normal mode, press **Mouse** again or other keys except for the mouse related multi-function keys.

Remote control effective range


Infra-Red (IR) remote control sensors are located on the front and the top of the projector. The remote control must be held at an angle within 30 degrees perpendicular to the projector's IR remote control sensors to function correctly. The distance between the remote control and the sensors should not exceed 8 meters (~ 26 feet).

Make sure that there are no obstacles between the remote control and the IR sensors on the projector that might obstruct the infra-red beam.

 Operating the projector from the front




Operating the projector from the top



Replacing the remote control batteries

- 1. To open the battery cover, turn the remote control over to view its back, push on the finger grip on the cover and slide it in the direction of the arrow as illustrated. The cover will slide off.
- 2. Remove any existing batteries (if necessary) and install two AAA batteries observing the battery polarities as indicated in the base of the battery compartment. Positive (+) goes to positive and negative (-) goes to negative.
- 3. Refit the cover by aligning it with the base and sliding it back down into position. Stop when it clicks into place.





- Avoid leaving the remote control and batteries in an excessive heat or humid environment like the kitchen, bathroom, sauna, sunroom or in a closed car.
- · Replace only with the same or equivalent type recommended by the battery manufacturer.
- Dispose of the used batteries according to the manufacturer's instructions and local environment regulations for your region.
- Never throw the batteries into a fire. There may be danger of an explosion.
- If the batteries are dead or if you will not be using the remote control for an extended period of time, remove the batteries to avoid damage to the remote control from possible battery leakage.

Positioning your projector


Choosing a location

Your room layout or personal preference will dictate which installation location you select. Take into consideration the size and position of your screen, the location of a suitable power outlet, as well as the location and distance between the projector and the rest of your equipment.

Your projector is designed to be installed in one of four possible installation locations:

1. Front Table

Select this location with the projector placed near the floor in front of the screen. This is the most common way to position the projector for quick setup and portability.




2. Front Ceiling

Select this location with the projector suspended upside-down from the ceiling in front of the screen.

Purchase the projector ceiling mount kit from your dealer to mount your projector on the ceiling.

Set Front Ceiling in the SYSTEM SETUP: Basic > Projector Position menu after you turn the projector on.




3. Rear Ceiling

Select this location with the projector suspended upside-down from the ceiling behind the screen.

Note that a special rear projection screen and the projector ceiling mounting kit are required for this installation location.

Set **Rear Ceiling** in the **SYSTEM SETUP: Basic** > **Projector Position** menu after you turn the projector on.




4. Rear Table

Select this location with the projector placed near the floor behind the screen.

Note that a special rear projection screen is required.

Set Rear Table in the SYSTEM SETUP: Basic > Projector Position menu after you turn the projector on.




Projection dimensions


Refer to "Dimensions" on page 66 for the center of lens dimensions of this projector before calculating the appropriate position.

The "screen" mentioned below refers to the projection screen usually consisting of a surface and a support structure


PJD5126/PJD5226/PJD6223/PJD6253/PJD6353/ PJD6353s/PJD6383/PJD6383s


• 4:3 image on a 4:3 screen





• 16:9 image on a 4:3 screen





PJD5126/PJD5226/PJD6223

(a) C.			4	:3 im	age or	a 4:3	Scree	en		16:9 image on a 4:3 Screen								
) Si	(b) Projection Size (nch (m)] (b) Projection (distance [m (inch)]		(c) Image (d) Vertical height offset		(b) F	Projecti [m (i		tance	(c) Image height		(d) Vertical offset							
	` /1	m	in.	m	ax.	[cm (inch)]	[cm	(inch)]	n	nin.	m	ах.	[cm (inch)		[cm ((inch)]	
30	(8.0)	1.1	(45)	1.3	(49)	46	(18)	2	(0.9)	1.1	(45)	1.3	(49	34	(14)	8.0	(3.2)	
40	(1.0)	1.5	(60)	1.7	(66)	61	(24)	3	(1.2)	1.5	(60)	1.7	(66)	46	(18)	10.7	(4.2)	
50	(1.3)	1.9	(75)	2.1	(82)	76	(30)	4	(1.5)	1.9	(75)	2.1	(82)	57	(23)	13.3	(5.3)	
60	(1.5)	2.3	(90)	2.5	(99)	91	(36)	5	(1.8)	2.3	(90)	2.5	(99)	69	(27)	16.0	(6.3)	
70	(1.8)	2.7	(105)	2.9	(115)	107	(42)	5	(2.1)	2.7	(105)	2.9	(115)	80	(32)	18.7	(7.4)	
80	(2.0)	3.0	(120)	3.4	(132)	122	(48)	6	(2.4)	3.0	(120)	3.4	(132)	91	(36)	21.3	(8.4)	
90	(2.3)	3.4	(135)	3.8	(148)	137	(54)	7	(2.7)	3.4	(135)	3.8	(148)	103	(41)	24.0	(9.5)	
100	(2.5)	3.8	(150)	4.2	(165)	152	(60)	8	(3.0)	3.8	(150)	4.2	(165)	114	(45)	26.7	(10.5)	
120	(3.0)	4.6	(180)	5.0	(198)	183	(72)	9	(3.6)	4.6	(180)	5.0	(198)	137	(54)	32.0	(12.6)	
150	(3.8)	5.7	(225)	6.3	(247)	229	(90)	11	(4.5)	5.7	(225)	6.3	(247)	171	(68)	40.0	(15.8)	
200	(5.1)	7.6	(300)	8.4	(330)	305	(120)	15	(6.0)	7.6	(300)	8.4	(330)	229	(90)	53.3	(21.0)	
250	(6.4)	9.51	(375)	10.5	(412)	381	(150)	19	(7.5)	9.51	(375)	10.5	(412)	286	(113)	66.7	(26.3)	
300	(7.6)	11.4	(450)	12.6	(495)	457	(180)	23	(9.0)	11.4	(450)	12.6	(495)	343	(135)	80.0	(31.5)	

PJD6253


(,)0			4	4:3 im	nage o	n a 4:	3 Scre	en		16:9 image on a 4:3 Screen								
`´Si	ze (m)]	(b) Projection distance [m (inch)]		(c) Image (d) Vertical height offset				(b)	Project [m (ion di inch)]		1 ` ′	mage ight	(d) Vertical offset				
L	. ()1	n	nin.	m	ах.	[cm (inch)]	[cm (inch)]		n	min.		ах.	[cm (inch)		[cm (inch)]		
30	(8.0)	0.9	(36)	1.2	(47)	46	(18)	3	(1.4)	0.9	(36)	1.2	(47)	34	(14)	9.1	(3.6)	
40	(1.0)	1.2	(48)	1.6	(63)	61	(24)	5	(1.8)	1.2	(48)	1.6	(63)	46	(18)	12.2	(4.8)	
50	(1.3)	1.5	(61)	2.0	(79)	76	(30)	6	(2.3)	1.5	(61)	2.0	(79)	57	(23)	15.2	(6.0)	
60	(1.5)	1.8	(73)	2.4	(94)	91	(36)	7	(2.7)	1.8	(73)	2.4	(94)	69	(27)	18.3	(7.2)	
70	(1.8)	2.2	(85)	2.8	(110)	107	(42)	8	(3.2)	2.2	(85)	2.8	(110)	80	(32)	21.3	(8.4)	
80	(2.0)	2.5	(97)	3.2	(126)	122	(48)	9	(3.6)	2.5	(97)	3.2	(126)	91	(36)	24.4	(9.6)	
90	(2.3)	2.8	(109)	3.6	(142)	137	(54)	10	(4.1)	2.8	(109)	3.6	(142)	103	(41)	27.4	(10.8)	
100	(2.5)	3.1	(121)	4.0	(157)	152	(60)	11	(4.5)	3.1	(121)	4.0	(157)	114	(45)	30.5	(12.0)	
120	(3.0)	3.7	(145)	4.8	(189)	183	(72)	14	(5.4)	3.7	(145)	4.8	(189)	137	(54)	36.6	(14.4)	
150	(3.8)	4.6	(182)	6.0	(236)	229	(90)	17	(6.8)	4.6	(182)	6.0	(236)	171	(68)	45.7	(18.0)	
200	(5.1)	6.2	(242)	8.0	(315)	305	(120)	23	(9.0)	6.2	(242)	8.0	(315)	229	(90)	61.0	(24.0)	
250	(6.4)	7.7	(303)	10.0	(394)	381	(150)	29	(11.3)	7.7	(303)	10.0	(394)	286	(113)	76.2	(30.0)	
300	(7.6)	9.2	(363)	12.0	(472)	457	(180)	34	(13.5)	9.2	(363)	12.0	(472)	343	(135)	91.4	(36.0)	


PJD6353/PJD6353s/PJD6383/PJD6383s

(2) S	creen		4:3 image	e on a 4	1:3 Scre	en			16:9 image	on a	4:3 Sc	reen	
) Si	ize n (m)]		rojection e [m (inch)]	he	mage ight [inch)]) o	/ertical ffset (inch)]	. , ,	(b) Projection distance [m (inch)]		(c) Image height [cm (inch)		ertical set inch)]
30	(8.0)	0.4	(15)	46	(18)	7	(2.7)	0.4	(15)	34	(14)	12.6	(5.0)
40	(1.0)	0.5	(19)	61	(24)	9	(3.6)	0.5	(19)	46	(18)	16.8	(6.6)
50	(1.3)	0.6	(24)	76	(30)	11	(4.5)	0.6	(24)	57	(23)	21.0	(8.3)
60	(1.5)	0.7	(29)	91	(36)	14	(5.4)	0.7	(29)	69	(27)	25.1	(9.9)
70	(1.8)	0.9	(34)	107	(42)	16	(6.3)	0.9	(34)	80	(32)	29.3	(11.6)
80	(2.0)	1.0	(39)	122	(48)	18	(7.2)	1.0	(39)	91	(36)	33.5	(13.2)
90	(2.3)	1.1	(44)	137	(54)	21	(8.1)	1.1	(44)	103	(41)	37.7	(14.9)
100	(2.5)	1.2	(49)	152	(60)	23	(9.0)	1.2	(49)	114	(45)	41.9	(16.5)
120	(3.0)	1.5	(58)	183	(72)	27	(10.8)	1.5	(58)	137	(54)	50.3	(19.8)
150	(3.8)	1.9	(73)	229	(90)	34	(13.5)	1.9	(73)	171	(68)	62.9	(24.8)
200	(5.1)	2.5	(97)	305	(120)	46	(18.0)	2.5	(97)	229	(90)	83.8	(33.0)
250	(6.4)	3.1	(122)	381	(150)	57	(22.5)	3.1	(122)	286	(113)	104.8	(41.3)
300	(7.6)	3.7	(146)	457	(180)	69	(27.0)	3.7	(146)	343	(135)	125.7	(49.5)


PJD5226w/PJD6553w/PJD6653ws/PJD6683ws/PJD6683ws/


• 16:10 image on a 16:10 screen





• 16:10 image on a 4:3 screen





(e): Screen

(f): Center of lens

PJD5226w

(.) 0			16:	10 ima	age on	a 16:	10 Scr	een			1	6:10 ir	nage o	n a 4:	3 Scree	en	
) Si	(a) Screen Size [inch (m)] (b) Projection distance [m (inch)]					mage ight	of	ertical		-	tion dis	stance		mage ight	(d) Vertical offset		
_	(/1	m	in.	ma	ax.	[cm (inch)]		[cm (inch)]		min.		max.		[cm (inch)		[cm ((inch)]
30	(8.0)	0.97	(38)	1.06	(42)	40	(16)	0	(0.0)	0.91	(36)	1.00	(40)	38	(15)	3.8	(1.5)
40	(1.0)	1.29	(51)	1.42	(56)	54	(21)	0	(0.0)	1.22	(48)	1.34	(53)	51	(20)	5.1	(2.0)
50	(1.3)	1.61	(64)	1.77	(70)	67	(26)	0	(0.0)	1.52	(60)	1.67	(66)	64	(25)	6.4	(2.5)
60	(1.5)	1.94	(76)	2.13	(84)	81	(32)	0	(0.0)	1.83	(72)	2.01	(79)	76	(30)	7.6	(3.0)
70	(1.8)	2.26	(89)	2.48	(98)	94	(37)	0	(0.0)	2.13	(84)	2.34	(92)	89	(35)	8.9	(3.5)
80	(2.0)	2.58	(102)	2.84	(112)	108	(42)	0	(0.0)	2.43	(96)	2.68	(105)	102	(40)	10.2	(4.5)
90	(2.3)	2.90	(114)	3.19	(126)	121	(48)	0	(0.0)	2.74	(108)	3.01	(119)	114	(45)	11.4	(4.5)
100	(2.5)	3.23	(127)	3.55	(140)	135	(53)	0	(0.0)	3.04	(120)	3.35	(132)	127	(50)	12.7	(5.0)
120	(3.0)	3.87	(152)	4.26	(168)	162	(64)	0	(0.0)	3.65	(144)	4.02	(158)	152	(60)	15.2	(6.0)
150	(3.8)	4.84	(191)	5.32	(210)	202	(79)	0	(0.0)	4.56	(180)	5.02	(198)	191	(75)	19.1	(7.5)
200	(5.1)	6.45	(254)	7.10	(279)	269	(106)	0	(0.0)	6.09	(240)	6.70	(264)	254	(100)	25.4	(10.0)
250	(6.4)	8.06	(318)	8.87	(349)	337	(132)	0	(0.0)	7.61	(300)	8.37	(329)	318	(125)	31.8	(12.5)
300	(7.6)	9.68	(381)	10.65	(419)	404	(159)	0	(0.0)	9.13	(359)	10.04	(395)	381	(150)	38.1	(15.0)

PJD6553w

() 0			16:	10 ima	age on	a 16:	10 Scre	een			1	6:10 iı	mage o	n a 4:	3 Scree	en	
`´Si.	(b) Projection distance [m (inch)]					mage ight	· /	(d) Vertical offset		,	tion di (inch)]	stance		(c) Image height		(d) Vertical offset	
_	(/1	m	nin.	ma	ax.	[cm (inch)]		[cm (inch)]		min.		max.		[cm (inch)		[cm (inch)]	
30	(8.0)	0.78	(31)	1.02	(40)	40	(16)	1	(0.4)	0.74	(36)	0.96	(38)	38	(15)	3.8	(1.5)
40	(1.0)	1.05	(41)	1.36	(54)	54	(21)	1	(0.5)	0.99	(48)	1.28	(50)	51	(20)	5.1	(2.0)
50	(1.3)	1.31	(51)	1.70	(67)	67	(26)	2	(0.7)	1.23	(61)	1.60	(63)	64	(25)	6.4	(2.5)
60	(1.5)	1.57	(62)	2.04	(80)	81	(32)	2	(8.0)	1.48	(73)	1.92	(76)	76	(30)	7.6	(3.0)
70	(1.8)	1.83	(72)	2.38	(94)	94	(37)	2	(0.9)	1.73	(85)	2.24	(88)	89	(35)	8.9	(3.5)
80	(2.0)	2.09	(82)	2.72	(107)	108	(42)	3	(1.1)	1.97	(97)	2.57	(101)	102	(40)	10.2	(4.5)
90	(2.3)	2.35	(93)	3.06	(120)	121	(48)	3	(1.2)	2.22	(109)	2.89	(114)	114	(45)	11.4	(4.5)
100	(2.5)	2.61	(103)	3.40	(134)	135	(53)	3	(1.3)	2.47	(121)	3.21	(126)	127	(50)	12.7	(5.0)
120	(3.0)	3.14	(124)	4.08	(161)	162	(64)	4	(1.6)	2.96	(145)	3.85	(151)	152	(60)	15.2	(6.0)
150	(3.8)	3.92	(154)	5.10	(201)	202	(79)	5	(2.0)	3.70	(182)	4.81	(189)	191	(75)	19.1	(7.5)
200	(5.1)	5.23	(206)	6.80	(268)	269	(106)	7	(2.6)	4.93	(242)	6.41	(252)	254	(100)	25.4	(10.0)
250	(6.4)	6.54	(257)	8.50	(335)	337	(132)	8	(3.3)	6.17	(303)	8.02	(316)	318	(125)	31.8	(12.5)
300	(7.6)	7.84	(309)	10.20	(401)	404	(159)	10	(4.0)	7.40	(363)	9.62	(379)	381	(150)	38.1	(15.0)

PJD6653w/PJD6653ws/PJD6683w/PJD6683ws


(2) \$	creen	1	16:10 image	e on a 1	16:10 Sc	reen		16:10 image on a 4:3 Screen							
Si	ize n (m)]	(b) Projection distance [m (inch)]		(c) Image height [cm (inch)]		(d) Vertical offset [cm (inch)]		(b) Projection distance [m (inch)]		he	mage ight (inch)	(d) Vertical offset [cm (inch)]			
30	(8.0)	0.32	(12)	40	(16)	2	(8.0)	0.30	(12)	38	(15)	3.8	(1.5)		
40	(1.0)	0.42	(17)	54	(21)	3	(1.1)	0.40	(16)	51	(20)	5.1	(2.0)		
50	(1.3)	0.53	(21)	67	(26)	3	(1.3)	0.50	(20)	64	(25)	6.4	(2.5)		
60	(1.5)	0.63	(25)	81	(32)	4	(1.6)	0.60	(23)	76	(30)	7.6	(3.0)		
70	(1.8)	0.74	(29)	94	(37)	5	(1.9)	0.70	(27)	89	(35)	8.9	(3.5)		
80	(2.0)	0.84	(33)	108	(42)	5	(2.1)	0.79	(31)	102	(40)	10.2	(4.0)		
90	(2.3)	0.95	(37)	121	(48)	6	(2.4)	0.89	(35)	114	(45)	11.4	(4.5)		
100	(2.5)	1.05	(41)	135	(53)	7	(2.6)	0.99	(39)	127	(50)	12.7	(5.0)		
120	(3.0)	1.26	(50)	162	(64)	8	(3.2)	1.19	(47)	152	(60)	15.2	(6.0)		
150	(3.8)	1.58	(62)	202	(79)	10	(4.0)	1.49	(59)	191	(75)	19.1	(7.5)		
200	(5.1)	2.11	(83)	269	(106)	13	(5.3)	1.99	(78)	254	(100)	25.4	(10.0)		
250	(6.4)	2.63	(104)	337	(132)	17	(6.6)	2.48	(98)	318	(125)	31.8	(12.5)		
300	(7.6)	3.16	(124)	404	(159)	20	(7.9)	2.98	(117)	381	(150)	38.1	(15.0)		

There is 3% tolerance among these numbers due to optical component variations. It is recommended that if you intend to permanently install the projector, you should physically test the projection size and distance using the actual projector in situ before you permanently install it, so as to make allowance for this projector's optical characteristics. This will help you determine the exact mounting position so that it best suits your installation location.

Connection

When connecting a signal source to the projector, be sure to:

- 1. Turn all equipment off before making any connections.
- 2. Use the correct signal cables for each source.
- 3. Ensure the cables are firmly inserted.
- In the connections shown below, some cables may not be included with the projector (see "Shipping contents" on page 5). They are commercially available from electronics stores.
 - The connection illustrations below are for reference only. The rear connecting jacks available on the projector vary with each projector model.
 - For detailed connection methods, see pages 18-21.



- 1. VGA cable
- 2. VGA to DVI-A cable
- 3. USB cable
- 4. Component Video to VGA (D-Sub) adapter cable
- 5. S-Video cable
- 6. Video cable
- 7. Audio cable
- 8. HDMI cable

Connecting a computer or monitor

Connecting a computer

The projector provides two VGA input sockets that allow you to connect them to both IBM® compatibles and Macintosh® computers. A Mac adapter is needed if you are connecting legacy version Macintosh computers.

To connect the projector to a notebook or desktop computer:

- 1. Take the supplied VGA cable and connect one end to the D-Sub output socket of the computer.
- 2. Connect the other end of the VGA cable to the **COMPUTER IN 1** or **COMPUTER IN 2** signal input socket on the projector.
- 3. If you wish to use the remote paging function, take a USB cable and connect the larger end to the USB port of the computer, and smaller end to the **Type B USB** socket on the projector. See "Using the remote mouse control" on page 10 for details.
- Many notebooks do not turn on their external video ports when connected to a projector.

 Usually a key combo like FN + F3 or CRT/LCD key turns the external display on/off. Locate a function key labeled CRT/LCD or a function key with a monitor symbol on the notebook. Press FN and the labeled function key simultaneously. Refer to your notebook's documentation to find your notebook's key combination.

Connecting a monitor

If you want to view your presentation close-up on a monitor as well as on the screen, you can connect the **MONITOR OUT** signal output socket on the projector to an external monitor with a VGA cable following the instructions below:

To connect the projector to a monitor:

- 1. Connect the projector to a computer as described in "Connecting a computer" on page 18.
- 2. Take a suitable VGA cable (only one supplied) and connect one end of the cable to the D-Sub input socket of the video monitor.
 - Or if your monitor is equipped with a DVI input socket, take a VGA to DVI-A cable and connect the DVI end of the cable to the DVI input socket of the video monitor.
- 3. Connect the other end of the cable to the **MONITOR OUT** socket on the projector.
- For the PJD5126/PJD5226/PJD5226w, the MONITOR OUT output only works when COMPUTER IN 1 is made to the projector.
 - For the PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383/PJD6383sPJD6553w/PJD6653w/PJD6653ws/PJD6683w/PJD6683ws, MONITOR OUT output only works when COMPUTER IN 1 or COMPUTER IN 2 is made to the projector.
 - To use this connection method when the projector is in standby mode, turn on the Active VGA Out function under the SYSTEM SETUP: Advanced > Standby Settings menu.

Connecting Video source devices

You can connect your projector to various Video source devices that provide any one of the following output sockets:

- HDMI
- Component Video
- S-Video
- Video (composite)

You need only connect the projector to a Video source device using just one of the above connecting methods, however each provides a different level of video quality. The method you choose will most likely depend upon the availability of matching terminals on both the projector and the Video source device as described below:

Best video quality

The best available video connection method is HDMI. If your source device is equipped with a HDMI socket, you can enjoy uncompressed digital video quality.

See "Connecting an HDMI device" on page 20 for how to connect the projector to a HDMI source device and other details.

If no HDMI source is available, the next best video signal is Component video (not to be confused with composite video). Digital TV tuner and DVD players output Component video natively, so if available on your devices, this should be your connection method of choice in preference to (composite) video.

See "Connecting a Component Video source device" on page 20 for how to connect the projector to a component video device.

Better video quality

The S-Video method provides a better quality analog video than standard composite Video. If you have both composite Video and S-Video output terminals on your Video source device, you should elect to use the S-Video option.

See "Connecting an S-Video source device" on page 21 for how to connect the projector to an S-Video device.

Least video quality

Composite Video is an analog video and will result in a perfectly acceptable, but less than optimal result from your projector, being the least video quality of the available methods described here.

See "Connecting a composite Video source device" on page 21 for how to connect the projector to a composite Video device.

Connecting audio

The projector has one built-in mono speaker which is designed to provide basic audio functionality accompanying data presentations for business purposes only. They are not designed for, nor intended for stereo audio reproduction use as might be expected in home theater or home cinema applications. Any stereo audio input (if provided), is mixed into a common mono audio output through the projector speaker.

The table below describes where the sound is from when different source is connected.

Input source	COMPUTER IN 1	COMPUTER IN 2, VIDEO, S-VIDEO
The projector can play the sound from	AUDIO IN 1	AUDIO IN 2

If you wish, you can make use of the projector (mixed mono) speaker in your presentations, and also connect separate amplified speakers to the Audio Out socket of the projector. The audio output is a mixed mono signal and controlled by the projector Volume and Mute settings.

If you have a separate sound system, you will most likely want to connect the audio output of your Video source device to that sound system, instead of to the mono audio projector.

Connecting an HDMI device

You should use an HDMI cable when making connection between the projector and HDMI devices.

To connect the projector to an HDMI device:

- 1. Take an HDMI cable and connect one end to the HDMI-output port of the video device.
- 2. Connect the other end of the cable to the **HDMI**-input port on the projector.



- The projector is only capable of playing mixed mono audio, even if a stereo audio input is connected. See "Connecting audio" on page 19 for details.
- The HDMI input port is only available on the PJD6223/PJD6253/PJD6553w series.

Connecting a Component Video source device

Examine your Video source device to determine if it has a set of unused Component Video output sockets available:

- If so, you can continue with this procedure.
- If not, you will need to reassess which method you can use to connect to the device.

To connect the projector to a Component Video source device:

- 1. Take a Component Video to VGA (D-Sub) adaptor cable and connect the end with 3 RCA type connectors to the Component Video output sockets of the Video source device. Match the color of the plugs to the color of the sockets; green to green, blue to blue, and red to red.
- 2. Connect the other end of the Component Video to VGA (D-Sub) adaptor cable (with a D-Sub type connector) to the **COMPUTER IN 1** or **COMPUTER IN 2** socket on the projector.
- The projector is only capable of playing mixed mono audio, even if a stereo audio input is connected. See "Connecting audio" on page 19 for details.
 - If the selected video image is not displayed after the projector is turned on and the correct video source has been selected, check that the Video source device is turned on and operating correctly. Also check that the signal cables have been connected correctly.
 - VGA-Component adapter (ViewSonic P/N: CB-00008906)

Connecting an S-Video source device

Examine your Video source device to determine if it has an unused S-Video output socket available:

- If so, you can continue with this procedure.
- If not, you will need to reassess which method you can use to connect to the device.

To connect the projector to an S-Video source device:

- 1. Take an S-Video cable and connect one end to the S-Video output socket of the Video source device.
- 2. Connect the other end of the S-Video cable to the **S-VIDEO** socket on the projector.
- The projector is only capable of playing mixed mono audio, even if a stereo audio input is connected. See "Connecting audio" on page 19 for details.
 - If the selected video image is not displayed after the projector is turned on and the correct video source has been selected, check that the Video source device is turned on and operating correctly. Also check that the signal cables have been connected correctly.
 - If you have already made a Component Video connection between the projector and this S-Video source device using Component Video connections, you need not connect to this device using an S-Video connection as this makes an unnecessary second connection of poorer picture quality. See "Connecting Video source devices" on page 19 for details.

Connecting a composite Video source device

Examine your Video source device to determine if it has a set of unused composite Video output sockets available:


- If so, you can continue with this procedure.
- If not, you will need to reassess which method you can use to connect to the device.

To connect the projector to a composite Video source device:

- 1. Take a Video cable and connect one end to the composite Video output socket of the Video source device.
- 2. Connect the other end of the Video cable to the **VIDEO** socket on the projector.
- The projector is only capable of playing mixed mono audio, even if a stereo audio input is connected. See "Connecting audio" on page 19 for details.
 - If the selected video image is not displayed after the projector is turned on and the correct video source has been selected, check that the Video source device is turned on and operating correctly. Also check that the signal cables have been connected correctly.
 - You need only connect to this device using a composite Video connection if Component Video and S-Video inputs are unavailable for use. See "Connecting Video source devices" on page 19 for details.

Starting up the projector

- Plug the power cord into the projector and into a wall socket. Turn on the wall socket switch (where fitted). Check that the POWER indicator light on the projector flashes blue after power has been applied.
- 2. Press **OPOWER** on the projector or remote control to start the projector. The **POWER** indicator light stays blue when the projector is on.



(If necessary) Rotate the focus ring to adjust the image clearness.

- If the projector is still hot from previous activity, it will run the cooling fan for approximately 90 seconds before energizing the lamp.
 - To maintain the lamp life, once you turn the projector on, wait at least 5 minutes before turning it off.
 - 3. If the projector is activated for the first time, select your OSD language following the on-screen instructions.
 - 4. Switch all of the connected equipment on.
 - 5. The projector will start to search for input signals. The current input signal being scanned appears in the upper left corner of the screen. If the projector doesn't detect a valid signal, the message 'No Signal' will continue to be displayed until an input signal is found.

You can also press **SOURCE** on the projector or remote control to select your desired input signal. See "Switching input signal" on page 27 for details.


If the frequency/resolution of the input signal exceeds the projector's operating range, you will see the message 'Out of Range' displayed on a blank screen. Please change to an input signal which is compatible with the projector's resolution or set the input signal to a lower setting. See "Timing chart" on page 67 for details.

Using the menus

The projector is equipped with On-Screen Display (OSD) menus for making various adjustments and settings.

The OSD screenshots below are for reference only, and may differ from the actual design.

Below is the overview of the OSD menu.



To use the OSD menus, please set them to your familiar language first.

 Press MENU/EXIT on the projector or Menu on the remote control to turn the OSD menu on.



Press ✓ to highlight
 Language and press 〈/〉 to select a preferred language.




2. Use ⟨/⟩ to highlight the SYSTEM SETUP: Basic menu.



4. Press MENU/EXIT twice* on the projector or Exit on the remote control to leave and save the settings.

*The first press leads you back to the main menu and the second press closes the OSD menu.




Utilizing the password function

For security purposes and to help prevent unauthorized use, the projector includes an option for setting up password security. The password can be set through the On-Screen Display (OSD) menu. For details of the OSD menu operation, please refer to "Using the menus" on page 23.

You will be inconvenienced if you activate the password functionality and subsequently forget the password. Print this user manual (if necessary) and write the password you used in this manual, and keep it in a safe place for later use.

Setting a password

- Open the OSD menu and go to the SYSTEM SETUP: Advanced > Security Settings menu. Press MODE/ENTER on the projector or Enter on the remote control. The Security Settings page is displayed.
- 2. Highlight **Power On Lock** and select **On** by pressing $\langle \rangle$.
- 3. As pictured to the right, the four arrow keys (⟨, ∧, ∨, ⟩) respectively represent 4 digits (1, 2, 3, 4). According to the password you desire to set, press the arrow keys to enter six digits for the password.



- 4. Confirm the new password by re-entering the new password.
 - Once the password is set, the OSD menu returns to the **Security Settings** page.
- 5. To leave the OSD menu, press **MENU/EXIT** on the projector or **Exit** on the remote control.
- Once a password has been set, the projector cannot be used unless the correct password is entered every time the projector is started.

If you forget the password

If the password function is activated, you will be asked to enter the six-digit password every time you turn on the projector. If you enter the wrong password, the password error message as pictured to the right is displayed lasting for three seconds, and the message 'INPUT PASSWORD' follows. You can retry by entering another six-digit password, or if you did not



record the password in this user manual, and you absolutely do not remember it, you can use the password recall procedure. See "Entering the password recall procedure" on page 25 for details.

If you enter an incorrect password 5 times in succession, the projector will automatically shut down in a short time.

Entering the password recall procedure

- Press and hold AUTO on the projector or Auto Sync on the remote control for 3 seconds. The projector will display a coded number on the screen.
- 2. Write down the number and turn off your projector.
- 3. Seek help from the local service center to decode the number. You may be required to provide proof of purchase documentation to verify that you are an authorized user of the projector.



Changing the password

- Open the OSD menu and go to the SYSTEM SETUP: Advanced > Security Settings > Change Password menu.
- 2. Press MODE/ENTER on the projector or Enter on the remote control. The message 'INPUT CURRENT PASSWORD' is displayed.
- 3. Enter the old password.
 - If the password is correct, another message 'INPUT NEW PASSWORD' is displayed.
 - If the password is incorrect, the password error message is displayed lasting for three seconds, and the message 'INPUT CURRENT PASSWORD' is displayed for your retry. You can press MENU/EXIT on the projector or Exit on the remote control to cancel the change or try another password.
- 4. Enter a new password.
- 5. Confirm the new password by re-entering the new password.
- 6. You have successfully assigned a new password to the projector. Remember to enter the new password next time the projector is started.
- 7. To leave the OSD menu, press **MENU/EXIT** on the projector or **Exit** on the remote control.

The digits being input will be displayed as asterisks on-screen. Write your selected password down here in this user manual in advance or right after the password is entered so that it is available to you should you ever forget it.
Password:
Keep this user manual in a safe place.

Disabling the password function

To disable password protection, go back to the **SYSTEM SETUP:** Advanced > Security **Settings** > **Power On Lock** menu after opening the OSD menu system. Select **Off** by pressing $\langle \rangle$. The message **'INPUT PASSWORD'** is displayed. Enter the current password.

- If the password is correct, the OSD menu returns to the **Security Settings** page with **'Off'** shown in the row of **Power On Lock**. You will not have to enter the password next time you turn on the projector.
- If the password is incorrect, the password error message is displayed lasting for three seconds, and the message 'INPUT PASSWORD' is displayed for your retry. You can press MENU/EXIT on the projector or Exit on the remote control to cancel the change or try another password.

Though the password function is disabled, you need to keep the old password in hand should you ever need to re-activate the password function by entering the old password.

Switching input signal


The projector can be connected to multiple devices at the same time. However, it can only display one full screen at a time.

Be sure the **Quick Auto Search** function in the **SOURCE** menu is **On** if you want the projector to automatically search for the signals.


You can also manually select the desired signal by pressing one of the source selection keys on the remote control, or cycle through the available input signals.

- 1. Press **SOURCE** on the projector or remote control. A source selection bar is displayed.
- Press ∧ / ∨ until your desired signal is selected and press MODE/ENTER on the projector or Enter on the remote control.
 Once detected, the selected source information will be displayed on the screen for seconds. If there are multiple devices connected to the projector, repeat steps 1-2 to search for another signal.
- The brightness level of the projected image will change accordingly when you switch between different input signals. Data (graphic) "PC" presentations using mostly static images are generally brighter than "Video" using mostly moving images (movies).
 - The input signal type effects the options available for the Color Mode. See "Selecting a picture mode" on page 32 for details.
 - Please see "Projector specifications" on page 64
 for the native display resolution of this projector.
 For best display picture results, you should select
 and use an input signal which outputs at this
 resolution. Any other resolutions will be scaled by
 the projector depending upon the 'aspect ratio'
 setting, which may cause some image distortion
 or loss of picture clarity. See "Selecting the aspect
 ratio" on page 30 for details.

PJD5126/PJD5226/PJD5226w



PJD6223/PJD6253/PJD6353/ PJD6353s/PJD6383/PJD6383s/ PJD6553w/PJD6653w/PJD6653ws PJD6683w/PJD6683ws



Changing Color Space

This function is only available for the PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383/PJD6553w/PJD6653w/PJD6653w/PJD6653w/PJD6683w/PJD6683ws series.

In the unlikely event that you connect the projector to a DVD player via the projector's **HDMI** input and the projected picture displays wrong colors, please change the color space to **YUV**.

To do this:


- 1. Open the OSD menu and go to the **SOURCE** menu.
- This function is only available when the HDMI-input port is in use.

Adjusting the projected image

Adjusting the projection angle

The projector is equipped with 1 quick-release adjuster foot and 2 rear adjuster feet. These adjusters change the image height and projection angle. To adjust the projector:

- 1. Press the quick-release button and lift the front of the projector. Once the image is positioned where you want it, release the quick-release button to lock the foot in position.
- 2. Screw the rear adjuster feet to fine tune the horizontal angle.



If the projector is not placed on a flat surface or the screen and the projector are not perpendicular to each other, the projected image becomes trapezoidal. To correct this situation, see "Correcting keystone" on page 29 for details.



- Do not look into the lens while the lamp is on. The strong light from the lamp may cause damage to your eyes.
- Be careful when you press the adjuster button as it is close to the exhaust vent where hot air comes from.

Auto-adjusting the image

In some cases, you may need to optimize the picture quality. To do this, press **AUTO** on the projector or **Auto Sync** on the remote control. Within 3 seconds, the built-in Intelligent Auto Adjustment function will re-adjust the values of Frequency and Clock to provide the best picture quality.


The current source information will be displayed in the upper left corner of the screen for 3 seconds.




- The screen will be blank while AUTO is functioning.
- · This function is only available when PC signal (analog RGB) is selected.

Fine-tuning the image clarity

1. Adjust the projected image to the size that you need using the zoom ring.



2. If necessary, Sharpen the image by rotating the focus ring.





PJD6353/PJD6353s/ PJD6383/PJD6383s/ PJD6653w/PJD6653ws/ PJD6683w/PJD6683ws/

Correcting keystone

Keystoning refers to the situation where the projected image is noticeably wider at either the top or bottom. It occurs when the projector is not perpendicular to the screen.

To correct this, besides adjusting the height of the projector, you will need to manually correct it following one of these steps.

• Using the remote control

Press \(\blue{/}\) on the projector or remote control to display the Keystone correction page. Press \(\blue{\}\) to correct keystoning at the top of the image. Press \(\blue{\}\) to correct keystoning at the bottom of the image.



- Using the OSD menu
- Press MENU/EXIT on the projector or Menu on the remote control and then press
 \(\rangle \rangle \) until the DISPLAY menu is highlighted.
- 2. Press ✓ to highlight **Keystone** and press **MODE/ENTER** on the projector or **Enter** on the remote control. The **Keystone** correction page is displayed.
- 3. Press to correct keystoning at the top of the image or press to correct keystoning at the bottom of the image.

Magnifying and searching for details

If you need to find the details on the projected picture, magnify the picture. Use the direction arrow keys for navigating the picture.

- Using the remote control
- 1. Press **Magnify** on the remote control to display the Zoom bar.
- 2. Press \(\structure \) repeatedly to magnify the picture to a desired size.
- 3. To navigate the picture, press **MODE/ENTER** on the projector or **Enter** on the remote control to switch to the paning mode and press the directional arrows (⟨⟨,∧,∨,⟩) to navigate the picture.
- 4. To reduce size of the picture, press **MODE/ENTER** on the projector or **Enter** on the remote control to switch back to the zoom in/out functionality, and press **AUTO/Auto Sync** to restore the picture to its original size. You can also press ✓ repeatedly until it is restored to the original size.
- Using the OSD menu
- 1. Press **MENU/EXIT** on the projector or **Menu** on the remote control and then press $\langle \rangle$ until the **DISPLAY** menu is highlighted.
- 2. Press ✓ to highlight **Zoom** and press **MODE/ENTER** on the projector or **Enter** on the remote control. The Zoom bar is displayed.
- 3. Repeat steps 2-4 in the section of Using the remote control above.
- The picture can only be navigated after the picture is magnified. You can further magnify the picture while searching for details.

Selecting the aspect ratio

The 'aspect ratio' is the ratio of the image width to the image height. Most analog TV and computers are in 4:3 ratio, and digital TV and DVDs are usually in 16:9 ratio.

With the advent of digital signal processing, digital display devices like this projector can dynamically stretch and scale the image output to a different aspect than that of the image input signal.


To change the projected image ratio (no matter what aspect the source is):

- Using the remote control
- 1. Press **Aspect** to show the current setting.
- 2. Press **Aspect** repeatedly to select an aspect ratio to suit the format of the video signal and your display requirements.
- Using the OSD menu
- 1. Press **MENU/EXIT** on the projector or **Menu** on the remote control and then press $\langle \rangle$ until the **DISPLAY** menu is highlighted.
- 2. Press ✓ to highlight **Aspect Ratio**.
- 3. Press ⟨/⟩ to select an aspect ratio to suit the format of the video signal and your display requirements.


About the aspect ratio

In the pictures below, the black portions are inactive areas and the white portions are active areas. OSD menus can be displayed on those unused black areas.

- 1. **Auto**: Scales an image proportionally to fit the projector's native resolution in its horizontal width. This is suitable for the incoming image which is neither in 4:3 nor 16:9 and you want to make most use of the screen without altering the image's aspect ratio.
- 16:10 picture 0
 15:9 picture
- 2. **4:3**: Scales an image so that it is displayed in the center of the screen with a 4:3 aspect ratio. This is most suitable for 4:3 images like computer monitors, standard definition TV and 4:3 aspect DVD movies, as it displays them without aspect alteration.




3. **16:9**: Scales an image so that it is displayed in the center of the screen with a 16:9 aspect ratio. This is most suitable for images which are already in a 16:9 aspect, like high definition TV, as it displays them without aspect alteration.



4. 16:10 (PJD5226w/PJD6553w/PJD6653w/PJD6653ws/PJD6683w/PJD6683ws only):

Scales an image so that it is displayed in the center of the screen with a 16:10 aspect ratio. This is most suitable for images which are already in a 16:10 aspect, as it displays them without aspect alteration



Optimizing the image

Selecting a picture mode

The projector is preset with several predefined picture modes so that you can choose one to suit your operating environment and input signal picture type.

To select an operation mode that suits your need, you can follow one of the following steps.

- Press MODE/ENTER on the projector or Color Mode on the remote control repeatedly until your desired mode is selected.
- Go to the **PICTURE** > **Color Mode** menu and press $\langle \rangle$ to select a desired mode.

Picture modes for different types of signals

The picture modes available for different types of signals are listed below.

PC input signals: D-Sub / Comp. 1/2 (analog RGB)

- 1. **Brightest mode**: Maximizes the brightness of the projected image. This mode is suitable for environments where extra-high brightness is required, such as using the projector in well lit rooms.
- 2. **PC mode**: Is designed for presentations under daylight environment to match PC and notebook coloring.
- 3. **ViewMatch mode**: Switches between high brightness performance and accurate color performance.
- 4. **Movie mode**: Is appropriate for playing colorful movies, video clips from digital cameras or DVs through the PC input for best viewing in a blackened (little light) environment.
- 5. **Dynamic PC mode**: Is designed for presentations under daylight environment to match PC and notebook coloring. In addition, the projector will optimize the image quality using the dynamic PC function in accordance with the projected contents.
- It takes some time to initiate this function. Make sure the projector has been turned on for more than 4 minutes.

 If the projector is resumed by using the Smart Restart feature, this function can be executed immediately.
 - 6. **Dynamic Movie mode**: Is appropriate for playing colorful movies, video clips from digital cameras or DVs through the PC input for best viewing in a blackened (little light) environment. In addition, the projector will optimize the image quality using the dynamic Movie function in accordance with the projected contents.
- It takes some time to initiate this function. Make sure the projector has been turned on for more than 4 minutes.

If the projector is resumed by using the Smart Restart feature, this function can be executed immediately.

7. **User 1/User 2 mode**: Recalls the settings customized based on the current available picture modes. See "Setting the User 1/User 2 mode" on page 33 for details.

Video input signals: S-Video, Video, D-Sub / Comp. 1/2 (YPbPr) / HDMI

- 1. **Brightest mode**: Optimized for daylight viewing, with living room level ambient brightness.
- 2. **Gaming mode**: Suitable for all types of entertainment media, including gaming and movies.

- 3. **ViewMatch mode**: Switches between high brightness performance and accurate color performance.
- 4. **Movie mode**: Is suitable for enjoying dark movies or DVD movies best viewed in a blackened (little light) home cinema or lounge room environment.
- 5. **Dynamic Movie mode**: Is suitable for enjoying dark movies or DVD movies best viewed in a blackened (little light) home cinema or lounge room environment. In addition, the projector will optimize the image quality using the dynamic Movie function in accordance with the projected contents.
- It takes some time to initiate this function. Make sure the projector has been turned on for more than 4 minutes.

If the projector is resumed by using the Smart Restart feature, this function can be executed immediately.

6. **User 1/User 2 mode**: Recalls the settings customized based on the current available picture modes. See "Setting the User 1/User 2 mode" on page 33 for details.

Setting the User 1/User 2 mode

There are two user-definable modes if the current available picture modes are not suitable for your need. You can use one of the picture modes (except the User 1/User 2) as a starting point and customize the settings.

- 1. Press **MENU/EXIT** on the projector or **Menu** on the remote control to open the On-Screen Display (OSD) menu.
- 2. Go to the **PICTURE** > **Color Mode** menu.
- 3. Press $\langle \rangle$ to select **User 1** or **User 2**.
- 4. Press ✓ to highlight **Reference Mode**.
- This function is only available when User 1 or User 2 mode is selected up in the Color Mode sub-menu item.
 - 5. Press $\langle \rangle$ to select a picture mode that is closest to your need.
 - 6. Press \vee to select a sub-menu item to be changed and adjust the value with \langle / \rangle . See Fine-tuning the image quality in user modes below for details.
 - 7. When all settings have been done, highlight **Save Settings** and press **MODE/ENTER** on the projector or **Enter** on the remote control to store the settings.
 - 8. The confirmation message 'Setting Saved' is displayed.

Using Screen Color

In the situation where you are projecting onto a colored surface such as a painted wall which may not be white, the **Screen Color** feature can help correct the projected picture's colors to prevent possible color difference between the source and projected pictures.

To use this function, go to the **DISPLAY** > **Screen Color** menu and press \langle / \rangle to select a color which is closest to the color of the projection surface. There are several precalibrated colors to choose from: **Whiteboard**, **Greenboard**, and **Blackboard**.

This function is only available when a PC type input signal is selected.

Fine-tuning the image quality in user modes

According to the detected signal type, there are some user-definable functions available when **User 1** or **User 2** mode is selected. You can make adjustments to these functions based on your needs.

Adjusting Brightness

Highlight the **PICTURE** > **Brightness** menu and press </>>.

The higher the value, the brighter the image. And the lower the setting, the darker the image. Adjust this control so the black areas of the image appear just as black and that detail in the dark areas is visible.







Adjusting Contrast

Highlight the **PICTURE** > **Contrast** menu and press </>>>.

The higher the value, the greater the contrast. Use this to set the peak white level after you have previously adjusted the **Brightness** setting to suit your selected input and viewing environment.







Adjusting Color

Highlight the **PICTURE** > **Color** menu and press </>>.

Lower setting produces less saturated colors. If the setting is too high, colors on the image will be overpowering, which makes the image unrealistic.

Adjusting Tint

Highlight the **PICTURE** > **Tint** menu and press </>>.

The higher the value, the more reddish the picture becomes. The lower the value, the more greenish the picture becomes.

Adjusting Sharpness

Highlight the **PICTURE** > **Sharpness** menu and press </>>.

The higher the value, the sharper the picture becomes. The lower the value, the softer the picture becomes.

Adjusting Brilliant Color

Highlight the PICTURE > Brilliant Color menu and press $\langle \rangle$.

This feature utilizes a new color-processing algorithm and system level enhancements to enable higher brightness while providing truer, more vibrant colors in the projected picture. It enables a greater than 50% brightness increase in mid-tone images, which are common in video and natural scenes, so the projector reproduces images in realistic and true colors. If you prefer images with that quality, select **On**. If you don't need it, select **Off**.

When **Off** is selected, the **Color Temperature** function is not available.

Selecting a Color Temperature

Highlight the PICTURE > Color Temperature menu and press </>>.

The options available for color temperature* settings vary according to the signal type selected.

- 1. **T1:** With the highest color temperature, T1 makes the image appear the most bluish white than other settings.
- 2. **T2:** Makes images appear bluish white.
- 3. **T3:** Maintains normal colorings for white.
- 4. **T4:** Makes images appear reddish white.

*About color temperatures:

There are many different shades that are considered to be "white" for various purposes. One of the common methods of representing white color is known as the "color temperature". A white color with a low color temperature appears to be reddish white. A white color with a high color temperature appears to have more blue in it.

Color Management

Only in permanent installations with controlled lighting levels such as boardrooms, lecture theaters, or home theaters, should color management be considered. Color management provides fine color control adjustment to allow for more accurate color reproduction, should you require it.

If you have purchased a test disc which contains various color test patterns and can be used to test the color presentation on monitors, TVs, projectors, etc., you can project any image from the disc on the screen and enter the **Color Management** menu to make adjustments.

To adjust the settings:

- 1. Go to the **DISPLAY** menu and highlight **Color Management**.
- 2. Press **MODE/ENTER** on the projector or **Enter** on the remote control and the **Color Management** page is displayed.
- 3. Highlight **Primary Color** and press ⟨/⟩ to select a color from among Red, Yellow, Green, Cyan, Blue, or Magenta.
- 4. Press ✓ to highlight **Hue** and press
 ⟨/⟩ to select its range. Increase in the range will include colors consisted of more proportions of its two adjacent colors.

Please refer to the illustration to the right for how the colors relate to each other.

For example, if you select Red and set its range at 0, only pure red in the projected picture will be selected. Increasing its range will include red close to yellow and red close to magenta.


Press

✓ to highlight Saturation and adjust its values to your preference by pressing

✓/

>. Every adjustment made will reflect to the image immediately.

For example, if you select Red and set its value at 0, only the saturation of pure red will be affected.



- Saturation is the amount of that color in a video picture. Lower settings produce less saturated colors; a setting of "0" removes that color from the image entirely. If the saturation is too high, that color will be overpowering and unrealistic.
 - 6. Press \vee to highlight **Gain** and adjust its values to your preference by pressing $\langle \rangle$
 - >. The contrast level of the primary color you select will be affected. Every adjustment made will reflect to the image immediately.
 - 7. Repeat steps 3 to 6 for other color adjustments.
 - 8. Make sure you have made all of the desired adjustments.
 - 9. Press **MENU/EXIT** on the projector or **Exit** on the remote control to exit and save the settings.

Setting the presentation timer

Presentation timer can indicate the presentation time on the screen to help you achieve better time management when giving presentations. Follow these steps to utilize this function:

- Press Timer on the remote control to access the Presentation Timer menu or go to the SYSTEM SETUP: Advanced > Presentation Timer menu and press MODE/ ENTER to display the Presentation Timer page.
- 2. Highlight **Timer Period** and decide the time period by pressing ⟨/⟩. The length of time can be set from 1 to 5 minutes in 1-minute increments and 5 to 240 minutes in 5-minute increments.

If the timer is already on, the timer will restart whenever the Timer Period is reset.

3. Press \checkmark to highlight **Timer Display** and choose if you want the timer to show up on the screen by pressing $\langle \rangle$.

Selection Description	
Always	Displays the timer on screen throughout the presentation
	time.
1 min/2 min/3 min	Displays the timer on screen in the last 1/2/3 minute(s).
Never	Hides the timer throughout the presentation time.

4. Press \vee to highlight **Timer Position** and set the timer position by pressing $\langle \rangle$.

5. Press ✓ to highlight **Timer Counting Direction** and select your desired counting direction by pressing 〈/〉.

Selection	Description
Count Up	Increases from 0 to the preset time.
Count Down	Decreases from the preset time to 0.

- 6. Press ✓ to highlight **Sound Reminder** and decide if you want to activate sound reminder by pressing ⟨/⟩. If you select **On**, a double beep sound will be heard at the last 30 seconds of counting down/up, and a triple beep sound will be produced when the timer is up.
- 7. To activate the presentation timer, press ✓ and press </br>
 ✓ to highlight Start Counting and press MODE/ENTER.
- 8. A confirmation message displays. Highlight **Yes** and press **MODE/ENTER** on the projector or remote control to confirm. You will see the message "**Timer is On**" displaying on the screen. The timer starts counting when the timer is on.

To cancel the timer, perform the following steps:

- 1. Go to the **SYSTEM SETUP: Advanced > Presentation Timer** menu and highlight **Off**. Press **MODE/ENTER**. A confirmation message displays.
- 2. Highlight Yes and press **MODE/ENTER** to confirm. You will see the message "Timer is Off" displaying on the screen.

Hiding the image

In order to draw the audience's full attention to the presenter, you can use \langle on the projector or **Blank** on the remote control to hide the screen image. Press any key on the projector or remote control to restore the image. The word '**BLANK**' appears at the lower right corner of the screen while the image is hidden.

You can set the blank time in the **SYSTEM SETUP: Basic > Blank Timer** menu to let the projector return the image automatically after a period of time when there is no action taken on the blank screen.

Once Blank is pressed, the projector enters Economic mode automatically.

Do not block the projection lens from projecting as this could cause the blocking object to become heated and deformed or even cause a fire.

Locking control keys

With the control keys on the projector locked, you can prevent your projector settings from being changed accidentally (by children, for example). When the **Panel Key Lock** is on, no control keys on the projector will operate except () **POWER**.

- Press > on the projector or Lock on the remote control, or go to the SYSTEM SETUP: Basic > Panel Key Lock menu, and select On by pressing ⟨/⟩ on the projector or remote control.
- 2. A confirmation message is displayed. Select **Yes** to confirm.

To release panel key lock, press and hold > on the projector or **Lock** no on the remote control for 3 seconds.

You can also use the remote control to enter the SYSTEM SETUP: Basic > Panel Key Lock menu and press $\langle \rangle$ to select Off.

- Keys on the remote control are still functional when panel key lock is enabled.
 - If you press OPOWER to turn off the projector without disabling panel key lock, the projector will still be in locked status the next time it is turned on.

Freezing the image

Press **Freeze** on the remote control to freeze the image. The word **'FREEZE**' will be displayed in the upper left corner of the screen. To release the function, press any key on the projector or remote control.

Even if an image is frozen on the screen, the pictures are running on the video or other device. If the connected devices have active audio output, you will still hear the audio even though the image is frozen on screen.

Operating in a high altitude environment

We recommend you use the **High Altitude Mode** when your environment is between 1500 m–3000 m above sea level, and temperature is between 0°C–35°C.

(!\CAUTION

Do not use the High Altitude Mode if your altitude is between 0 m and 1500 m and temperature is between 0°C and 35°C. The projector will be over cooled, if you turn the mode on under such a condition.

To activate the **High Altitude Mode**:

- Press MENU/EXIT on the projector or Menu on the remote control and then press ⟨/⟩ until the SYSTEM SETUP: Advanced menu is highlighted.
- Press ✓ to highlight High Altitude Mode and press
 to select On. A confirmation message is displayed.



3. Highlight **Yes** and press **MODE/ENTER** on the projector or **Enter** on the remote control.

Operation under "**High Altitude Mode**" may cause a higher decibel operating noise level because of increased fan speed necessary to improve overall system cooling and performance.

If you use this projector under other extreme conditions excluding the above, it may display auto shut-down symptoms, which is designed to protect your projector from over-heating. In cases like this, you should switch to **High Altitude Mode** to solve these symptoms. However, this is not to state that this projector can operate under any and all harsh or extreme conditions.

Creating your own startup screen

This function is only available for the PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383/PJD6383s/PJD6553w/PJD6653w/PJD6653ws/PJD6683w/PJD6683ws series.

In addition to selecting the projector preset startup screen from among ViewSonic logo, Black or Blue screen, you can make your own startup screen that is a picture projected from your computer or video source.

To create your own startup screen, project the picture you want to use as your startup screen from either a computer or video source. The rest of the steps are as follows.


- 1. Press **MENU/EXIT** on the projector or **Menu** on the remote control and then press $\langle \rangle$ until the **SYSTEM SETUP: Basic** menu is highlighted.
- 2. Press ✓ to highlight **Screen Capture** and press **MODE/ENTER** on the projector or **Enter** on the remote control.
- 3. A confirmation message is displayed. Press **MODE/ENTER** on the projector or **Enter** on the remote control again.
- 4. The message 'Screen Capturing...' is displayed while the projector is processing the picture. Please wait.
- 5. If the action is successful, you see the message 'Capture Succeeded' on the screen. The captured picture is saved as Screen Capture and the captured picture will be displayed as the startup screen if you restart the projector.

In the unlikely event that the capturing action fails, change your target picture. When the resolution of the input signal is higher than the projector's native display resolution (See "Projector specifications" on page 64 for details.), the capture action may fail. When it happens, please set the resolution of the input signal under native resolution and try again.

Controlling the projector through a LAN environment

This function is only available for the PJD6223/PJD6253/PJD6353s/PJD6353s/PJD6383/PJD6353w/PJD6653w/PJD6653ws/PJD6653ws/PJD6683ws series.

The projector supports Crestron[®] software. With correct settings for the **LAN Control Settings** menu, you can manage the projector from a computer using a web browser when the computer and the projector are properly connected to the same local area network.



(An example of connection)

Configuring the LAN Control Settings

If you are in a DHCP environment:

- 1. Take a RJ45 cable and connect one end to the RJ45 LAN input jack of the projector and the other end to the RJ45 port.
- 2. Press **MENU/EXIT** on the projector or **Menu** on the remote control and then press $\langle \rangle$ until the **SYSTEM SETUP: Basic** menu is highlighted.
- 3. Press ✓ to highlight LAN Control Settings and press MODE/ENTER on the projector or Enter on the remote control. The LAN Control Settings page is displayed.
- 4. Press \vee to highlight **DHCP** and press $\langle \rangle$ to select **On**.
- 5. Press ✓ to highlight **Apply** and press **MODE/ENTER** on the projector or **Enter** on the remote control.
- Please wait for around 15 20 seconds, and then re-enter the LAN Control Settings
 page. The Projector IP Address, Subnet Mask, Default Gateway, and DNS Server
 settings will be displayed. Note down the IP address displayed in the Projector IP
 Address row.
- If the Projector IP Address still does not appear, contact your network administrator.
 - If the RJ45 cables are not properly connected, the Projector IP Address, Subnet Mask, Default Gateway, and DNS Server settings will display 0.0.0.0. Make sure the cables are properly connected and perform the procedures above again.
 - If you need to connect to the projector in its standby mode, set Power Saving to Off.


If you are in a non-DHCP environment:

- 1. Repeat steps 1-3 above.
- 2. Press \checkmark to highlight **DHCP** and press \langle / \rangle to select **Off**.
- 3. Contact your ITS administrator for information on the **Projector IP Address**, **Subnet Mask**, **Default Gateway**, and **DNS Server** settings.
- 4. Press ✓ to select the item you want to modify and press **MODE/ENTER** on the projector or **Enter** on the remote control.
- 5. Press $\langle \rangle$ to move the cursor and the press $\langle \rangle$ to enter the value.
- 6. To save the settings, press **MODE/ENTER** on the projector or **Enter** on the remote control. If you do not want to save the settings, press **MENU/EXIT** on the projector or **Menu** on the remote control.
- 7. Press ✓ to highlight **Apply** and press **MODE/ENTER** on the projector or **Enter** on the remote control.
- If the RJ45 cables are not properly connected, the Projector IP Address, Subnet Mask, Default Gateway, and DNS Server settings will display 0.0.0.0. Make sure the cables are properly connected and perform the procedures above again.
 - If you wish to connect to the projector in its standby mode, be sure you have selected RJ45 and obtained the Projector IP Address, Subnet Mask, Default Gateway, and DNS Server information when the projector is on.


Controlling the projector through a web browser

Once you have the correct IP address for the projector and the projector is on or in standby mode, you can use any computer that is on the same local area network to control the projector.

- If you are using Microsoft Internet Explorer, make sure it is version 7.0 or higher.
 - The screen shots in this manual are for reference only, and may differ from the actual design.
 - 1. Enter the address of the projector in the address bar of your browser and press Enter.




2. The main page of the Network Control appears.



- Accessing to Network Settings or Email Alert page requires Administrator password. The default password is "0000".
 - 3. This page allows you to make adjustments to the AMX and SNMP settings. In the AMX device discover row, when ON is selected, the projector can be detected by

controllers of AMX connected to the same network. For the Details of AMX Device Discovery, visit the AMX web site at http://www.amx.com/.



4. If your projector is connected to a network which supports Simple Mail Transfer Protocol (SMTP), you can configure it to alert you via email on significant events.



5. The Crestron (e-Control) page displays the Crestron e-Control user interface. See "About Crestron e-Control®" on page 42 for details.

Please pay attention to the limitation of input length (including space and other punctuation keys) in the list blow:

Category Item		Input Length	Maximum Number of Characters
	Network	DHCP/Manual	(N/A)
		IP Address	XXX.XXX.XXX
		Subnet Mask	XXX.XXX.XXX
		Gateway	XXX.XXX.XXX
		DNS Server	XXX.XXX.XXX
Nativade Cattings		AMX device discovery	(N/A)
Network Settings	Password	Administrator	(N/A)
		New Password	4
		Confirm Password	4
	SNMP	SysLocation	22
		SysName	22
		SysContact	22

	Email Setting	То	40
		Сс	40
		Subject	30
		From	40
	SMTP Setting	Server	30
		User Name	40
Email Alert		Password	14
	Alert Condition	Fan Error	(N/A)
		Lamp Error	(N/A)
		Over Temperature	(N/A)
		Lamp Time Alert	(N/A)
		Submit	(N/A)
		Issue Test Mail	(N/A)

/>< \$ % + \ ' " are prohibited.</pre>

About Crestron e-Control®

1. The Crestron e-Control[®] page provides a variety of virtual keys to control the projector or adjust the projected pictures.



- i. These buttons function the same as the ones on the OSD menus or remote control. See "2. PICTURE menu" on page 51 and "Projector" on page 7 for details.
- ii. To switch between input signals, click on your desired signal.
- The Menu button can also be used to go back to previous OSD menus, exit and save menu settings.
 - · The source list varies according to the connectors available on the projector.
 - When you use the projector control panel or remote control to change the OSD menu settings, it may take a while for the web browser to synchronize these changes with the projector.

2. The tools page allows you to manage the projector, configure the LAN control settings and secure access of remote network operation on this projector.




- i. This section is only used with the Crestron Control System. Please contact Creston or refer to its user manual for setup information.
- ii. You can name the projector, keep track of its location and the person in charge of it.
- iii. You can adjust the LAN Control Settings.
- iv. Once set, access to the remote network operation on this projector has been password-protected.
- v. Once set, access to the tools page has been password-protected.
- To prevent errors, only input the English alphabet and digits on the tools page.
 - After making the adjustments, press the Send button and the data will be saved for the projector.
 - vi. Press **Exit** to go back to the remote network operation page.

Please pay attention to the limitation of input length (including space and other punctuation keys) in the list blow:

Category Item	Input Length	Maximum Number of Characters
	IP Address	15
Crestron Control	IP ID	2
	Port	5
	Projector Name	10
Projector	Location	9
	Assigned To	9
	DHCP (Enabled)	(N/A)
	IP Address	15
Network Configuration	Subnet Mask	15
	Default Gateway	15
	DNS Server	15

	Enabled	(N/A)
User Password	New Password	20
	Confirm	2
	Enabled	(N/A)
Admin Password	New Password	20
	Confirm	20

3. The info page displays the information and status of this projector.



4. After pressing the button "Contact IT Help", the HELP DESK window will appear in the upper right corner of the screen. You will be able to deliver messages to RoomViewTM software administrators/users who connect to the same local area network.

For more information, visit http://www.crestron.com & www.crestron.com/getroomview.

**Crestron RoomView

On the "Edit Room" page, enter the IP Address (or hostname) as shown on the projector's on-screen display (OSD) menu, and "02" for IPID, "41794" for the reserved Crestron control port.



About Crestron RoomViewTM setting and command method, please access below website to get RoomViewTM User Guide and more information:

http://www.crestron.com/products/roomview_connected_embedded_projectors_devices/resources.asp

PJLinkTM, SNMP, AMX and Xpanel formats supported


This projector is PJLinkTM, SNMP V.1, AMX or Xpanel V1.10 compliant. For details, please follow its user guide or website respectively to control and manage projectors.

Using the projector in standby mode

Some of the projector functions are available in standby mode (plugged in but not turned on). To use these functions, be sure you have turned on the corresponding menus under **SYSTEM SETUP: Basic** > **Standby Settings**, and the cable connections are correctly made. For the connection methods, see the Connection chapter.

Power Saving

Less than 1W power consumption when **Power Saving** mode is turned on.



• When Power Saving is On, the network function is not available when the projector is in standby mode.

Active VGA Out


Selecting **On** outputs a VGA signal when the **COMPUTER IN 1** and **COMPUTER OUT** sockets are correctly connected to devices. The projector outputs the signal received only from **COMPUTER IN 1**.

Active Audio Out

Selecting **On** outputs an audio signal when the **AUDIO IN 1** and **AUDIO OUT** sockets are correctly connected to devices. The projector outputs the audio signal received only from **AUDIO IN 1**.

Quick Power Off


Selecting **On** enables the function and the projector will not enter the cooling process after being shut down. Selecting **Off** disables the function and the projector will enter normal cooling process after being shut down.



· When Off is selected, the Smart Restart function will be automatically turned off.

Shutting down the projector

- Press () POWER and a confirmation message is displayed prompting you.
 If you don't respond in a few seconds, the message will disappear.
- 2. Press (1) **POWER** a second time.
- Disconnect the power cord from the wall socket if the projector will not be used in an extended period of time.



() CAUTION

- To protect the lamp, the projector will not respond to any commands during the cooling process.
- To shorten the cooling time, you can also activate the Quick Power Off function. See "Quick Power Off" on page 45 for details.
- Do not unplug the power cord before the projector shutdown sequence is complete.

Menu operation

Menu system

Please note that the on-screen display (OSD) menus vary according to the signal type selected.

The menu items are available when the projector detects at least one valid signal. If there is no equipment connected to the projector or no signal detected, limited menu items are accessible.

Main menu	Sub-menu		Options
	Screen Color		Off/Blackboard/
			Greenboard/Whiteboard Auto/4:3/16:9/
	Aspect Ratio		16:10 (PJD5226w/ PJD6553w/
	·		PJD6653w/PJD6653ws/ PJD6683w/PJD6683ws only)
	Keystone		
	Position		
1.	Phase		
DISPLAY	H. Size		
	Zoom		
	3D Sync		TI 3D DLP Link/Off
	3D Sync Invert		Disable/Invert
		Primary Color	R/G/B/C/M/Y
	Color Management	Hue	
		Saturation	
		Gain	
		_	t/PC/ViewMatch/Movie/ ic Movie/User 1/User 2
	Color Mode	•	test/Gaming/ViewMatch/
	Reference Mode	Dynamic PC/Dynam Video source: Brigh	test/Gaming/ViewMatch/
2.		Movie/Dynamic Mov	ie
PICTURE	Brightness		
	Contrast		
	Color		
	Tint		
	Sharpness		010#
	Brilliant Color		On/Off
	Color Temperatu	ıre	T1/T2/T3/T4
	Save Settings		

Main menu	Sub-menu	Options
	Quick Auto Search	Off/On
	Color Space Conversion (PJDe PJD6253/PJD6353/PJD6353s/P PJD6383s/PJD6553w/PJD6653 PJD6683w/PJD6683ws only)	PJD6383/ RGB/YHV/Auto
	DynamicEco Timer	Disable/5 min/10 min/15 min/30 min
	Smart Restart	Off/On
3. SOURCE	PJD622 Pattern 01/02/03 PJD655	6/PJD5226/PJD5226w: Off/On 3/PJD6253/PJD6353/PJD6353s/PJD6383/PJD6383s: 8/04/05/User 3w/PJD6653w/PJD6653ws/PJD6683w/PJD6683ws: 8/04/User
	My Button Mode/DCI My Button Off)/Mess (PJD6223	n (Projector Position)/3D Sync/Lamp R/Closed Caption/Auto Off (Auto Power age/Screen Color/Screen Capture /PJD6253/PJD6353/PJD6353s/PJD6383/PJD6383s/PJD6553w/ v/PJD6653ws/PJD6683w/PJD6683ws only)/Information
	Language	Multi-language OSD selection
	Projector Position	Front Table/Rear Table/ Rear Ceiling/Front Ceiling
	Auto Power Off	Disable/5 min/10 min/20 min/30 min/40 min/50 min/ 60 min
4. SYSTEM	Blank Timer	Disable/5 min/10 min/15 min/20 min/25 min/30 min
SETUP:	Panel Key Lock	On/Off
Basic	Splash Screen	Black/Blue/ViewSonic/ Screen Capture (PJD6223/ PJD6253/PJD6353/PJD6353s/ PJD6383/PJD6383s/PJD6653w/ PJD6553w/PJD6653ws/PJD6683w PJD6683ws only) Off
		3/PJD6253/PJD6353/PJD6353s/PJD6383s/ D6653ws/PJD6683w/PJD6683ws only)

Main menu	Su	b-menu	Options
	Message		On/Off
	LAN Control	DHCP	On/Off
	Settings	Projector IP Address	6
	(PJD6223/PJD6253/ PJD6353/PJD6353s/	Subnet Mask	
4	PJD6383/PJD6383s/	Default Gateway	
SYSTEM	PJD6553w/ PJD6653w/	DNS Server	
SETUP: Basic	PJD6653ws/ PJD6683w PJD6683ws only)	Apply	
		Power Saving	On/Off
	Standby	Active VGA Out	On/Off
	Settings	Active Audio Out	On/Off
		Quick Power Off	On/Off
	High Altitude Mo	ode	On/Off
	DCR		On/Off
	Audio Settings	Mute	On/Off
	Audio Settings	Volume	
	Menu Settings	Menu Display Time	5 sec/10 sec/15 sec/20 sec/ 25 sec/30 sec
		Menu Position	Center/Top-Left/Top-Right/ Bottom-Left/Bottom-Right
	Closed Caption	Closed Caption Enable	On/Off
		Caption Version	CC1/CC2/CC3/CC4
		Lamp Mode	Normal/Economic
5.	Lamn Settings	Reset Lamp Timer	
SYSTEM SETUP:	Lamp Settings	Equivalent Lamp Hour	
Advanced		Timer Period	1~240 minutes
	Presentation Timer	Timer Display	Always/1 min/2 min/3 min/ Never
		Timer Position	Top-Left/Bottom-Left/Top- Right/Bottom-Right
		Timer Counting Direction	Count Down/Count Up
		Sound Reminder	On/Off
		Start Counting/Off	
	Security	Change Password	
	Settings	Power On Lock	On/Off
	Remote Control Code		A/B
	Reset All Settings		On/Off

Main menu	Sub-menu	Options
6. INFORMATION	Current System Status	 Source Color Mode Resolution Color System Equivalent Lamp Hour MAC Address (PJD6223/PJD6253/PJD6353/PJD6353/PJD6353s/PJD6383sPJD6353w/PJD6653w/PJD6653ws/PJD6683w/PJD6683w/PJD6683ws only)

Description of each menu

	Function	Description
	Screen Color	Corrects the projected picture's color when the projection surface is not white. See "Using Screen Color" on page 33 for details.
	Aspect Ratio	There are three options to set the image's aspect ratio depending on your input signal source. See "Selecting the aspect ratio" on page 30 for details.
	Keystone	Corrects any keystoning of the image. See "Correcting keystone" on page 29 for details.
	Position	Displays the position adjustment page. To move the projected image, use the directional arrow keys. The values shown on the lower position of the page change with every key press you made until they reach their maximum or minimum.
	Phase	Adjusts the clock phase to reduce image distortion.
	H. Size	Adjusts the horizontal width of the image.
1. D	Zoom	Magnifies or reduces the projected image. See "Magnifying and searching for details" on page 29 for details.
1. DISPLAY menu	3D Sync	This projector features a 3D function which enables you to enjoy the 3D movies, videos, and sporting events in a more realistic way by presenting the depth of the images.
menu		This function is not available when video source is detected for the PJD5126/PJD5226/PJD5226w.
_		You need to wear a pair of 3D glasses to view the 3D images.
		• TI 3D DLP Link: Enables projector for TI 3D DLP Link.
		• Off: Disables 3D.
		 When the 3D Sync function is on: The brightness level of the projected image will decrease. The Color Mode cannot be adjusted. The Keystone can only be adjusted within limited degrees. The Zoom can only magnify the pictures to limited sizes.
	3D Sync Invert	When you discover the inversion of the image depth, enable this function to correct the problem. (For TI 3D DLP Link only)
	Color Management	See "Color Management" on page 35 for details.

	Function	Description
	Color Mode	Pre-defined picture modes are provided so you can optimize your projector image set-up to suit your program type. See "Selecting a picture mode" on page 32 for details.
	Reference Mode	Selects a picture mode that most suits your need for the image quality and further fine-tune the image based on the selections listed on the same page below. See "Setting the User 1/User 2 mode" on page 33 for details.
	Brightness	Adjusts the brightness of the image. See "Adjusting Brightness" on page 34 for details.
2.	Contrast	Adjusts the degree of difference between dark and light in the image. See "Adjusting Contrast" on page 34 for details.
	Color	Adjusts the color saturation level the amount of each color in a video image. See "Adjusting Color" on page 34 for details.
PICTURE menu	Tint	Adjusts the red and green color tones of the image. See "Adjusting Tint" on page 34 for details.
menu		The function is only available when Video or S-Video with NTSC system is selected.
	Sharpness	Adjusts the image to make it look sharper or softer. See "Adjusting Sharpness" on page 34 for details.
	Brilliant Color	Adjusts white peaking while maintaining correct color presentation. See "Adjusting Brilliant Color" on page 34 for details.
	Color Temperature	See "Selecting a Color Temperature" on page 34 for details.
	Save Settings	Saves the settings made for the User 1 or User 2 mode.

	Function	Description		
	Quick Auto Search	See "Switching input signal" on page 27 for details.		
	Color Space Conversion	See "Changing Color Space" on page 27 for details.		
ယ	DynamicEco Timer	Allows the projector to decrease the power consumption automatically if no input signal is detected after a set period of time. It takes some time to initiate this function. Make sure the projector has been turned on for more than 4 minutes.		
3. SOURCE menu	Smart Restart	Selecting On enables you to restart the projector immediately within 150 seconds after turning it off. After 150 seconds, if the projector is not turned on again, it will directly enter the standby mode. •It takes some time to initiate this function. Make sure the projector has been turned on for more than 4 minutes. If the projector is resumed by using the Smart Restart feature, this function can be executed immediately. •When On is selected, the Quick Power Off function will be automatically set to "On".		
	Pattern	The projector can display several test patterns. It helps you adjust the image size and focus and check that the projected image is free from distortion. Selecting User displays the picture you saved as Screen Capture.		
	My Button	Sets a hotkey on remote control.		

	Function	Description		
4. SYST	Language	Sets the language for the On-Screen Display (OSD) menus. See "Using the menus" on page 23 for details.		
	Projector Position	The projector can be installed on a ceiling or behind a screen, or with one or more mirrors. See "Choosing a location" on page 12 for details.		
	Auto Power Off	Allows the projector to turn off automatically if no input signal is detected after a set period of time. See "Setting Auto Power Off" on page 57 for details.		
	Blank Timer	Sets the image blank time when the Blank feature is activated, once elapsed the image will return to the screen. See "Hiding the image" on page 37 for details.		
M SETU	Panel Key Lock	Disables or enables all panel key functions except POWER on the projector and keys on the remote control. See "Locking control keys" on page 37 for details.		
SYSTEM SETUP: Basic menu	Splash Screen	Allows you to select which logo screen will be displayed during projector start-up.		
	Screen Capture	Captures and stores the projected picture as Screen Capture . See "Creating your own startup screen" on page 38 for details.		
	Message	Selecting On displays the current information on the screen when the projector is detecting or searching for a signal.		
	LAN Control Settings	See "Controlling the projector through a LAN environment" on page 39 for details.		
	Standby Settings	See "Using the projector in standby mode" on page 45 for details.		
5. SY	High Altitude Mode	A mode for operation in high altitude areas. See "Operating in a high altitude environment" on page 37 for details.		
YSTEM SETUP: Advanced menu	DCR	Enables or disables the DCR (Dynamic Contrast Ratio) function. Selecting On enables the function and the projector will automatically switch the lamp mode between normal and economic modes according to the input image detected. This function is only available when a PC source is in use. After enabling DCR, frequent lamp mode switching may shorten lamp life and noise level will vary during operation.		

	Function	Description
	Audio	The sound adjustments made as below will have an effect on the projector speaker. Be sure you have made a correct connection to the projector audio input/output jacks. See "Connection" on page 17 for more details. Mute
	Settings	Mutes the sound received from AUDIO IN 1 and AUDIO IN 2 (L/R).
		Volume Adjusts the sound level received from AUDIO IN 1 and AUDIO IN 2 (L/R).
51	Menu Settings	Menu Display Time Sets the length of time the OSD will remain active after your last key press. The range is from 5 to 30 seconds in 5-second increments.
YS		Menu Position
STI		Sets the On-Screen Display (OSD) menu position.
EM SET	Closed Caption	Closed Caption Enable Activates the function by selecting On when the selected input signal carries closed captions.
5. SYSTEM SETUP: Advanced menu		• Captions: An on-screen display of the dialogue, narration, and sound effects of TV programs and videos that are closed captioned (usually marked as "CC" in TV listings).
inced m		This function is only available when a Composite video or S-Video input signal is selected and its system format is NTSC.
ent		Caption Version
		Selects a preferred closed captioning mode. To view captions, select CC1, CC2, CC3, or CC4 (CC1 displays captions in the primary language in your area).
		Lamp Mode See "Setting Lamp Mode as Economic" on page 57 for details.
	Lamp Settings	Reset Lamp Timer See "Resetting the lamp timer" on page 61 for details.
		Equivalent Lamp Hour See "Getting to know the lamp hour" on page 57 for details on how the total lamp hour is calculated.
	Presentation Timer	Reminds the presenter to finish the presentation within a certain time frame. See "Setting the presentation timer" on page 36 for details.

Function		Description	
5. SYST	Security Settings	See "Utilizing the password function" on page 24 for details.	
	Remote Control Code	See "Remote control code" on page 9 for details.	
5. SYSTEM SETUP: Advanced menu	Reset All Settings	Returns all settings to the factory preset values. The following settings will still remain: Phase, H. Size, User 1, User 2, Language, Projector Position, High Altitude Mode, Security Settings.	
6. INFORMATION menu	Current System Status	Shows the current signal source. Color Mode Shows the selected mode in the PICTURE menu. Resolution Shows the native resolution of the input signal. Color System Shows input system format, NTSC, PAL, SECAM, or RGB. Equivalent Lamp Hour Displays the number of hours the lamp has been used. MAC Address Shows the MAC Address of your projector. MAC Address stands for Media Access Control Address, which is a physical layer address used to uniquely identify a network node.	

Care of the projector

Your projector needs little maintenance. The only thing you need to do on a regular basis is to keep the lens clean.

Never remove any parts of the projector except the lamp. Contact your dealer if other parts need replacing.

Cleaning the lens

Clean the lens whenever you notice dirt or dust on the surface.

- Use a canister of compressed air to remove dust.
- If there is dirt or smears, use lens-cleaning paper or moisten a soft cloth with lens cleaner and gently wipe the lens surface.



Never rub the lens with abrasive materials.

Cleaning the projector case

Before you clean the case, turn the projector off using the proper shutdown procedure as described in "Shutting down the projector" on page 45 and unplug the power cord.

- To remove dirt or dust, wipe the case with a soft, lint-free cloth.
- To remove stubborn dirt or stains, moisten a soft cloth with water and a neutral pH detergent. Then wipe the case.

! CAUTION

Never use wax, alcohol, benzene, thinner or other chemical detergents. These can damage the case.

Storing the projector

If you need to store the projector for an extended time, please follow the instructions below:

- Make sure the temperature and humidity of the storage area are within the recommended range for the projector. Please refer to "Specifications" on page 64 or consult your dealer about the range.
- · Retract the adjuster feet.
- Remove the battery from the remote control.
- Pack the projector in its original packing or equivalent.

Transporting the projector

It is recommended that you ship the projector with its original packing or equivalent.

Lamp information

Getting to know the lamp hour

When the projector is in operation, the duration (in hours) of lamp usage is automatically calculated by the built-in timer.

To obtain the lamp hour information:

- 1. Press **MENU/EXIT** on the projector or **Menu** on the remote control and then press $\langle \rangle$ until the **SYSTEM SETUP: Advanced** menu is highlighted.
- 2. Press ▼ to highlight Lamp Settings and press MODE/ENTER on the projector or ENTER on the remote control. The Lamp Settings page is displayed.
- 3. You will see the **Equivalent lamp hour** information on the menu.
- 4. To leave the menu, press **MENU/EXIT** on the projector or **Exit** on the remote control.

You can also get the lamp hour information on the **INFORMATION** menu.

Extending lamp life

The projection lamp is a consumable item. To keep the lamp life as long as possible, you can do the following settings via the OSD menu.

Setting Lamp Mode as Economic

Using **Economic** mode reduces system noise and power consumption by 20%. If the **Economic** mode is selected, the light output will be reduced and result in darker projected pictures.

Setting the projector in **Economic** mode also extends the lamp operation life. To set **Economic** mode, go into the **SYSTEM SETUP:** Advanced > Lamp Settings > Lamp Mode menu and press </>> .

Setting Auto Power Off

This function allows the projector to turn off automatically if no input source is detected after a set period of time to prevent unnecessary waste of lamp life.

To set **Auto Power Off**, go into the **SYSTEM SETUP: Basic** > **Auto Power Off** menu and press </>> > . If the preset time lengths are not suitable for your presentation, select **Disable**. The projector will not automatically shut down in a certain time period.

Timing of replacing the lamp

When the **Lamp indicator** lights up red or a message appears suggesting it is time to replace the lamp, please install a new lamp or consult your dealer. An old lamp may cause a malfunction in the projector and in some instances the lamp may explode.

/!\CAUTION

The Lamp indicator light and Temperature warning light will light up if the lamp becomes too hot. Turn the power off and let the projector cool for 45 minutes. If the Lamp or Temp indicator still lights up after turning the power back on, please contact your dealer. See "Indicators" on page 62 for details.

The following lamp warning displays will remind you to change the lamp.

Status	Message
Install a new lamp for optimal performance. If the projector is normally run with Economic selected (See "Setting Lamp Mode as Economic" on page 57), you may continue to operate the projector until the next hour lamp warning appears.	Order Replacement Lamp Lamp > Hours OK
A new lamp should be fitted to avoid the inconvenience when the projector runs out of lamp time.	Replace Lamp Soon Lamp > Hours
It is strongly recommended that you replace the lamp at this age. The lamp is a consumable item. The lamp brightness diminishes with use. This is normal lamp behavior. You can replace the lamp whenever you notice that the brightness level has significantly diminished. If the lamp is not replaced beforehand, it must be replaced when you see this message.	Replace Lamp Now Lamp > Hours Lamp usage time exceeded OK
The lamp MUST be replaced before the projector will operate normally.	Notice Lamp usage time exceeded Replace lamp (refer to User Manual) Then reset lamp timer OK

Replacing the lamp

To prepare a new lamp, contact your dealer and tell the lamp type number.


Type number: RLC-070 (PJD5226w/PJD6223/PJD6353/PJD6353s/PJD6653w/PJD6653ws)
Type number: RLC-071 (PJD6253/PJD6383/PJD6383s/PJD6553w/PJD6683ws)

Type number: RLC-077 (PJD5126/PJD5226)

/!\WARNING

Hg - Lamp contains mercury. Manage in accordance with local disposal laws. See www.lamprecycle.org


- To reduce the risk of electrical shock, always turn the projector off and disconnect the power cord before changing the lamp.
- To reduce the risk of severe burns, allow the projector to cool for at least 45 minutes before replacing the lamp.
- To reduce the risk of injuries to fingers and damage to internal components, use caution
 when removing lamp glass that has shattered into sharp pieces. Before replacing the
 lamp, clean the lamp compartment and dispose of cleaning materials. Be careful of sharp
 edges in the lamp compartment. Wash hands after lamp replacement.
- Only ViewSonic certified lamps are tested with this projector. Use of other lamps may cause electrical shock and fire.
- 1. Turn the power off and disconnect the projector from the wall socket. If the lamp is hot, avoid burns by waiting for approximately 45 minutes until the lamp has cooled.
- 2. Loosen the screws that secure the lamp cover on the both sides of the projector until the lamp cover loosens.




3. Remove the lamp cover from the projector.

/!\warning

- Do not turn the power on with the lamp cover removed.
- Do not insert your fingers between the lamp and the projector. The sharp edges inside the projector may cause injuries.
- 4. Remove and dispose of the lamp protection film.




5. Loosen the screw that secures the lamp.




6. Lift the handle so that it stands up. Use the handle to slowly pull the lamp out of the projector.

/!\CAUTION

- Pulling it too quickly may cause the lamp to break and scatter broken glass in the projector.
- Do not place the lamp in locations where water might splash on it, children can reach it, or near flammable materials.
- Do not insert your hands into the projector after the lamp is removed. If you touch the optical components inside, it could cause color unevenness and distortion of the projected images.
- 7. Insert the new lamp into the lamp compartment and make sure it fits in the projector.







8. Tighten the screw that secures the lamp.

/!\CAUTION

- Loose screw may cause a bad connection, which could result in malfunction.
- · Do not over tighten the screw.
- 9. Ensure the handle is fully laid flat and locked in place.




- 10. Place the lamp protection film supplied with the new lamp on the lamp compartment.
- 11. Replace the lamp cover on the projector.



12. Tighten the screws that secure the lamp cover.

/ CAUTION

- Loose screw may cause a bad connection, which could result in malfunction.
- · Do not over tighten the screws.



13. Restart the projector.

/ CAUTION

Do not turn the power on with the lamp cover removed.

Resetting the lamp timer

- 14. After the startup logo, open the On-Screen Display (OSD) menu.
- 15. Go to the SYSTEM SETUP: Advanced > Lamp Settings menu. Press MODE/ENTER on the projector or ENTER on the remote control. The Lamp Settings page is displayed.
- 16. Press ▼ to highlight Reset lamp timer and press MODE/ENTER on the projector or ENTER on the remote control. A warning message is displayed asking if you want to reset the lamp timer.
- 17. Highlight **Reset** and press **MODE/ENTER** on the projector or **ENTER** on the remote control. The lamp time will be reset to '0'.



Do not reset if the lamp is not new or replaced as this could cause damage.



Indicators

Light			Status & Description
Power	Temp	Lamp	
			Power events
Blue Flashing	Off	Off	Stand-by mode
Blue	Off	Off	Powering up
Blue	Off	Off	Normal operation
			Lamp events
Purple Flashing	Off	Red	The projector has shut down automatically. If you try to restart the projector, it will shut down again. Please contact your dealer for assistance.
Off	Off	Red	 The projector needs 90 seconds to cool down. Or Please contact your dealer for assistance.
			Thermal events
Off	Red	Off	
Off	Red	Red	
Off	Red	Green	
Red	Red	Red	
Red	Red	Green	The projector has shut down automatically. If you try to restart the projector, it will shut down again. Please contact
Blue	Red	Red	your dealer for assistance.
Blue	Red	Green	
Purple	Red	Red	
Purple	Red	Green	
Off	Green	Red	

Troubleshooting

? The projector does not turn on.

Cause	Remedy
There is no power from the power cord.	Plug the power cord into the AC inlet on the projector, and plug the power cord into the power outlet. If the power outlet has a switch, make sure that it is switched on.
Attempting to turn the projector on again during the cooling process.	Wait until the cooling down process has completed.

? No picture

Cause	Remedy
The video source is not turned on or connected correctly.	Turn the video source on and check that the signal cable is connected correctly.
The projector is not correctly connected to the input signal device.	Check the connection.
The input signal has not been correctly selected.	Select the correct input signal with the SOURCE key on the projector or remote control.
The lens cover is still closed.	Open the lens cover.

? Blurred image

Cause	Remedy
The projection lens is not correctly	Adjust the focus of the lens using the focus
focused.	ring.
The projector and the screen are not	Adjust the projection angle and direction as
aligned properly.	well as the height of the projector if necessary.
The lens cover is still closed.	Open the lens cover.

? Remote control does not work

Cause	Remedy
The battery is out of power.	Replace the battery with a new one.
There is an obstacle between the remote control and the projector.	Remove the obstacle.
You are too far away from the projector.	Stand within 8 meters (26 feet) of the projector.

Specifications

Projector specifications



- All specifications are subject to change without notice.
 - Not all models can be purchased in your region.


General	
Product name	DLP Projector
Optical	
Resolution	PJD5126 : 800 x 600 SVGA
	PJD5226/PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383 /PJD6383s: 1024 x 768 XGA
	PJD5226w/PJD6553w/PJD6653w/PJD6653ws/PJD6683w /PJD6383ws: 1280 x 800 WXGA
Display system	1-CHIP DMD
Lamp	PJD5126/PJD5226/PJD5226w/PJD6223/PJD6353/PJD6353s/PJD6653w /PJD6653ws: 180 W lamp
	PJD6253/PJD6383/PJD6383s/PJD6553w/PJD6683w /PJD6683ws: 240 W lamp
Electrical	
Power supply	PJD5126/PJD5226/PJD5226w/PJD6223/PJD6353/PJD6353s/PJD6653w/PJD6653ws: AC100–240V, 2.9 A, 50/60 Hz (Automatic)
	PJD6253/PJD6383/PJD6383s/PJD6553w/PJD6683w/PJD6683ws:
	AC100–240V, 3.5 A, 50/60 Hz (Automatic)
Power consumption	PJD5126/PJD5226/PJD5226w/PJD6223/PJD6353/PJD6353s/PJD6653w/PJD6653ws: 285 W (Max); < 1 W (Standby)
	PJD6253/PJD6383/PJD6383s/PJD6553w/PJD6683w/PJD6683ws:
	350 W (Max); < 1 W (Standby)
Mechanical	
Weight	PJD5126/PJD5226/PJD5226w/PJD6223/PJD6253/PJD6553w : 2.6 Kg (5.74 lbs)
	PJD6353/PJD6353s/PJD6383/PJD6383s/PJD6653w/PJD6653ws/PJD6683 ws: 2.99 Kg (6.6 lbs)

Input terminal	
Computer input	
RGB input	D-Sub 15-pin (female) x 2
Video signal input	D-Sub 13-pin (lemaie) x 2
S-VIDEO	Mini DIN 4-pin port x 1
VIDEO	RCA jack x 1
SD/HDTV signal	
input	
Analog –	D-Sub <-> Component RCA jack x 3 (through RGB input)
Digital –	PJD5126/PJD5226/PJD5226w: N/A
	PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383s/PJD6553w/ PJD6653w/PJD6653ws/PJD6683w/PJD6683ws: HDMI V1.3 x 1
Audio signal input	PC audio jack x 1 PC audio jack x 2
Output termina	al
RGB output	D-Sub 15-pin (female) x 1
Speaker	PJD5126/PJD5226/PJD5226w:
	2 watt x 1
	PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383s/PJD6553w/ PJD6653w/PJD6653ws/PJD6683w/PJD6683ws: 10 watt x 1
Control termin	al
RS-232 serial control	9 pin x 1
LAN	PJD5126/PJD5226/PJD5226w:
	N/A
	PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383/PJD6383s/PJD6553w/PJD6653w/PJD6653ws/PJD6683w/PJD6683ws:
	RJ45 x 1
USB serial control	Type mini B
IR receiver	PJD5126/PJD5226/PJD5226w: x 1 (Front)
	PJD6223/PJD6253/PJD6353/PJD6353s/PJD6383/PJD6383s/PJD6553w/PJD6653w/PJD6653ws/PJD6683w/PJD6683ws:
	x 2 (Front and Top)
Environmenta	Requirements
Operating temperature	0°C–40°C at sea level
Operating relative humidity	10%–90% (without condensation)
Operating altitude	• 0–1499 m at 0°C–35°C
	• 1500–3000 m at 0°C–30°C (with High Altitude Mode on)


Dimensions

294 mm (W) x 84 mm (H) x 242 mm (D) (Excluding extrusions)


PJD5126/PJD5226/PJD5226w/ PJD6223/PJD6253/PJD6553w



PJD6353/PJD6353s/PJD6383s/PJD6653w/PJD6653ws/PJD6683ws



Ceiling mount installation



Timing chart

Supported timing for PC input

Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Frequency (MHz)	Mode
720 x 400	31.469	70.087	28.3221	720 x 400_70
640 x 480	31.469	59.94	25.175	VGA_60
	37.861	72.809	31.5	VGA_72
	37.5	75	31.5	VGA_75
	43.269	85.008	36	VGA_85
	61.91	119.518	52.5	VGA_120
800 x 600	37.879	60.317	40	SVGA_60
	48.077	72.188	50	SVGA_72
	46.875	75	49.5	SVGA_75
	53.674	85.061	56.25	SVGA_85
	30.998	49.916	30.75	SVGA_50
	77.425	119.854	83	SVGA_120
1024 x 768	48.363	60.004	65	XGA_60
	56.476	70.069	75	XGA_70
	60.023	75.029	78.75	XGA_75
	68.667	84.997	94.5	XGA_85
	39.634	49.98	52	XGA_50
	98.958	119.804	137.75	XGA_120
1280 x 800	49.702	59.81	83.5	WXGA_60
	62.795	74.934	106.5	WXGA_75
	71.554	84.88	122.5	WXGA_85
1280 x 1024	63.981	60.020	108.000	SXGA_60
	79.976	75.025	135.000	SXGA_75
	91.146	85.024	157.500	SXGA_85
1280 x 960	60	60	108	1280 x 960_60
1400 x 1050	65.317	59.978	121.75	SXGA+_60
1600 x 1200	75	60	162	UXGA
640 x 480@67Hz	35	66.667	30.24	MAC13
832 x 624@75Hz	49.722	74.546	57.28	MAC16
1024 x 768@75Hz	60.241	75.02	80	MAC19
1152 x 870@75Hz	68.68	75.06	100	MAC21

Supported timing for Component-YPbPr input

Signal Format	Horizontal Frequency (kHz)	Vertical Frequency (Hz)
480i(525i)@60Hz	15.73	59.94
480p(525p)@60Hz	31.47	59.94
576i(625i)@50Hz	15.63	50.00
576p(625p)@50Hz	31.25	50.00
720p(750p)@60Hz	45.00	60.00
720p(750p)@50Hz	37.50	50.00
1080i(1125i)@60Hz	33.75	60.00
1080i(1125i)@50Hz	28.13	50.00
1080P@60Hz	67.5	60
1080P@50Hz	56.26	50

Displaying a 1080i(1125i)@60Hz or 1080i(1125i)@50Hz signal may result in slight image vibration.

Supported timing for Video and S-Video inputs

Video mode	Horizontal	Vertical Frequency	Color sub-carrier	
video mode	Frequency (kHz)	(Hz)	Frequency (MHz)	
NTSC	15.73	60	3.58	
PAL	15.63	50	4.43	
SECAM	15.63	50	4.25 or 4.41	
PAL-M	15.73	60	3.58	
PAL-N	15.63	50	3.58	
PAL-60	15.73	60	4.43	
NTSC4.43	15.73	60	4.43	

Copyright information

Copyright

Copyright 2011. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of ViewSonic Corporation.

Disclaimer

ViewSonic Corporation makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Further, ViewSonic Corporation reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

*DLP and Digital Micromirror Device (DMD) are trademarks of Texas Instruments. Others are copyrights of their respective companies or organizations.

Appendix

IR control table

Code A

Blank	Key	Format	Byte1	Byte2	Byte3	Byte4		
Up / KeyS + NEC	Power	NEC	83	F4	17	E8		
Down / KeyS - NEC	Freeze	NEC	83	F4	03	fc		
Left NEC 83 F4 0e f1 Right NEC 83 F4 0f f0 Color Mode NEC 83 F4 10 ef Mute NEC 83 F4 14 EB Auto Sync NEC 83 F4 08 f7 Source NEC 83 F4 04 fb Blank NEC 83 F4 07 f8 Menu NEC 83 F4 15 ea Exit NEC 83 F4 41 be VGA 1 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 55 AA	Up / KeyS +	NEC	83	F4	0b	f4		
Right NEC 83 F4 Of f0 Color Mode NEC 83 F4 10 ef Mute NEC 83 F4 14 EB Auto Sync NEC 83 F4 08 f7 Source NEC 83 F4 04 fb Blank NEC 83 F4 07 f8 Menu NEC 83 F4 15 ea Exit NEC 83 F4 28 D7 VGA 1 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA	Down / KeyS -	NEC	83	F4	0с	f3		
Color Mode NEC 83 F4 10 ef Mute NEC 83 F4 14 EB Auto Sync NEC 83 F4 08 f7 Source NEC 83 F4 04 fb Blank NEC 83 F4 07 f8 Menu NEC 83 F4 30 CF Enter / Mouse L NEC 83 F4 15 ea Exit NEC 83 F4 41 be VGA 1 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 27 d8 Aspect NEC 83 F4 27 d8 Pattern NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA <tr< td=""><td>Left</td><td>NEC</td><td>83</td><td>F4</td><td>0e</td><td>f1</td><td></td><td></td></tr<>	Left	NEC	83	F4	0e	f1		
Mute NEC 83 F4 14 EB Auto Sync NEC 83 F4 08 f7 Source NEC 83 F4 04 fb Blank NEC 83 F4 07 f8 Menu NEC 83 F4 30 CF Enter / Mouse L key NEC 83 F4 15 ea Exit NEC 83 F4 41 be VGA 1 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 57 A8	Right	NEC	83	F4	Of	f0		
Auto Sync NEC 83 F4 08 f7 Source NEC 83 F4 04 fb Blank NEC 83 F4 07 f8 Menu NEC 83 F4 30 CF Enter / Mouse L key NEC 83 F4 41 be Exit NEC 83 F4 41 be VGA 1 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 31 CE Timer NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 57 A8 Volume + NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Color Mode	NEC	83	F4	10	ef		
Source NEC 83 F4 04 fb Blank NEC 83 F4 07 f8 Menu NEC 83 F4 07 f8 Menu NEC 83 F4 30 CF Enter / Mouse L NEC 83 F4 15 ea Exit NEC 83 F4 41 be VGA 1 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 52 ad Aspect NEC 83 F4 27 d8 Aspect NEC 83 F4 28 D4 Pattern NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 57 A8 <tr< td=""><td>Mute</td><td>NEC</td><td>83</td><td>F4</td><td>14</td><td>EB</td><td></td><td></td></tr<>	Mute	NEC	83	F4	14	EB		
Source	Auto Sync	NEC	83	F4	08	f7	D IDEACCID IDEACCID IDEACCIO	D IDCOES/D IDCO
Menu NEC 83 F4 30 CF Enter / Mouse L key NEC 83 F4 15 ea Exit NEC 83 F4 28 D7 VGA 1 NEC 83 F4 41 be VGA 2 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 31 CE Mouse NEC 83 F4 31 CE Timer NEC 83 F4 13 EC Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C	Source	NEC	83	F4	04	fb	PJD6223/PJD6353/PJD6353s	PJD6553w/PJD
Menu NEC 83 F4 30 CF Enter / Mouse L key NEC 83 F4 15 ea Exit NEC 83 F4 28 D7 VGA 1 NEC 83 F4 41 be VGA 2 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 13 EC Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C <td>Blank</td> <td>NEC</td> <td>83</td> <td>F4</td> <td>07</td> <td>f8</td> <td></td> <td></td>	Blank	NEC	83	F4	07	f8		
key NEC 83 F4 15 ea Exit NEC 83 F4 28 D7 VGA 1 NEC 83 F4 41 be VGA 2 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 27 d8 Aspect NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 82 7D Volume + NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Menu	NEC	83	F4	30	CF	Computer	Computer
VGA 1 NEC 83 F4 41 be VGA 2 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 27 d8 Aspect NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA <td></td> <td>NEC</td> <td>83</td> <td>F4</td> <td>15</td> <td>ea</td> <td></td> <td></td>		NEC	83	F4	15	ea		
VGA 2 NEC 83 F4 45 ba Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 27 d8 Aspect NEC 83 F4 13 EC Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Exit	NEC	83	F4	28	D7		
Video/Mouse R key NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 27 d8 Aspect NEC 83 F4 13 EC Magnify NEC 83 F4 2B D4 Pattern NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	VGA 1	NEC	83	F4	41	be	Meau Burion Exx	Menu My Bitton
Mouse NEC 83 F4 52 ad Mouse NEC 83 F4 31 CE Timer NEC 83 F4 27 d8 Aspect NEC 83 F4 13 EC Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	VGA 2	NEC	83	F4	45	ba		000
Mouse NEC 83 F4 31 CE Timer NEC 83 F4 27 d8 Aspect NEC 83 F4 13 EC Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA		NEC	83	F4	52	ad		
Aspect NEC 83 F4 13 EC Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Mouse	NEC	83	F4	31	CE		
Magnify NEC 83 F4 32 CD DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Timer	NEC	83	F4	27	d8		
DynamicEco™ NEC 83 F4 2B D4 Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Aspect	NEC	83	F4	13	EC		
Pattern NEC 83 F4 55 AA My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Magnify	NEC	83	F4	32	CD		
My Button NEC 83 F4 56 A9 Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	DynamicEco™	NEC	83	F4	2B	D4		
Panel Key Lock NEC 83 F4 57 A8 Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Pattern	NEC	83	F4	55	AA		
Volume + NEC 83 F4 82 7D Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	My Button	NEC	83	F4	56	A9		
Volume - NEC 83 F4 83 7C PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Panel Key Lock	NEC	83	F4	57	A8		
PgUp NEC 83 F4 06 F9 PgDn NEC 83 F4 05 FA	Volume +	NEC	83	F4	82	7D		
PgDn NEC 83 F4 05 FA	Volume -	NEC	83	F4	83	7C		
	PgUp	NEC	83	F4	06	F9		
Info NEC 83 F4 97 68	PgDn	NEC	83	F4	05	FA		
	Info	NEC	83	F4	97	68		

Code B

Key	Format	Byte1	Byte2	Byte3	Byte4
Power	NEC	83	F4	60	9F
Freeze	NEC	83	F4	61	6E
Up / KeyS +	NEC	83	F4	67	98
Down / KeyS -	NEC	83	F4	68	97
Left	NEC	83	F4	69	96
Right	NEC	83	F4	6A	95
Color Mode	NEC	83	F4	9E	61
Mute	NEC	83	F4	9D	62
Auto Sync	NEC	83	F4	63	9C
Source	NEC	83	F4	7D	82
Blank	NEC	83	F4	62	9D
Menu	NEC	83	F4	6C	93
Enter / Mouse L key	NEC	83	F4	6B	94
Exit	NEC	83	F4	6E	91
VGA 1	NEC	83	F4	64	9B
VGA 2	NEC	83	F4	65	9A
Video/Mouse R key	NEC	83	F4	66	99
Mouse	NEC	83	F4	9B	64
Timer	NEC	83	F4	9C	63
Aspect	NEC	83	F4	9A	65
Magnify	NEC	83	F4	99	66
DynamicEco™	NEC	83	F4	7F	80
Pattern	NEC	83	F4	7E	81
My Button	NEC	83	F4	6D	92
Panel Key Lock	NEC	83	F4	5E	A1
Volume +	NEC	83	F4	5A	A5
Volume -	NEC	83	F4	5B	A4
PgUp	NEC	83	F4	5D	A2
PgDn	NEC	83	F4	5C	A3
Info	NEC	83	F4	5F	A0

PJD5126/PJD5226/PJD5226w/ PJD6223/PJD6353/PJD6353s PJD6653w/PJD6653ws



PJD6253/PJD6383/PJD6383s/ PJD6553w/PJD6683w PJD6683ws



RJ45 response table

Status	Response	Response Code
	Normal => ACK	0x03 0x14 0x00 0x00 0x00 0x14
Write	Incorrect => ERROR ACK	0x00 0x14 0x00 0x00 0x00 0x14
	Timeout (>100ms)	N/A

Status		Response Code							
	BYTE0	BYTE0 BYTE1 BYTE2 BYTE3 BYTE4 BYTE5 BYTE6 BYTE7~N BYTE						E N+1	
	0x05	0x05							ksum
Read	Ex1. Re	x1. Read power status: 0x05 0x14 0x00 0x03 0x00 0x00 0x00 0x01 0x18 = On							
rtodd	Ex2. Re	x2. Read brightness: 0x05 0x14 0x00 0x04 0x00 0x00 0x00 0x32 0x00 0x4A = 50							
		Ex3. Read lamp hours: 0x05 0x14 0x00 0x06 0x00 0x00 0x00 0x28 0x00 0x4A = 30 0x00 0x00 0x00 0x42 = 40							

RS232 command table

<Pin assignment for this two end>

Pin	Description	Pin	Description	
1	NC	2	RX	10 Data carrier detect
3	TX	4	NC	70 Receive data 70 Request to send 30 Transmit data
5	GND	6	NC	40 Clear to send 40 Data terminal ready 90 Ring indicator
7	RTSZ	8	CTSZ	50 Signal ground Protective ground
9	NC			- Protective ground

<Interface>

RS-232 protocol					
Baud Rate	115200 bps (default)				
Data Length	8 bit				
Parity Check	None				
Stop Bit	1 bit				
Flow Control	None				

<RS232/RJ45 command table>

Function	Status	Action	cmd
	Write	Turn on	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x00 0x00 0x5D
Power	vviite	Turn off	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x01 0x00 0x5E
	Read	Power status (on/off)	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x11 0x00 0x5E

The RJ45 commands can only be received via TCP port 4661.
 Please refer to the below RS232 command table for the commands.

Reset	Execute		0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x02 0x00 0x5F
		Splash Screen Black	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0A 0x00 0x67
		Splash Screen Blue	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0A 0x01 0x68
	Write	Splash Screen ViewSonic	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0A 0x02 0x69
Splash Screen		Splash Screen Screen Capture	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0A 0x03 0x6A
		Splash Screen Off	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0A 0x04 0x6B
	Read	Splash Screen status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x11 0x0A 0x68
	Write	Quick Power Off Off	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0B 0x00 0x68
Quick Power Off	vviite	Quick Power Off On	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0B 0x01 0x69
	Read	Quick Power Off status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x11 0x0B 0x69
	Write	High Altitude Mode Off	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0C 0x00 0x69
High Altitude Mode	vviite	High Altitude Mode On	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x0C 0x01 0x6A
	Read	High Altitude Mode status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x11 0x0C 0x6A
	Write	Lamp Mode Normal	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x10 0x00 0x6D
Lamp Mode	vvnie	Lamp Mode Economic	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x10 0x01 0x6E
	Read	Lamp Mode status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x11 0x10 0x6E
Message	Write	Message Off	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x27 0x00 0x84
	vvrite	Message On	0x06 0x14 0x00 0x04 0x00 0x34 0x11 0x27 0x01 0x85
	Read	Message status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x11 0x27 0x85

		Front Table	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x00 0x00 0x5E
	Write	Rear Table	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x00 0x01 0x5F
Projector	VVIIIG	Rear Ceiling	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x00 0x02 0x60
Position		Front Ceiling	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x00 0x03 0x61
	Read	projector position status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x00 0x5F
		OFF	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x20 0x00 0x7E
3D Sync	Write	TI 3D DLP Link	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x20 0x01 0x7F
	Read	3D Sync Status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x20 0x7F
	Write	Off	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x21 0x00 0x7F
3D Sync Invert	vvnie	On	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x21 0x01 0x80
mvert	Read	3D Sync Invert Status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x21 0x80
	Write	Contrast decrease	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x02 0x00 0x60
Contrast	vviite	Contrast increase	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x02 0x01 0x61
	Read	Contrast ratio	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x02 0x61
	Write	Brightness decrease	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x03 0x00 0x61
Brightness	vviite	Brightness increase	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x03 0x01 0x62
	Read	Brightness	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x03 0x62
		Aspect ratio Auto	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x04 0x00 0x62
	Write	Aspect ratio 4:3	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x04 0x02 0x64
Aspect ratio	VVIILE	Aspect ratio 16:9	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x04 0x03 0x65
		Aspect ratio 16:10	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x04 0x04 0x66
	Read	Aspect ratio	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x04 0x63
Auto Adjust	Excute		0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x05 0x00 0x63

	\0/-:	Horizontal position shift right	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x06 0x01 0x65
Horizontal position	Write	Horizontal position shift left	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x06 0x00 0x64
	Read	Horizontal position	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x06 0x65
	Write	Vertical position shift up	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x07 0x00 0x65
Vertical position	vviite	Vertical position shift down	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x07 0x01 0x66
	Read	read Vertical position	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x07 0x66
		color temperature T1	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x08 0x00 0x66
	Write	color temperature T2	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x08 0x01 0x67
Color temperature	vviite	color temperature T3	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x08 0x02 0x68
		color temperature T4	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x08 0x03 0x69
	Read	color temperature status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x08 0x67
)A/.'(.	Blank on	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x09 0x01 0x68
Blank	Write	Blank off	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x09 0x00 0x67
Read	Read	Blank status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x09 0x68
	\\/-:t-c	Decrease	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0A 0x00 0x68
Keystone- Vertical	Write	Increase	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0A 0x01 0x69
vertical	Read	Keystone status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x0A 0x69

Color mode		Brightest	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x00 0x69	
		Movie	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x01 0x6A	
	Write	User 1	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x02 0x6B	
		User 2	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x03 0x6C	
		PC / Gaming	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x04 0x6D	
		ViewMatch	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x05 0x6E	
		Dynamic PC	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x06 0x6F	
		Dynamic Movie	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x0B 0x07 0x70	
	Read	Preset mode status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x0B 0x6A	
	Write	Primary color R	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x10 0x00 0x6E	
		Primary color G	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x10 0x01 0x6F	
		Primary color B	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x10 0x02 0x70	
Primary Color		Primary color C	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x10 0x03 0x71	
		Primary color M	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x10 0x04 0x72	
		Primary color Y	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x10 0x05 0x73	
	Read	Primary color status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x10 0x6F	
	Write	Hue decrease	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x11 0x00 0x6F	
Hue		Hue increase	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x11 0x01 0x70	
	Read	Hue	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x11 0x70	
	Write	Saturation decrease	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x12 0x00 0x70	
Saturation		Saturation increase	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x12 0x01 0x71	
	Read	Saturation	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x12 0x71	

Gain	Write	Gain decrease	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x13 0x00 0x71		
		Gain increase	0x06 0x14 0x00 0x04 0x00 0x34 0x12 0x13 0x01 0x72		
	Read	Gain	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x12 0x13 0x72		
	144.5	Freeze on	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x00 0x01 0x60		
Freeze	Write	Freeze off	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x00 0x00 0x5F		
	Read	Freeze status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x13 0x00 0x60		
	Write	Input source VGA	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x01 0x00 0x60		
		Input source VGA2	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x01 0x08 0x68		
Source		Input source Composite	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x01 0x05 0x65		
input		Input source SVIDEO	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x01 0x06 0x66		
		Input source HDMI	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x01 0x03 0x63		
	Read	Source	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x13 0x01 0x61		
Quick Auto Search	Write	Quick Auto Search on	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x02 0x01 0x62		
		Quick Auto Search off	0x06 0x14 0x00 0x04 0x00 0x34 0x13 0x02 0x00 0x61		
	Read	Quick Auto Search status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x13 0x02 0x62		
	\\\/-:t-	Mute on	0x06 0x14 0x00 0x04 0x00 0x34 0x14 0x00 0x01 0x61		
Mute	Write	Mute off	0x06 0x14 0x00 0x04 0x00 0x34 0x14 0x00 0x00 0x60		
	Read	Mute status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x14 0x00 0x61		
	Write	Increse Volume	0x06 0x14 0x00 0x04 0x00 0x34 0x14 0x01 0x00 0x61		
Volume		Decrese Volume	0x06 0x14 0x00 0x04 0x00 0x34 0x14 0x02 0x00 0x62		
	Read	Volume	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x14 0x03 0x64		

Lamp Time	Write	Reset Lamp usuage hour	0x06 0x14 0x00 0x04 0x00 0x34 0x15 0x01 0x00 0x62	
	Read	Lamp usuage hour	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x15 0x01 0x63	
Error status	Read	Read error status	0x07 0x14 0x00 0x05 0x00 0x34 0x00 0x00 0x0C 0x0D 0x66	

Customer Support

For technical support or product service, see the table below or contact your reseller.

Note: You will need the product serial number.

Country/Region	Web Site	T=Telephone F=Fax	E-mail
Australia/New Zealand	www.viewsonic.com.au	AUS=1800 880 818 NZ=0800 008 822	service@au.viewsonic.com
Canada	www.viewsonic.com	T (Toll-Free)= 1-866-463-4775 T (Toll)= 1-424-233-2533 F= 1-909-468-3757	service.ca@viewsonic.com
Europe	www.viewsoniceurope.	www.viewsoniceurope.com/uk/support/	call-desk/
Hong Kong	www.hk.viewsonic.com	T= 852 3102 2900	service@hk.viewsonic.com
India	www.in.viewsonic.com	T= 1800 266 0101	service@in.viewsonic.com
Ireland (Eire)	www.viewsoniceurope.	www.viewsoniceurope.com/uk/sup- port/call-desk/	service_ie@viewsoni- ceurope.com
Korea	www.kr.viewsonic.com	T= 080 333 2131	service@kr.viewsonic.com
Latin America (Argentina)	www.viewsonic.com/la/	T= 0800-4441185	soporte@viewsonic.com
Latin America (Chile)	www.viewsonic.com/la/	T=1230-020-7975	soporte@viewsonic.com
Latin America (Columbia)	www.viewsonic.com/la/	T= 01800-9-157235	soporte@viewsonic.com
Latin America (Mexico)	www.viewsonic.com/la/	T= 001-8882328722	soporte@viewsonic.com
Electroser, Av Reforma	No. 403Gx39 y 41, 97000 M	PUEBLA, PUE. Tel: 01.222.891.55.77 CON Ierida, Yucatan. Tel: 01.999.925.19.16 pm/la/soporte/index.htm#Mexico	N 10 LINEAS
Latin America (Peru)	www.viewsonic.com/la/	T= 0800-54565	soporte@viewsonic.com
Macau	www.hk.viewsonic.com	T= 853 2870 0303	service@hk.viewsonic.com
Middle East	ap.viewsonic.com/me/	Contact your reseller	service@ap.viewsonic.com
Puerto Rico & Virgin Islands	www.viewsonic.com	T= 1-800-688-6688 (English) T= 1-866-379-1304 (Spanish) F= 1-909-468-3757	service.us@viewsonic.com soporte@viewsonic.com
Singapore/Malaysia/ Thailand	www.viewsonic.com.sg	T= 65 6461 6044	service@sg.viewsonic.com
South Africa	ap.viewsonic.com/za/	Contact your reseller	service@ap.viewsonic.com
United Kingdom	www.viewsoniceurope.	www.viewsoniceurope.com/uk/sup- port/call-desk/	service_gb@viewsoni- ceurope.com
United States	www.viewsonic.com	T (Toll-Free)= 1-800-688-6688 T (Toll)= 1-424-233-2530 F= 1-909-468-3757	service.us@viewsonic.com

Limited Warranty

VIEWSONIC® PROJECTOR

What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship, under normal use, during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, repair or replace the product with a like product. Replacement product or parts may include remanufactured or refurbished parts or components.

Limited Three (3) year General Warranty

Subject to the more limited one (1) year warranty set out below, North and South America: Three (3) years warranty for all parts excluding the lamp, three (3) years for labor, and one (1) year for the original lamp from the date of the first consumer purchase; Europe except Poland: Three (3) years warranty for all parts excluding the lamp, three (3) years for labor, and ninety (90) days for the original lamp from the date of the first consumer purchase; Poland: Two (2) years warranty for all parts excluding the lamp, two (2) years for labor, and ninety (90) days for the original lamp from the date of the first consumer purchase.

Limited One (1) year Heavy Usage Warranty:

Under heavy usage settings, where a projector's use includes more than fourteen (14) hours average daily usage, North and South America: One (1) year warranty for all parts excluding the lamp, one (1) year for labor, and ninety (90) days for the original lamp from the date of the first consumer purchase; Europe: One (1) year warranty for all parts excluding the lamp, one (1) year for labor, and ninety (90) days for the original lamp from the date of the first consumer purchase.

Other regions or countries: Please check with your local dealer or local ViewSonic office for the warranty information.

Lamp warranty subject to terms and conditions, verification and approval. Applies to manufacturer's installed lamp only. All accessory lamps purchased separately are warranted for 90 days.

Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

What the warranty does not cover:

- 1. Any product on which the serial number has been defaced, modified or removed.
- 2. Damage, deterioration, failure, or malfunction resulting from:
 - a. Accident, abuse, misuse, neglect, fire, water, lightning, or other acts of nature, improper maintenance, unauthorized product modification, or failure to follow instructions supplied with the product.
 - b. Operation outside of product specifications.
 - c. Operation of the product for other than the normal intended use or not under normal conditions.
 - d. Repair or attempted repair by anyone not authorized by ViewSonic.
 - e. Any damage of the product due to shipment.
 - f. Removal or installation of the product.
 - g. Causes external to the product, such as electric power fluctuations or failure.
 - h. Use of supplies or parts not meeting ViewSonic's specifications.

- i. Normal wear and tear.
- j. Any other cause which does not relate to a product defect.
- 3. Removal, installation, and set-up service charges.

How to get service:

- 1. For information about receiving service under warranty, contact ViewSonic Customer Support (please refer to "Customer Support" page). You will need to provide your product's serial number.
- 2. To obtain warranted service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
- **3.** Take or ship the product freight prepaid in the original container to an authorized ViewSonic service center or ViewSonic.
- **4.** For additional information or the name of the nearest ViewSonic service center, contact ViewSonic.

Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

Exclusion of damages:

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

- 1. Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
- 2. Any other damages, whether incidental, consequential or otherwise.
- 3. Any claim against the customer by any other party.

Effect of state law:

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

Sales outside the U.S.A. and Canada:

For warranty information and service on ViewSonic products sold outside of the U.S.A. and Canada, contact ViewSonic or your local ViewSonic dealer.

The warranty period for this product in mainland China (Hong Kong, Macao and Taiwan Excluded) is subject to the terms and conditions of the Maintenance Guarantee Card.

For users in Europe and Russia, full details of warranty provided can be found in www.viewsoniceurope. com under Support/Warranty Information.

4.3: Projector Warranty

PRJ_LW01 Rev. 1h 06-25-07

Mexico Limited Warranty VIEWSONIC® PROJECTOR

What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship, under normal use, during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, repair or replace the product with a like product. Replacement product or parts may include remanufactured or refurbished parts or components & accessories.

How long the warranty is effective:

3 years for all parts excluding the lamp, 3 years for labor, 1 year for the original lamp from the date of the first consumer purchase.

Lamp warranty subject to terms and conditions, verification and approval. Applies to manufacturer's installed lamp only.

All accessory lamps purchased separately are warranted for 90 days.

Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

What the warranty does not cover:

- 1. Any product on which the serial number has been defaced, modified or removed.
- 2. Damage, deterioration or malfunction resulting from:
 - a. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, unauthorized attempted repair, or failure to follow instructions supplied with the product.
 - b. Any damage of the product due to shipment.
 - c. Causes external to the product, such as electrical power fluctuations or failure.
 - d. Use of supplies or parts not meeting ViewSonic's specifications.
 - e. Normal wear and tear.
 - f. Any other cause which does not relate to a product defect.
- 3. Any product exhibiting a condition commonly known as "image burn-in" which results when a static image is displayed on the product for an extended period of time.
- 4. Removal, installation, insurance, and set-up service charges.

How to get service:

For information about receiving service under warranty, contact ViewSonic Customer Support (Please refer to the attached Customer Support page). You will need to provide your product's serial number, so please record the product information in the space provided below on your purchase for your future use. Please retain your receipt of proof of purchase to support your warranty claim.

roi roui records		
Product Name:	Model Number:	
Document Number:	Serial Number:	
Purchase Date:	Extended Warranty Purchase?	(Y/N)
	If so, what date does warranty expire?	

- 1. To obtain warranty service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
- 2. Take or ship the product in the original container packaging to an authorized ViewSonic service center.
- 3. Round trip transportation costs for in-warranty products will be paid by ViewSonic.

Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

Exclusion of damages:

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

- 1. Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
- 2. Any other damages, whether incidental, consequential or otherwise.
- 3. Any claim against the customer by any other party.
- 4. Repair or attempted repair by anyone not authorized by ViewSonic.

Contact Information for Sales & Authorized Service (Centro Autorizado de Servicio) within Mexico: Name, address, of manufacturer and importers: México, Av. de la Palma #8 Piso 2 Despacho 203, Corporativo Interpalmas, Col. San Fernando Huixquilucan, Estado de México Tel: (55) 3605-1099 http://www.viewsonic.com/la/soporte/index.htm NÚMERO GRATIS DE ASISTENCIA TÉCNICA PARA TODO MÉXICO: 001.866.823.2004 Hermosillo: Villahermosa: Distribuciones y Servicios Computacionales SA de CV. Compumantenimietnos Garantizados, S.A. de C.V. Calle Juarez 284 local 2 AV. GREGORIO MENDEZ #1504 Col. Bugambilias C.P: 83140 COL, FLORIDA C.P. 86040 Tel: 01-66-22-14-9005 Tel: 01 (993) 3 52 00 47 / 3522074 / 3 52 20 09 E-Mail: disc2@hmo.megared.net.mx E-Mail: compumantenimientos@prodigy.net.mx Puebla, Pue. (Matriz): Veracruz, Ver.: RENTA Y DATOS, S.A. DE C.V. Domicilio: CONEXION Y DESARROLLO, S.A DE C.V. Av. Americas # 419 ENTRE PINZÓN Y ALVARADO 29 SUR 721 COL. LA PAZ 72160 PUEBLA, PUE. Fracc, Reforma C.P. 91919 Tel: 01(52).222.891.55.77 CON 10 LINEAS Tel: 01-22-91-00-31-67 E-Mail: datos@puebla.megared.net.mx E-Mail: gacosta@qplus.com.mx Chihuahua Cuernavaca Soluciones Globales en Computación Compusupport de Cuernavaca SA de CV C. Magisterio # 3321 Col. Magisterial Francisco Leyva # 178 Col. Miguel Hidalgo Chihuahua, Chih. C.P. 62040, Cuernavaca Morelos Tel: 4136954 Tel: 01 777 3180579 / 01 777 3124014 E-Mail: Cefeo@soluglobales.com E-Mail: aquevedo@compusupportcva.com Distrito Federal: Guadalajara, Jal.: QPLUS, S.A. de C.V. SERVICRECE, S.A. de C.V. Av. Niños Héroes # 2281 Av. Covoacán 931 Col. Del Valle 03100, México, D.F. Col. Arcos Sur, Sector Juárez Tel: 01(52)55-50-00-27-35 44170, Guadalajara, Jalisco Tel: 01(52)33-36-15-15-43 E-Mail: gacosta@qplus.com.mx E-Mail: mmiranda@servicrece.com Guerrero Acapulco Monterrey: GS Computación (Grupo Sesicomp) Global Product Services Progreso #6-A, Colo Centro Mar Caribe # 1987, Esquina con Golfo Pérsico 39300 Acapulco, Guerrero Fracc. Bernardo Reyes, CP 64280 Tel: 744-48-32627 Monterrey N.L. México Tel: 8129-5103 E-Mail: aydeem@gps1.com.mx MERIDA: Oaxaca, Oax.: **ELECTROSER** CENTRO DE DISTRIBUCION Y Av Reforma No. 403Gx39 y 41 SERVICIO, S.A. de C.V. Mérida, Yucatán, México CP97000 Murguía # 708 P.A., Col. Centro, 68000, Oaxaca Tel: (52) 999-925-1916 Tel: 01(52)95-15-15-22-22 E-Mail: rrrb@sureste.com Fax: 01(52)95-15-13-67-00 E-Mail. gpotai2001@hotmail.com Tiiuana: FOR USA SUPPORT: STD ViewSonic Corporation Av Ferrocarril Sonora #3780 L-C 381 Brea Canyon Road, Walnut, CA. 91789 USA Col 20 de Noviembre Tel: 800-688-6688 (English); 866-323-8056 (Spanish); Tijuana, Mexico Fax: 1-800-685-7276 E-Mail: http://www.viewsonic.com

4.3: ViewSonic Mexico Limited Warranty

PRJ_LW03 Rev. 1A 06-25-07

