Crudex Controls Pvt. Ltd.

Synergies with Energies

USER MANUAL

FUEL DISPENSERS
LAST UPDATE: 23-05-2025
SW VER:
HW VER:

Crudex Controls Pvt. Ltd.
10 DESAI APPARTEMENT, GOTRI RD, OPP. DEV COMMERCIAL CENTER, VADODARA, GUJARAT 390021
(+91)-8000118085
inquiry@crudexcontrols.com
http://www.crudexcontrols.com/

Contents

Version History **6**

Modes of Dispenser

Boot Mode 7

Standby Mode 7

Dispensing Mode 7

Function Mode 7

Query Mode 8

Error Mode 8

Firmware Mode 8

Calibration Modes

Auto Calibration Mode 9

Manual Calibration Mode 9

Common Instructions for Operator

Normal Dispensing 10

Large Dispensing 10

Preset Dispensing 10

Preset Liter Mode 10

Preset Amount Mode 11

Quantitative Repeat Dispensing 11

Preset Liter Mode 11

Preset Amount Mode 11

Shift Settlement 12

Amount Round-Off 12

Volume Round-Off 12

Printing Operations 13

Query Mode Operations 13

List of Function Number & Its Description

Function Code – [11] Dispenser Id 19

Function Code – [12] Set Admin Password 19

Function Code – [13] Lock Dispenser 20

Function Code – [14] Lock Time....20
Function Code – [15] Calibration Lock....18
Function Code – [16] Set Price Lock....18
Function Code – [17] Set Boot Type....19
Function Code – [18] Set Printer Configuration....19
Function Code – [19] Set Currency Type....19
Function Code – [20] Set Product Type....20
Function Code – [21] Set Buzzer Flag....20
Function Code – [22] Set Backlight Flag....20
Function Code – [23] Set Test Mode....21
Function Code – [24] Set RFID Flag....21
Function Code – [25] Set OTP Flag....21
Function Code – [26] Set Urea Sensor Type....22
Function Code – [27] Set Debug....22
Function Code – [28] To Set Hide Password....22
Function Code – [29] Set Tank Flag....22
Function Code – [30] Set Tank Level Po....23
Function Code – [31] Set Tank Level Height....23
Function Code – [32] Set Tank Level Low....23
Function Code – [33] Set Baud Rate....24
Function Code – [34] Set Fueling Timeout....24
Function Code – [35] Set Nozzle Timeout....24
Function Code – [36] Set Minimum Raise....25
Function Code – [37] Set Leakage Volume....25
Function Code – [38] Set Communication Flag....25
Function Code – [39] Set Logo Flag....25
Function Code – [40] Set Audio Flag....26
Function Code – [41] Set Urea Flag....26
Function Code – [42] Set Vehicle Flag....26
Function Code – [43] Set Flow Meter Type....27
Function Code – [44] Set Calibration Manual....27
Function Code – [45] Set Calibration Auto....27
Function Code – [46] Set Print Slip Format....27
Function Code – [47] Set Display Delay....28

Function Code – [48] Set Tank Volume 20
Function Code – [49] Set LV Open Volume....18
Function Code – [50] Set LV Close Volume....18
Function Code – [51] Set Payment Type 19
Function Code – [52] Set Payment Entry 19
Function Code – [53] Set Remote Preset 19
Function Code – [54] Set Calibration Log 20
Function Code – [55] Low Percent 20
Function Code – [56] Set Pressure Flag....20
Function Code – [57] Set Password Advance 21
Function Code – [58] Tank Calibration Full 21
Function Code – [59] Tank Calibration Empty....21
Function Code – [60] Date/Time Update 22
Function Code – [61] Set Quantitative Flag....22
Function Code – [62] Set Quantitative Volume 22
Function Code – [63] Set Quantitative Amount....22
Function Code – [64] Set Emergency Dispense 23
Function Code – [65] Set Large Dispense 23
Function Code – [66] Set Maximum Volume Preset Value 24
Function Code – [67] Set Maximum Amount Preset Value....24
Function Code – [68] Set Maximum Preset Value For (P1 – P3)....25
Function Code – [69] Set Maximum Preset-P1 Value....25
Function Code – [70] Set Maximum Preset-P2 Value....25
Function Code – [71] Set Maximum Preset-P3 Value....25
Function Code – [72] Set Maximum Preset-P4 Value....25
Function Code – [73] Set Preset-1 (P1) Type Flag 26
Function Code – [74] Set Preset-2 (P2) Type Flag....26
Function Code – [75] Set Preset-3 (P3) Type Flag....26
Function Code – [76] Set Preset-4 (P4) Type Flag....26
Function Code – [77] Clear Data 27
Function Code – [78] Urea Value....27

Function Code – [79] Urea Calibration Type 27
Function Code – [80] Set Unit Price 27
Function Code – [81] Set Base Password 28
Function Code – [82] Display Last Flow Count 26
Function Code – [83] Display Urea Data 26
Function Code – [84] Set Tank Lock 45
Function Code – [85] Set Panel Door Handling 45
Function Code – [86] Set Manhole Door Handling 45
Function Code – [87] Set Inlet Valve Open 46
Function Code – [88] Pulsar Registration 46

Version History

VERSION NO.	DETAILS	PREPARED BY	APPROVED BY	DATE
5.0.0.1	Document Prepared	Adityasinh Gohil (SW)	Mihir Patel	October-2025

Modes of Dispenser

Boot Mode

- This mode will occur when the user power on the dispenser.
- Then the power check, Peri Init and Config read is displayed on GLCD.
- Once the dispenser is powered, the LCD displays 0-9 in full screen.
- If all digits are visible on display, then the display is working properly.
- Then software and hardware version are displayed on GLCD.
- After that the system enters in the Standby mode.

Standby Mode

This is the idle state of the Dispenser System. In standby mode,

- First line on the LCD, displays the amount (in currency) of the last fuel dispensed.
- Second line on the LCD, displays the litres of the last fuel dispensed.
- The third line shows the current unit price.
- User can switch to various modes like Settings, Query, Error, Functions, Print, and Dispensing from this mode.

Dispensing Mode

- The user can start the dispensing process by picking up the nozzle after pressing the 'START' key or by lifting nozzle (Configured by the setting).
- After entering this mode, the screen will display the current transaction amount, transaction volume & current unit price.
- Putting the nozzle back into the nozzle holder after pressing the 'STOP' key will end the transaction.
- After completing the dispensing if vehicle entry and payment type are enabled, the user needs to enter vehicle No. and type of payment.

Function Mode

- When the user presses the 'OK' key in the Standby mode, the system enters the function mode.
- In this mode device will prompt the user to enter the function number. The user will enter the function number using digit keys.
- Then press the 'OK' Key to confirm the function number. (If the wrong value is inserted the device will not confirm when the 'OK' key is pressed)
- After this the device will prompt for a password and LCD will display ' _____'.
- After entering the correct password, press 'CLR' key before entering the new value and then, user can modify the value of the function with the help of digit keys.
- In this mode, after modification of the selected function user needs to press the 'OK' key, so the entered value will be stored as per the function & the dispenser will go back to the Standby mode. (If the entered value is not in the specified range, the device will not accept the value).
- In this mode, the user can press the 'STOP' key to go back to Standby mode without changing the value.

Query Mode

- In this mode the user can check the historical data (i.e., transaction details, totalizer data, etc.) which is stored in the dispenser at the time of the particular operations.
- To fetch all the data, the user needs to press the 'QUERY' key in the Standby mode and enter the password to enter the Query mode.
- After entering this mode, the GLCD displays the menu of the Query mode, and the segment LCD displays 'C'. It can be used to check the TXN. details, Totalizer, Daily, Monthly, Shift, Calibration details, yearly.
- User also can print the data fetched from the query mode.
- After the Query is completed, press the 'STOP' key to return to standby mode.

Error Mode

The Dispenser System will automatically enter this mode whenever an error occurs.

- In this mode Segment display will indicate the error code 'E-xx'.
- Buzzer and error LED will give an indication.
- The user can exit this mode by pressing the 'STOP' key which will clear all the system errors and will go back to Standby mode. A list of all error codes is given at the end of the manual.

Firmware Mode

- This mode is used to check the current firmware version of the dispenser.
- To enter the Firmware Mode, the user needs to long Press the 'ZERO (0)' Key in Standby mode.
- After entering in this mode, the dispenser will print the current firmware version with its date.

Calibration Modes

This mode is used to calibrate the dispenser. Be cautious while performing this operation because it will directly impact the accuracy of the transaction.

There are two types of calibration available in this dispenser. They are:

- Auto calibration (function no. 45)
- Manual calibration (function no. 44)

Auto Calibration Mode

- For auto-calibration, go into function no. 45.
- When the nozzle is picked up the motor will start automatically and the user has to dispense "X" volume of fuel.
- The flow count will be displayed on the Segment LCD while the dispensing is on.
- The user will then have to enter the value of the dispensed volume “X” into the dispenser when the dispensing is stopped. Press the ‘OK’ key to complete the auto-calibration process.

Manual Calibration Mode

- For manual calibration, go into function no. 44.
- The user had to enter the pulse count and then press the ‘OK’ key to save the count value. The device will prompt the user to enter litre value, then the user needs to press the ‘OK’ key to save the value of litre and return to Standby mode.

Common Instructions for Operator

Normal Dispensing

- Operator can pick up the nozzle to start the normal dispensing. It will start incrementing in real-time and will show the dispensed amount in currency in the first row of Segment LCD, volume in liter in the second row of Segment LCD & the current set unit price for the fuel in the third row of Segment LCD.
- Putting the nozzle back into the nozzle holder will end the transaction. At the end of the transaction, the screen will show the final count of the filled volume (in litre) and its amount (in currency).
- The maximum allowed transaction limit in this mode is 9999999 litre or Amount (whichever is higher).

Large Dispensing

- By modifying the function no. 59 from zero(0) to one(1) and confirming it, the operator can enter the Large Dispensing mode.
- Operator can pick up the nozzle to start the large dispensing. It will start incrementing in real-time and will show the dispensed volume in litre in the first and second rows both of Segment LCDs, the amount in currency in the GLCD, & the current set unit price for the fuel in the third row of Segment LCD.
- Putting the nozzle back into the nozzle holder will end the transaction. At the end of the transaction, the screen will show the final count of the filled volume (in litre) and its amount (in currency).
- The maximum allowed transaction limit in this mode is 999999999999.99 litre which will be displayed on the Segment LCD and the amount will be displayed on GLCD.

Preset Dispensing

There are three preset dispensing modes and they are,

- Preset litre mode
- Preset amount mode
- Fixed Preset (P1 – P3)

Users can toggle through these modes between Amt/Ltr.

Preset Litre Mode

The operator needs to Press the 'P/L' key to enter the preset Volume dispensing mode. Then need to press the 'CLR' key and enter the value through digit keys for litres required to be filled and then press the 'OK' key to confirm the preset litres. Lift the nozzle to start dispensing. The maximum value limit can be set from the function mode. Please check the function mode for further details.

Preset Amount Mode

The operator needs to Press the 'P/L' key to enter the preset Amount dispensing mode. Then need to press the 'CLR' key and enter the value through digit keys for theamount required and then press the 'OK' key to confirm the preset amount. Lift the nozzle to start dispensing. The maximum value limit can be set from the function mode. Please check the function mode for further details.

Preset Dispensing – Fixed Preset (P1 – P3)

The operator needs to press the 'P1', 'P2', and 'P3' keys to select the fixed preset Volume or Amount in Standby mode. Lift the nozzle to start dispensing. The Value can be configured using the Function Mode. Please check the Function mode for further details.

Quantitative Repeat Dispensing

There are two preset dispensing modes and they are,

- Preset liter mode
- Preset amount mode

The operator needs to enter into the function no. 61 and modify it from Zero(0) to One(1) for Liter and two(2) for Amount, to turn on the Quantitative Repeat Dispensing.

Preset Liter Mode

The operator needs to modify function no. 61 to one(1) and then enter function no. 62 and set the volume of liter's which is required to be dispensed. Press the 'OK' key to save the value and return to the Standby mode. Lift the nozzle to start dispensing. The maximum value limit can be set from the function mode. Please check the function mode for further details.

Preset Amount Mode

The operator needs to modify function no. 61 to two(2) and then enter function no. 63 and set the amount which is required to be dispensed. Press the 'OK' key to save the value and return to the Standby mode. Lift the nozzle to start dispensing. The maximum value limit can be set from the function mode. Please check the function mode for further details.

Shift Settlement

- In order to simplify the shift settlement operation when the operator is off duty, the administrator can long press the 'OK' key in the Standby mode and enter the shift settlement password (BASIC) to handle the shift.
- After the success of the shift settlement process, the dispenser will print the data of the last shift & go into Standby mode.
- It is convenient to check the date of the handover. At this point, the shifting work is completed, and the fueling data will be recorded in the next shift.
- Minimum time between two shifts is **2 Hours**. So, the user can only perform this operation after 2 Hours from the last shift settlement.
- In addition, a maximum of three shift settlements are allowed per day.

SHIFT CHANGE	**REQUIRED BUFFER TIME**
SHIFT 1 □ SHIFT 2 SHIFT 2 □ SHIFT 3	Minimum 2 Hour Minimum 2 Hour
SHIFT 3 □ SHIFT 1	Minimum 1 Day

Amount Round-off

In Dispensing mode, if the user wants to stop the dispensing at his required Value (in currency) he gets two options to do so.

- Press the **dot (.)** key to stop dispensing automatically when the amount value reaches the next multiple of a hundred.
- Press the **AMOUNT** Key to stop automatically when the dispensing amount reaches the next Tens integer value.

Volume Round-off

In Dispensing mode, if the user wants to stop the dispensing at his required Value (in liter's) he gets two options to do so.

- Press the **Zero (0)** key to stop dispensing automatically when the dispensing liter value reaches the next Tens integer liter volume.
- Press the **Liter** key to stop automatically when dispensing liter's to reach the next integer liter's volume.

Printing Operations

In the standby mode, press the 'PRINT' key and enter the **BASE** password to open print menu for printing.

Various print cases are as follows:

1. In standby mode press the 'PRINT' key & then press '1' to print the Last Transaction details in the print slip.
2. In standby mode press the 'PRINT' key & then press '2' to print the Calibration value.
3. In standby mode press the 'PRINT' key & then press '3' to print Totalizer details.
4. In standby mode press the 'PRINT' key & then press '4' to print Current Shift details.
5. In standby mode press the 'PRINT' key & then press '5' to print Daily Record details.
6. In standby mode press the 'PRINT' key & then press '6' to print Monthly Record details.
7. In standby mode press the 'PRINT' key & then press '7' to print Yearly Record details.
8. In standby mode press the 'PRINT' key & then press '8' to enter Log's menu.
    - In the log menu press '1' to print Boot log.
    - In the log menu press '2' to print Calibration log.
    - In the log menu press '3' to print Configuration log.
    - In the log menu press '4' to print the Error log.

Query Mode Operations

In the standby mode, press the 'QUERY' key and enter the **BASE** password to open Query menu for printing.
To Enter into Query Mode User Needs to Press the 'QUERY' key in Standby Mode then enter the password. then 'C---' will be displayed on the Segment LCD. After that user can press the required key to see particular details from the query mode menu. Following is the description of each Query mode.

1. TXN. Details

- In Standby mode press the "QUERY" key to enter query mode, then press key '1' from digit keys to enter in TXN. Details.
- It will display all the past transactions in the segment LCD. The first row will display the liter, the second row will display the amount and the third row will display the number of the transaction.
- By pressing the 'PRINT' key at any transaction we can get print of that particular transaction.
- Press the 'STOP' key to exit query mode.

2. Lifetime Totalizer

- In Standby mode press the "QUERY" key to enter query mode, then press key '2' from digit keys to enter in Lifetime Totalizer details.

- It will display the current year in the first row, the total amount of volume dispensed in the second row, and the total number of transactions in the third row.
- By pressing the 'PRINT' key we can get a print of the total amount and total liter's dispensed from the date of installation.
- Press the 'STOP' key to exit query mode.

3. [Daily] Totalizer Record Mode

- In Standby mode press the "QUERY" key to enter query mode, then press key '3' from the digit keys to enter in Daily Totalizer Record mode in which summation of full-day dispensing data will be displayed.
- In this mode first row of the Segment LCD displays the current date, the second row shows the total volume dispensed and the third row displays the total number of transactions of the above date mentioned in the first row.
- Press "<" or ">" button to switch the Day.
- By pressing the 'PRINT' key user can get print of the whole day transaction.
- Press the 'STOP' key to exit query mode.

4. [Monthly] Totalizer Record Mode

- In Standby mode press the "QUERY" key to enter query mode, then press key '4' from the digit keys to enter in Monthly Totalizer Record mode in which summation of full month dispensing data will be displayed.
- In this mode first row of the Segment LCD displays the particular month and year, the second row displays the total volume dispensed in the whole month and the third row displays the total number of transactions of the above month mentioned in the first row.
- Press "<" or ">" button to switch the Month.
- By pressing the 'PRINT' key we can get print of the particular, month's transaction.
- Press 'STOP' to exit query mode.

5. Shift Details

- In Standby mode press the "QUERY" key to enter query mode, then press key '5' from the digit keys to enter in current shift details.
- By default, displays the current shift's accumulated data, the first line of the screen displays the current date, the second line shows the accumulated volume of the above date and the third line shows the current shift.
- Press the "<" or ">" button to switch the shift along with the date.
- Press 'STOP' to exit query mode.

6. [Yearly] Totalizer Record Mode

- In Standby mode press the "QUERY" key to enter query mode, then press key ‘6’ from the digit keys to enter in Yearly Totalizer Record mode in which summation of full-year dispensing data will be displayed.
- In this mode first row of the Segment LCD displays the particular year, the second row displays the total volume dispensed in the whole year and the third row displays the total number of transactions of the above year mentioned in the first row.
- By pressing the ‘PRINT’ key we can get print of the particular, year's transaction.
- Press ‘STOP’ to exit query mode.

❖ LED Indicators

12V POWER	It will indicate the 12V power supply to the main board.
230V SENSE	It will indicate a 230V power supply.
5V-1 POWER	It will indicate the 5V-1 power supply to the main board.
5V-2 POWER	It will indicate the 5V-2 power supply to the main board.
PRINTER POWER	It will indicate if the Printer is powered ON or OFF.
GSM POWER	It will indicate if GSM is powered ON or OFF.
MCU SUPPLY	It will indicate if the MCU is powered ON or OFF.
FLOWMETER	It will show the flow meter's pulses to the main board.
NOZZLE	It will indicate the nozzle pick-up status.
ERROR	It will indicate if any error occurs.
GSM COMM.	It will show the current network status of the GSM.

❖ Dispenser Functions Password

Type	Used For	Default Value	Resettable?
Basic	Function	333333	Yes
Advance	Function	666666	Yes
Admin	Totalizer overflow	999999	Yes

❖ List of Functions

F-11	Set dispenser ID	To set the dispenser ID	ADMIN
F-12	Set password admin	To set the admin password	ADMIN
F-13	Set dispenser lock	To lock the dispenser	ADMIN
F-14	Time lock	To lock/unlock the date update function	ADMIN
F-15	Calibration lock	To lock/unlock the calibration change function	ADMIN
F-16	Price lock	To lock/unlock the function to change unit price	ADMIN
F-17	Boot type	To set the boot type	ADMIN

F-18	Set printer configuration	To set printer functionality	ADMIN
F-19	Currency type	To set currency functionality	ADMIN
F-20	Set product type	To turn ON/OFF product type functionality	ADMIN
F-21	Buzzer flag	To select the buzzer flag	ADMIN
F-22	Set backlight flag	To turn ON/OFF backlight	ADMIN
F-23	Test mode	Reserved for future use	ADMIN
F-24	RFID flag	To turn ON/OFF RFID functionality	ADMIN
F-25	OTP flag	To turn On/OFF OTP operation	ADMIN
F-26	Urea sensor type	To set urea sensor type	ADMIN
F-27	Debug function	Reserved for future use	ADMIN
F-28	Hide password	To Turn ON/OFF Hide password functionality	ADMIN
F-29	Tank flag	To Turn ON/OFF tank flag	ADMIN
F-30	Set Tank level PO	To set the tank level PO	ADMIN
F-31	Tank level high	To set High level of fluid storage tank	ADMIN
F-32	Tank level low	To set Low level of fluid storage tank	ADMIN
F-33	Baud rate	To set the baud rate	ADMIN
F-34	Set fueling timeout	To turn ON/OFF fueling functionality	ADMIN
F-35	Nozzle timeout	To turn ON/OFF fueling functionality	ADMIN

F-36	Set minimum raise	To set the value of minimum raise function	ADMIN
F-37	Set leakage volume	To set leakage volume for detection of leakage	ADMIN
F-38	Set communication flag	To select communication medium	ADMIN
F-39	Set logo flag	To ON/OFF the logo functionality	ADMIN
F-40	Set audio flag	To ON/OFF the audio functionality	ADMIN
F-41	Set urea Flag	To ON/OFF the urea sensor functionality	ADMIN
F-42	Set vehicle Flag	To ON/OFF the vehicle flag	ADMIN
F-43	Set flowmeter type	To set the flowmeter type	ADMIN
F-44	Set Calibration manual	To manually set the calibration	ADMIN
F-45	Set calibration auto	To automatically calculate the calibration	ADMIN
F-46	Set Print slip format	To set the print slip format	ADMIN
F-47	Set display delay	To set the value of delay in display	ADMIN
F-48	Set Tank volume	To set the tank capacity	ADMIN
F-49	LV open volume	To set the LV open value	ADMIN
F-50	LV close volume	To set the LV close value	ADMIN
F-51	Payment type	To set the payment type	ADMIN
F-52	Payment entry	To ON/OFF the payment flag	ADMIN
F-53	Remote preset	To set the preset	ADMIN

F-54	Calibration lock	To lock/unlock the auto calibration functionality	ADMIN
F-55	Low percent	To set the low percent	ADMIN
F-56	Pressure flag	To turn On/OFF pressure flag	ADMIN
F-57	Password advance	To set the password for advance functions	ADVANCE
F-58	Tank calibration full	Automatic System Configurable	ADVANCE
F-59	Tank calibration empty	Automatic System Configurable	ADVANCE
F-60	Date update	To set the value of date/time	ADVANCE
F-61	Quantitative flag	To Turn ON/OFF the Quantitative Functionality	ADVANCE
F-62	Quantitative volume	To set the quantitative volume	ADVANCE
F-63	Quantitative amount	To set the quantitative amount	ADVANCE
F-64	Emergency dispense	To turn ON/OFF emergency flag	ADVANCE
F-65	Large dispense	To turn ON/OFF large dispense flag	ADVANCE
F-66	Maximum volume	To set the maximum liter value	ADVANCE
F-67	Maximum amount	To set the maximum amount value	ADVANCE
F-68	Maximum preset	To set the maximum preset value	ADVANCE
F-69	Maximum P1	To set the value in P1	ADVANCE
F-70	Maximum P2	To set the value in P2	ADVANCE
F-71	Maximum P3	To set the value in P3	ADVANCE
F-73	P1 type	To set the type in P1	ADVANCE

F-74	P2 type	To set the type P2	ADVANCE
F-75	P3 type	To set the type in P3	ADVANCE
F-77	Clear data	To clear all the data from memory	ADVANCE
F-78	Urea value	To set the urea value	ADVANCE
F-79	Urea calib type	To set the urea calibration type	ADVANCE
F-80	Unit price	To set the unit price	ADVANCE
F-81	Password base	To set the password for base functions	BASIC
F-82	Display last flow count	Its display's the last flow count of the flowmeter	BASIC
F-83	Display urea data	It display's the urea data	BASIC
F-84	Tank lock	To lock/unlock the tank	BASIC
F-85	Panel door handling	To open/close panel door	BASIC
F-86	Manhole door handling	To open/close manhole door	BASIC
F-87	Inlet valve open	To open/close inlet valve	BASIC
F-88	Pulsar registration	To register the pulsar for flow	BASIC
F-89	Backup totalizer and calibration value	To backup totalizer and calibration data	BASIC

List of Function Number & Its Description

- User Can Enter Function Mode by Pressing the ‘OK’ key in Standby Mode.
- Segment LCD will Display “F ---”.
- The user needs to press digit keys as per the required function number and the segment LCD will display “F X-X” (X being the value entered by the User). Then press the ‘OK’ key to enter the required function.
- If the Entered Function number exists in the device then, it will ask the user to enter a Password, and if it does not then the device will exit the function menu and return back to Standby mode.
- User can traverse through the function using ‘<’ and ‘>’ after entering the correct password.
- The user needs to enter a Password based on its category. If a password is correct system will show two values.
- In default case First Line of the Segment LCD will show the Current value of that respective function. The user needs to press the ‘CLR’ key and then, enter a new value which is displayed in the second line of Segment LCD.
- If the user presses the ‘OK’ key, it will update the current settings. If the ‘STOP’ key gets pressed then the old value does not get updated.

Function Code – [11] Dispenser ID

> **Password: Admin Code**

The First two lines of the segment display shows the current Dispenser ID press the clear button to make changes to the previous value. Then press ‘OK’ key to save the settings

> **Range: “000000000000” to “999999999999"**
> **Decimal Point: 12**

Function Code – [12] Set Admin Password

> **Password: Admin Code**

The first line of the LCD displays the current Admin Password.
At this time, directly enter the new value and then press ‘**OK**’ key to save the settings.
Now the password for all the function password has been updated.

> **Range: “100000” to “999999"**
> **Default value: 999999**
> **Decimal Point: 6**

Function Code – [13] Lock Dispenser

> **Password: Admin Code**

After entering the Admin Password, press 1 and then the OK key to lock the dispenser. Once locked, no operations can be performed on the dispenser until the correct password is entered to unlock it.

> **Range: “0” to “1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [14] Lock Time

> **Password: Admin Code**

After entering the Admin Password, to lock the “DATE UPDATE” function press 1 and then press ‘**OK**’ key. Now the date and time settings of dispenser are locked. To make changes set the “TIME LOCK” function back to ‘0’.

0 = Unlock the “DATE UPDATE” function
1 = Lock the “DATE UPDATE” function

> **Range: “0” to “1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [15] Lock Calibration

> **Password: Admin Code**

After entering the Admin Password, to lock the “AUTO CALIBRATION” function press 1 and then press ‘**OK**’ key. calibration setting of the dispenser have been locked. No changes can be made to the “AUTO CALIBRATION” function. To make changes press 0 and press ‘**OK**’

0 = Unlock the “AUTO CALIBRATION” function
1 = Lock the “AUTO CALIBRATION” function

> **Range: “0” to “1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [16] Price Lock

> **Password: Admin Code**

After entering the Admin Password, to lock the "UNIT PRICE" function press 1 and then press '**OK**' key. The unit price of the product cannot be modified. To enable changes press 0 and then press '**OK**'.

0 = Unlock the "UNIT PRICE" function
1 = Lock the "UNIT PRICE" function

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [18] Set Printer Configuration

> **Password: Admin Code**

0 = Off the Printer Configuration
1 = Set the printer configuration in Manual mode
2 = Set the printer configuration in Auto mode

This function controls the operation of the printer. When the printer configuration is set to '0', the printer is disabled, and no prints can be generated. In Manual Mode, a print is generated only when the "**Print**" key is pressed. In Auto Mode, a print is generated automatically after every transaction.

The first row of the LCDs displays the current Printer Configuration.
At this time, directly enter the new value and then press '**OK**' key to save the settings.

> **Range: "0" to "2"**
> **Default value: 1**
> **Decimal Point: 1**

Function Code – [19] Set Currency Type

> **Password: Admin Code**

The first line of the LCDs shows the current Currency Type.
At this time, directly enter the new value and then press '**OK**' key to save the settings.

0 = Off the currency type
1 = Set currency type to Rupees
2 = set currency type to Dollar

- **Range: “0” to “2"**
- **Default value: 1**
- **Decimal Point: 1**

Function Code – [20] Set Product Type

- **Password: Admin Code**

0 = Off the product type
1 = Set the product type as DEF
2 = Set the product type as Petrol
3 = Set the product type as Diesel
4 = Set the product type as Bio-Diesel
5 = Set the product type as Lube oil
6 = Set the product type as Ad-blue

The first line of the LCD displays the current Product Type.
At this time, directly enter the new value and then, press the ‘**OK**’ key to save the settings. The product type has been updated.

- **Range: “0” to “6"**
- **Default value: 1**
- **Decimal Point: 1**

Function Code – [21] Set Buzzer Flag

- **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current Buzzer Flag value.
At this time, directly enter the new value and then, press the ‘**OK**’ key to save the settings. This function defines the functionality of buzzer. Turning the flag to ‘0’ would off the buzzer and ‘1’ would on the buzzer.

- **Range: “0” to “1"**
- **Default value: 1**
- **Decimal Point: 1**

Function Code – [22] Set Backlight Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

This function is used to turn on/off the backlight of segment LCD. To turn on the light set the flag to 1 and to turn off light set the flag to 0. The first line of the LCD displays the current Backlight Flag value. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 1**
> **Decimal Point: 1**

Function Code – [23] Test Mode

Password: Admin Code

Reserved for the future use.

Function Code – [24] RFID Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

This function is used to turn on/off RFID. To turn on the RFID functionality set the flag to 1 and to turn off the RFID functionality set the flag to 0. The first line of the LCD displays the current RFID Flag value. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [25] Set OTP Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current OTP Flag value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [26] Set Urea Sensor Type

> **Password: Admin Code**

0 = Orange Type Urea Sensor
1 = Yellow Type Urea Sensor

The first line of the LCD displays the current Urea Sensor Type.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [27] Debug Function

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current debug Flag value. This function is used to turn on/off debug functions. To turn on the debug functionality set the flag to 1 and to turn off the debug functionality set the flag to 0. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [28] Set Hide Password Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

This function allows users to hide or unhide the password during entry. When the **h**ide password flag is set to 1, the password is hidden, and when set to 0, it is visible. The first line of the LCD displays the current flag value. To update the setting, simply enter the new value and press the '**OK**' key to save the changes.

> **Range: "0" to "1"**
> **Default value: 1**
> **Decimal Point: 1**

Function Code – [29] Set Tank Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

This flag is use to define the functionality of tank sensor. To turn off the tank sensor functionality set the flag to 0 and to turn on the functionality set the flag to 1.
The first line of the LCD displays the current Tank Flag Type.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [30] Set Tank Level PO

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

This function is used to turn on/off debug functions. To turn on the debug functionality set the flag to 1 and to turn off the debug functionality set the flag to 0. The first line of the LCD displays the current debug Flag value. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [31] Set High Tank Level

> **Password: Admin Code**

The first line of the LCD displays the current tank level.
The High tank level indicates that at this value of the tank device will give the error that the product in the tank has reached the maximum limit set.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "51" to "100"**
> **Default value: 90**
> **Decimal Point: 3**

Function Code – [32] Set Low Tank Level

> **Password: Admin Code**

The first line of the LCD displays the current low tank level.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.
The Low tank level indicates that at this value device will give error when the quantity of the product inside the tank has reached low value set.

> **Range: "0" to "50"**
> **Default value: 10**
> **Decimal Point: 2**

Function Code – [34] Set Fueling Timeout

> **Password: Admin Code**

The first line of the LCD displays the present Fuel Timeout value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.
Fuel timeout means when Operator picks up the nozzle and does not start the dispensing in given fuel timeout seconds, then system will generate error on screen. To stop the error message press "**STOP**" key. after pressing "**STOP**" you will reach back to standby mode.

> **Range: "0" to "999"**
> **Default value: 60**
> **Decimal Point: 3**

Function Code – [35] Set Nozzle Timeout

> **Password: Admin Code**

The first line of the LCD displays the Nozzle Timeout value.
At this time, directly enter the new value and then, press the '**OK'** key to save the settings.
Nozzle timeout means When Operator picks up the nozzle and does a transaction but do not put the nozzle back after transaction in given Nozzle timeout seconds, then system will generate error on screen. To stop the error message press "**STOP**" key to reach back to standby mode.

> **Range: "0" to "999"**
> **Default value: 120**
> **Decimal Point: 3**

Function Code – [36] Set Minimum Raise

> **Password: Admin Code**

The first line of the LCD displays the current Minimum Raise value.
At this time, directly enter the new value and then, press the 'OK' key to save the settings.
2When user set certain value here the dispenser will only save those transaction which crosses the liter value set in this function.
Note: Though Dispenser will show real time transaction values during dispensing as soon as transaction is finished the values will be discarded and will not be stored anywhere. The first line of the LCD displays the current Minimum Raise Amount value.
At this time, directly enter the new value and then, press the '**OK'** key to save the settings.
After pressing "**OK**" it will show standby mode again.

> **Range: "0.00" to "2.00"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [37] Set Leakage Volume

> **Password: Admin Code**

The first line of the LCD displays the Current leakage volume.
At this time, directly enter the new value and then, press the 'OK' key to save the settings.
if there is a case when the dispenser is in standby mode and still the pulse are being counted then after the Leakage volume has crossed the value of the set value then it will throw a leakage error.
Press "**STOP**" key to stop the error mode.

> **Range: "0" to "2"**
> **Default value: 2**
> **Decimal Point: 1**

Function Code – [38] Set Communication Flag

> Password: Admin Code

0 = Off the product type
1 = GSM
2 = WIFI

The first line of the LCD displays the current Communication medium with server.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.
This function determines the network medium of the dispenser. If the flag is set to '0' the network connectivity of the dispenser will be disabled. If the flag is turned 1 then dispenser will use GSM module (sim card) to establish connectivity and if the flag is set to '2' dispenser will use WIFI connectivity to get connect to internet.

> Range: "0" to "2"
> Default value: 0
> Decimal Point: 1

Function Code – [39] Set Logo Flag

> Password: Admin Code

0 = turn off flag functionality
1 = Logo 1
2 = Logo 2

The first line of the LCD displays the current Logo Flag value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> Range: "0" to "2"
> Default value: 1
> Decimal Point: 1

Function Code – [40] Set Audio Flag

> Password: Admin Code

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current audio flag value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings. This function is used to on/off the audio flag. To turn on the audio set the flag to 1 and to turn off the audio set the flag to 0.

> Range: "0" to "1"
> Default value: 1
> Decimal Point: 1

Function Code – [41] Set Urea Flag

> Password: Admin Code

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current Urea Flag value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.
This function is used to on/off the concentration sensor. To turn on the sensor set the flag to 1 and to turn off set the flag to 0.

> Range: "0" to "1"
> Default value: 0
> Decimal Point: 1

Function Code – [42] Set Vehicle Entry Flag

> Password: Admin Code

0 = turn off flag functionality
1 = turn on flag functionality

This function activates or deactivates the entry of vehicle number. If the flag is set to 1 then the dispenser will ask for the vehicle number after every transaction and if the flag is set to 0 then it will not ask for entry. The first line of the LCD displays the current Vehicle Flag value. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> Range: "0" to "1"
> Default value: 0
> Decimal Point: 1

Function Code – [43] Set Flowmeter Type

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current flowmeter type value.
This function is used to set the flowmeter type. To set the flowmeter type 0(default type) press the key "0" and to set the flowmeter type 1 press the key "1".
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 00**
> **Decimal Point: 1**

Function Code – [44] Set Manual Calibration

> **Password: Admin Code**

1. Segment LCD will display zero (0) in 1st line which is current pulse count.
2. Press the clear button to make changes to the value.
3. Now enter the pulse count you want to calibrate and press '**OK**'.
4. Now enter the volume for calibration.
5. Press '**OK**' key to set the new calibration.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [45] Set Auto Calibration

> **Password: Admin Code**

> Segment LCD will display zero (0) in 1st Line which is current Pulse count.
> As soon as user pick up the nozzle from the stand the Motor, S.V. & L.V. will start automatically
> Now user should do the dispensing in pre-decided vessel. While dispensing Dispenser will show the current pulse count on the system.
> When Dispensing is finished, user can press 'STOP' key to stop the dispensing. User needs to put nozzle into stand for further process.t
> After that user had to enter volume of vessel in 2nd line. Then press '**OK**' key and it will automatically update the calibration Factor

> **Range: "0.01" to "99999.99"**
> **Default value: --**
> **Decimal Point: 5**

Function Code – [46] Set Print Slip Format

> **Password: Admin Code**

0 = Both OFF
1 = Header On, Footer OFF
2 = Header OFF, Footer ON
3 = Both ON

This function defines the format of the print slip of transaction. You can choose whether you want to print the header or footer with the transaction details
The first line of the LCD displays the current print slip format.
At this time, directly enter the new value and then, press the 'OK' key to save the settings.

- **Range: "0" to "3"**
- **Default value: 0**
- **Decimal Point: 1**

Function Code – [47] Set Display Delay

- **Password: Admin Code**

It will show Current Value on 1st Line and User can enter desired value on 2nd Line. When user set certain value here which is not 0.00 then during dispensing the screen will keep showing 0 until the dispensing volume crosses the Display Delay Liter value. After That dispenser will update value in Real time and resume the dispensing from Display Liter Value.

- **Range: "0.00' to "2.00"**
- **Default value: 0**
- **Decimal Point: 2**

Function Code – [48] Set Tank Volume

> **Password: Admin Code**

The first line of the LCD displays the current tank volume. User can set the new tank volume value. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

- **Range: "1" to "99999.99"**
- **Default value: 1000**
- **Decimal Point: 5**

Function Code – [49] Set LV Opening Liter Value

> **Password: Admin Code**

When Dispensing starts LV will open after set amount of liter value has passed. LV will not open if the liter does not cross the set limit & dispensing will only happen on small valve.
The first line of the LCD displays the Current Value.
At this time, directly enter the new value and then, press the 'OK' key to save the settings.

> **Range: "0.00" to "5.00"**
> **Default value: 0.5**
> **Decimal Point: 2**

Function Code – [50] Set LV Closing Liter Value

> **Password: Admin Code**

This feature will only work in Preset Mode dispensing. When user set any value here then LV, will automatically get closed after dispensing value crosses limit of Preset Value LV closing liter Value.
After that only small valve will stay turned on to finish the transaction.
The first line of the LCD displays Current Value.
At this time, directly enter the new value and then, press the 'OK' key to save the settings.

> **Range: "0.00" to "5.00"**
> **Default value: 0.5**
> **Decimal Point: 2**

Function Code – [51] Set Payment Type

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current payment entry Flag value.
This function is used to on/off the payment entry flag. To turn on the payment entry flag set the flag to 1 and to turn off set the flag to 0.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [52] Set Payment Entry Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current payment entry Flag value.
This function is used to on/off the payment entry flag. To turn on the payment entry flag set the flag to 1 and to turn off set the flag to 0.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [53] Remote preset

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current preset value.
This function defines the functionality of remote preset. Turning the flag to '0' would off the remote preset and '1' would on the remote preset.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [54] Calibration Log

> **Password: Admin Code**

This function is used to save the manual and auto calibration value or factor in the memory. After the manual or auto calibration process set the value one (1) in this function to save the settings. By default, this function shows the value zero (0).

Function Code – [55] Low Percent

> **Password: Admin Code**

The first line of the segment LCD displays the current low percent value.
This function is used to set the low percent value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "999"**
> **Default value: 0**
> **Decimal Point: 3**

Function Code – [56] Pressure Flag

> **Password: Admin Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current pressure flag value. This function is used to turn on/off pressure functions. To turn on the pressure functionality set the flag to 1 and to turn off the debug functionality set the flag to 0. At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [57] Set Advance Password

> **Password: Advance Code**

This function is used to set the password for Advance functions.
The first line of the LCD displays the Current Value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "100000" to "999999"**
> **Default value: 666666**
> **Decimal Point: 6**

Function Code – [60] To Set Date/Time

> **Password: Advance Code**

This function is used to set Date/Time.
To use this function, we have to first set the Time Lock Flag to '0' then only we can enter this function or else it will show the error.
The first row of the LCD displays the Current Date.
The second row of the LCD displays the Current Time.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

Function Code – [61] Set Quantitative Flag

> **Password: Advance Code**

0 = turn off flag functionality
1 = turn on flag functionality (Volume)
2 = turn on flag functionality (Amount)

The first row of the LCD displays the current Quantitative Flag value.
At this time, directly enter the new Quantitative Flag value you wish to use and then, press the 'OK' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [62] Set Quantitative Repeat Volume

> **Password: Advance Code**

In this function user can set the value for the Quantitative repeated dispensing in liters.
For using this function, we have to set the Quantitative Flag value to '1'.
The first line of the LCD displays the currently sets value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99"**
> **Default value: 9**
> **Decimal Point: 5**

Function Code – [63] Set Quantitative Repeat Amount

> **Password: Advance Code**

In this function user can set the value for the Quantitative repeated dispensing in amount.
For using this function, we have to set the Quantitative Flag value to '2'.
The first line of the LCD displays the currently sets value.
At this time, directly enter the new value, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99"**
> **Default value: 150**
> **Decimal Point: 5**

Function Code – [64] Set Emergency Dispense Flag

> **Password: Advance Code**

0 = turn off flag functionality
1 = turn on flag functionality

The first line of the LCD displays the current Emergency Dispense Flag value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [65] Set Large Dispensing Flag

> **Password: Advance Code**

0 = turn off flag functionality
1 = turn on flag functionality

This function is used when the customer demands large volume of fuel.
The first line of the LCD displays the current Large Dispensing Flag value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [66] Set Maximum Liter Preset Value

> **Password: Advance Code**

In this function user can set maximum liter value for preset type dispensing.
The first line of the LCD displays the default value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99 "**
> **Default value: 99999.99**
> **Decimal Point: 5**

Function Code – [67] Set Maximum Amount Preset Value

> **Password: Advance Code**

In this function user can set maximum amount value for preset type dispensing.
The first line of the LCD displays the default value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99"**
> **Default value: 99999.99**
> **Decimal Point: 5**

Function Code – [68] Set Maximum Preset Value for (P1 – P3)

> **Password: Advance Code**

In this function user can set the maximum value, up to which user can set the values for the preset (P1 – P3).
The first line of the LCD displays the default value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99"**
> **Default value: 99999.99**
> **Decimal Point: 5**

Function Code – [69] Set Maximum Preset-P1 Value

> **Password: Advance Code**

In this function user can set the maximum value, up to which user can set the values for the preset (P1) dispensing.
This maximum value should not exceed the value set in the Set Maximum Preset Value function.
The first line of the LCD displays the currently set value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99"**
> **Default value: 1**
> **Decimal Point: 5**

Function Code – [70] Set Maximum Preset-P2 Value

> **Password: Advance Code**

In this function user can set the maximum value, up to which the user can set the values for the preset (P2) dispensing.
This maximum value should not exceed the value set in the Set Maximum Preset Value function.
The first line of the LCD displays the currently set value.
At this time, directly enter the new value and then, press the '**OK**' key to save the settings.

> **Range: "0.01" to "99999.99"**
> **Default value: 2**
> **Decimal Point: 5**

Function Code – [71] Set Maximum Preset-P3 Value

> **Password: Advance Code**

In this function user can set the maximum value, up to which user can set the values for the preset (P3) dispensing.
This maximum value should not exceed the value set in the Set Maximum Preset Value function.
The first line of the LCD displays the currently sets value. At this time, directly enter the new value and then, press the '**OK**' key to save the

> **Range: "0.01" to "99999.99"**
> **Default value: 3**
> **Decimal Point: 5**

Function Code – [73] Set Preset-1 (P1) Type Flag

> **Password: Advance Code**

0 = To set the Liter
1 = To set the Amount

This Function is used to set the Type Flag of the Preset-1(P1).
The first row of the LCD displays the current Preset-1 (P1) Type Flag value.
At this time, directly set the new Preset-1(P1) Type Flag and then, press the 'OK' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [74] Set Preset-2 (P2) Type Flag

> **Password: Advance Code**

0 = Preset Unit is Liter
1 = Preset Unit is Amount

This Function is used to set the Type Flag of the Preset-2(P2).
The first row of the LCD displays the current Preset-2 (P2) Type Flag value.
At this time, directly set the new Preset-2(P2) Type Flag and then, press the 'OK' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [75] Set Preset-3 (P3) Type Flag

> **Password: Advance Code**

0 = Preset Unit is Liter
1 = Preset Unit is Amount

This Function is used to set the Type Flag of the Preset-3(P3).
The first row of the LCD displays the current Preset-3 (P3) Type Flag value.
At this time, directly set the new Preset-3(P3) Type Flag and then, press the 'OK' key to save the settings.

> **Range: "0" to "1"**
> **Default value: 0**
> **Decimal Point:1**

Function Code – [77] Clear Data

> **Password: Advance Code**

909090 = To clear data
919191 = To do GSM self OTA
373737 = To do ESP self OTA

This function is used to clear and reset all the data and configuration, attempt GSM self OTA and ESP self OTA.

Function Code – [78] Urea Value

> **Password: Advance Code**

This function displays the urea value.

> **Range: “1” to “99.99"**
> **Default value: 33.75**
> **Decimal Point: 2**

Function Code – [79] Urea Calibration Value

> **Password: Advance Code**

This function is used save the calibration value.

> **Range: “0” to “2"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [80] Set Unit Price

> **Password: Advance Code**

This function is used to change the unit price.
The first line of the LCD displays the current Unit Price value.
At this time, directly enter the new value and then, press the ‘OK’ key to save the settings.

> **Range: “0.01” to “9999.99"**
> **Default value: 100**
> **Decimal Point: 4**

settings.

> **Range: “0” to “1"**
> **Default value: 0**
> **Decimal Point: 1**

Function Code – [81] Set Basic Password

- **Password: Basic Code**

  This function is used to set the password for Basic functions.
  The first line of the LCD displays the Current Value.
  At this time, directly enter the new value and then, press the 'OK' key to save the settings.

  - **Range: "100000" to "999999"**
  - **Default value: 333333**
  - **Decimal Point: 6**

Function Code – [82] Display last Flow Meter Count

- **Password: Basic Code**

  This function is used to display the last flow count on the segment LCD.
  The first line of the LCD displays the Current value.
  At this time, directly enter the new value and then, press the 'OK' key to save the settings.

  - **Range: ----**
  - **Default value: ---**
  - **Decimal Point: ---**

Function Code – [83] Display Urea Data

- **Password: Basic Code**

  This function is used to display the urea data on the segment LCD.

  - **Range: ----**
  - **Default value: 0**
  - **Decimal Point: ----**

Function Code – [84] Tank Lock

- **Password: Basic Code**

  This function is used to lock/unlock the tank door.
  Enter the password to open/close the door. Password -> 357159
  Press the key "STOP" to go in STANDBY mode.

Function Code – [85] Panel Door Handling

> **Password: Basic Code**

This function is used to open and close the panel door.
Press the key “1” to open the door and key “2” to close the door
Press the key “STOP” to go in STANDBY mode.

Function Code – [86] Manhole Door Handling

> **Password: Basic Code**

This function is used to open and close the manhole door.
Press the key “1” to open the door and key “2” to close the door
Press the key “STOP” to go in STANDBY mode.

Function Code – [87] Inlet valve Open

> **Password: Basic Code**

This function is used to open and close the inlet valve.
Press the key “1” to open the door and key “2” to close the door
Enter the password to open/close the door. Password -> 357159
Press the key “STOP” to go in STANDBY mode.

Function Code – [88] Pulsar Registration

> **Password: Basic Code**

This function is used to register the pulsar with the PCB.
Enter the password to register the pulsar. Password -> 519462
If registration gets successful the PULSAR REGISTER frame is displayed on GLCD.
Press the key “STOP” to go in STANDBY mode.

Function Code – [89] Backup Totalizer and Calibration

> **Password: Basic Code**

Press key “1” to get the print slip of totalizer.
Press key “2” to get the print slip of calibration factor.
Press key “3” to copy the value of totalizer.
Press key “4” to copy the value of calibration.

ERROR CODE	ERROR REASON	SOLUTION
E - 01	Pulse not detected	Turn on flow
E – 02	Nozzle is hanging out	Put the nozzle back in the nozzle holder
E – 03	Leakage detected	Turn of the flow before putting the nozzle back in the nozzle holder
E – 04	Tank Low	Tank level Low
E – 05	Tank High	Tank level High
E - 06	Urea sensor not detected	Turn of the urea flag if urea sensor is not connected with the device
E – 07		
E – 08		
E – 09		
E - 10	Filter choke-up	Clean the filter
E – 11		
E - 12	Tank Leak	Check the tank leakage and turn off the door
E – 13	Tank Overflow	Check the tank level and turn off the flow