

ACME Enterprise Router & Gateway Series v4.2 Official Troubleshooting & Support Manual

1. System Overview & Indicator Lights

- **Power LED (Solid Green):** Device is receiving correct voltage.
- **Power LED (Flashing Amber):** Low voltage detected or power supply failure. Action: Replace power brick with official 12V 2A adapter.
- **Network LED (Off):** Ethernet cable disconnected or faulty physical link. Action: Swap out Cat6 cable and verify switch port status.
- **Internet LED (Flashing Red):** WAN authentication failure or PPPoE timeout.

2. Common Error Codes & Resolutions

- **Error Code E-401 (Authentication Timeout):** Occurs when ISP credentials expire or RADIUS server is unreachable. Resolution: Log into the admin portal at 192.168.0.1, navigate to Network > WAN Settings, re-enter your PPPoE username and password, and click Save.
- **Error Code E-503 (Firmware Corruption):** Triggered by an interrupted firmware update. Resolution: Unplug the power cord, hold the physical Reset button on the back panel for 15 seconds while reconnecting power to enter Recovery Mode, then flash firmware version 4.2.1 via emergency web server at 192.168.1.1.
- **Error Code E-909 (Thermal Overload):** Fan failure or blocked intake vents. Resolution: Ensure at least 6 inches of clearance around chassis vents, use compressed air to clear dust from side intake grills, and verify internal fan rpm exceeds 2500 RPM in the diagnostics dashboard.

3. Wi-Fi & Mesh Connectivity Issues

- **Symptom:** Clients unable to acquire IP address via DHCP. Resolution: Restart the DHCP scope service under Advanced Settings > Services, or perform a soft factory reset by pressing the reset pinhole for 5 seconds.
- **Symptom:** Frequent packet loss on 5GHz band. Resolution: Change the wireless channel width from 80MHz to 40MHz to avoid local DFS radar interference, and lock channel selection to 36, 40, or 44.