

# P2 Flush Pull

Low profile · Lift or pull · Single hole mount

- Snap-in installation
- 2 sizes

#### **Material and Finish**

ABS plastic, black

#### **Performance Details**

 ${\it Maximum\ static\ load:}$ 

Lifting / pulling: 1300 N (300 lbf)



Pushing / sliding: 450 N (100 lbf)





Flammability rating: UL94-HB or UL94-V0


Operating temperature range: -50°C (-60°F) to 60°C (140°F)

#### **Notes**

Performance details are based on installation in a 1.2 (.048) thick steel door. Maximum loads are limited by door strength.







#### **Part Number Selection**

Door Thickness Range		Part Number			
		Small		Large	
Min.	Max.	UL94-HB	UL94-V0	UL94-HB	UL94-V0
1.0 (.040)	1.4 (.055)	P2-41	P2-41-1	P2-51	P2-51-1
1.4 (.055)	1.8 (.070)	P2-42	P2-42-1	P2-52	P2-52-1
1.8 (.070)	2.1 (.085)	P2-43	P2-43-1	P2-53	P2-53-1
2.1 (.085)	2.5 (.100)	P2-44	P2-44-1	P2-54	P2-54-1

Other options available. For complete details on variety, part numbers, installation and specification, go to






# P2 Flush Pull - Lockable

Low profile · Lift or pull · Single hole mount





- Snap-in installation
- Lockable
- Lock core included or sold separately
- Cam sold separately

#### **Material and Finish**

Pull: ABS plastic, black

Lock parts:


Zinc alloy, powder coated. Brass. Steel, zinc plated. Buna-N

Flammability Rating


UL94-HB or UL94-VO (See table)

#### **Notes**

For pulls without lock core, lock core sold separately, see page 158.
Cam sold separately. See page 167.



## Part Number Selection



Other options available. For complete details on variety, part numbers, installation and specification, go to

LIC www.southco.com/P2



# **PK** Lock Cores SOUTHCO® Key-Choice System



#### **Lock Cores - Disc Tumbler**

Lock Core Part Number						
Keying	Key code	Bag qty	Shuttered stainless steel scalp	Non shuttered stainless steel scalp	Non shuttered black powder coated	Non shuttered chrome plated
KA	CH751	1	PK-39-72-13-KCH751	PK-132-13	PK-115-13	PK-116-13
KA	RS001	1	PK-39-72-13-RS001	PK-132-13-RS001	PK-29-15-13-RS001	PK-29-16-13-RS001
KD	10 CODES	10	PK-39-72-13-KD1010	PK-132-13-KD1010	PK-29-15-13-KD1010	PK-29-16-13-KD1010
KD	50 CODES	50	PK-39-72-13-KD1050	PK-132-13-KD1050	PK-29-15-13-KD1050	PK-29-16-13-KD1050
KD	125 CODES	125	PK-39-72-13-KD1125	PK-132-13-KD1125	PK-29-15-13-KD1125	PK-29-16-13-KD1125
MKKD	10 CODES	10	PK-39-72-13-MK1010	PK-132-13-MK1010	PK-29-15-13-MK1010	PK-29-16-13-MK1010
MKKD	50 CODES	50	PK-39-72-13-MK1050	PK-132-13-MK1050	PK-29-15-13-MK1050	PK-29-16-13-MK1050
MKKD	125 CODES	125	PK-39-72-13-MK1125	PK-132-13-MK1125	PK-29-15-13-MK1125	PK-29-16-13-MK1125

Keys	Part Number
Master Key (1)	PK-24-01
Control (Removal) Key (1)	PK-11-03

Keys	Part Number	
CH751	PK-10-01	
RS001	PK-10-01-RS001	

#### **Lock Cores - Tool Operable**

Head Style	Lock Core Part Number				
	Phillips recess	Slotted	4 mm Hex recess	8 mm Hex recess	
Chrome plated	PK-0-34027-01	PK-0-43489-01	PK-0-34323-01	PK-0-40374-01	
Black powder coated	PK-0-34027-50	PK-0-43489-50	PK-0-34323-50	PK-0-40374-50	

#### **Key code selection**

KA - Keyed Alike:

All lock cores are the same key code

**KD** - Keyed Differently:

Multiple key codes provided in a nonmaster key system


**MKKD** - Master Keyed, Keyed Differently:

Multiple key codes provided in a master key system

#### **Notes**

Part Number includes 1 lock core and 2 keys

### Lock Core Installation for CM-3 and CM-6 only (see page 164)



Dimensions in millimeters (inch) unless otherwise stated

#### **Installation Notes**

- 1. Prepare panel and install latches shown on page 164.
- Latch should be in unlatched position. The flats of the lock extender should be aligned with the flats on the housing.
- Take a lock core and orient the brass wafers to the internal ramped area of the housing.
   Push lock core into housing until it stops.
- 4. Insert key into lock core and turn to verify lock core is fully seated and operating properly.
- 5. Install cam.


Other options available. For complete details on variety, part numbers, installation and specification, go to




www.southco.com/PK

# **CM** Cam Locks Cams & installation








#### **Installation Notes**

- Place sealing washer onto housing (if included) and put through the mounting hole (see panel preparation).
- 2. Install mounting nut and tighten to 5 N·m (44 in·lbf).
- 3. Install cam to assembly Properly orientate for rotation and grip.
- 4. Install screw. Tighten to 4 N•m (35 in•lbf).



#### **Material and Finish**

Cam: Steel plated

### **Part Number Selection**

See table

Order lock and cam separately

Cam part number (no lock)

For Lock selection see pages 164-166

S Style C No hook

H Hook type 1

L Hook type 2

CM - S C L

L Length

06 19 (.75)

10 31.8 (1.25)

14 44.5 (1.75)

Other options available. For complete details on variety, part numbers, installation and specification, go to



