RGD Tech Troubleshooting Guide

RGD Tech | Policy and Knowledge Base | Version 2026.1 | Effective 1 July 2026

1. Troubleshooting Principles

Support agents should first identify the product, symptom, recent changes, and whether the problem is intermittent or persistent. Only approved and safe steps should be recommended.

2. Laptop: Will Not Turn On

Confirm the power adapter is connected correctly.

Check for charging indicators and try a known-good power outlet.

Disconnect non-essential accessories and retry.

If the device remains unresponsive, stop troubleshooting and create a technical diagnostic case.

3. Laptop: Overheating

Place the laptop on a hard, unobstructed surface.

Check whether ventilation openings are blocked.

Close unnecessary high-resource applications.

Allow the device to cool before continuing normal use.

If overheating persists, especially with unexpected shutdowns, burning smell, or abnormal fan behavior, stop use and escalate to Technical Support.

4. Laptop: Battery Drain

Check battery usage by applications.

Confirm the charging adapter is recognized.

Apply approved operating-system updates where appropriate.

If battery capacity appears abnormal or the device shuts down unexpectedly, route the case for warranty assessment.

5. Laptop: Wi-Fi Problems

Verify Wi-Fi is enabled and the correct network is selected.

Restart the device and network connection.

Test another network when available to distinguish device and network issues.

Escalate persistent hardware-related connectivity failures.

6. Smartphone: Charging Problems

Check the cable and power source.

Inspect the charging port without inserting tools or liquids.

Restart the device and retry charging.

If the device becomes unusually hot while charging or repeatedly fails to charge, stop use and escalate.

7. Smartphone: Battery Drain

Check battery usage by application.

Disable unnecessary background activity.

Confirm the device software is current.

Persistent abnormal drain may require warranty diagnostics.

8. Tablet: Performance Issues

Restart the tablet.

Close unused applications.

Check available storage.

Install approved system updates.

Persistent performance problems should be assessed by technical support.

9. When to Create a Warranty Case

Create a warranty case when a likely hardware defect persists after reasonable troubleshooting and the product is within the applicable warranty period.

Warranty eligibility must be checked against the warranty policy and the customer's transaction history.

10. Safety and Escalation

Never instruct customers to open the device, bypass safety systems, or perform unauthorized repairs.

Smoke, burning smell, swelling battery, liquid intrusion, or dangerous electrical behavior requires immediate cessation of use and technical escalation.