



COSMO INSTRUMENTS (I) PVT. LTD.
SPECIALIST IN AIR LEAK AND FLOW TEST



DP GAUGE

MODEL DP-340B

ERROR AND TROUBLESHOOTING MANUAL

1 ERRORS

If an error occurs, the digital indicator will display an error number such as **E-01**. The number remains displayed until the power is turned off. Use the following table to confirm the details of each error

ERR signals are output in the following cases.

Error	Description	Cause	Error Code
Instrument Error	EEPROM error	EEPROM malfunction	E-01
	System error	CPU ROM operation problem	E-02
	RAM error	RAM operation problem	E-03
Sensor error	Analog input range over *1	Sensor problem or internal circuit malfunction	E-04
	Sensor output error	Sensor problem	–
External output error	I/O output malfunction	Internal circuit or System failure	E-05

*1 The **E-04** error occurs when the sensor output exceeds the full-scale. The instrument returns to measurement mode when the sensor output falls back within the full-scale.

2 TROUBLESHOOTING

Check the following points before ordering to have your device repaired.

Problem	Symptom	Workaround
No power is supplied.	None of the LEDs are lit on.	Make sure the power cord is connected correctly.
No key operation is accepted.	When the SET key is pressed after after a setting is changed in setup mode, FAIL is displayed and the new setting is not accepted.	- Make sure <i>Loc</i> has not been set <i>on1</i> or <i>on2</i> in setup mode. - If <i>Loc</i> has been set to <i>on1</i> or <i>on2</i>, set it to <i>OFF</i>.
	The Auto Zero key is invalid.	- Check whether an external input is being used. (Settings specified via external input supersede settings specified via key input.) - Make sure <i>Loc</i> has not been set to <i>on1</i> setup mode. - If <i>Loc</i> is <i>on1</i>, set it to <i>on2</i> or <i>OFF</i>.
No external input (I/O) is accepted.	Any of the external input signals are invalid.	- Check that the connectors were correctly connected. - Check the input voltage of pin 17 (VEXT) on the external I/O connector (CODE OUT). - When using the 5V input option, do not apply a voltage of more than 5V to pin 12 (VEXT) on the external I/O connector (CODE OUT). Doing so may damage the internal circuit. .