

ABBREVIATIONS

Sr. No.	Abbreviation Issued	For
1	APU	Auxiliary Power Unit
2	BCM	Bridge Centre Module
3	BEM	Bridge End Module
4	BSB	Bank Seat Beam
5	CV	Carrier Vehicle
6	DCV	Directional Control Valve
7	DPT	Dye Penetration Test
8	ECP	Electronic Control Panel
9	FL	Front Left
10	FR	Front Right
11	GVW	Gross Vehicle Weight
12	HMV	High Mobility Vehicle
13	HPP	Hydraulic Power Pack
14	HSLA	High Strength Low Alloy
15	JC	Joystick Console
16	LP	Launching Platform
17	LED	Light Emitting Diode
18	LS	Launching System
19	LVJB	Launcher Vehicle Junction Box
20	MB	Modular Bridge
21	MDP	Main Distribution Panel
22	NAS	National Aerospace Standard
23	NCM	Nose Centre Module
24	NEM	Nose End Module

RESTRICTED

Sr. No.	Abbreviation Issued	For
25	NPC	Nose Pushing Cylinder
26	MBS	Modular Bridge System
27	MHD	Material Handling Device
28	MLC	Military Load Classification
29	MMI	Man Machine Interface
30	OEM	Original Equipment Manufacturer
31	PDU	Power Distribution Unit
32	PTO	Power Take Off
33	PVG	Proportional Valve Group
34	QDC	Quick Disconnect Coupling
35	RL	Rear Left
36	RR	Rear Right
37	SF	Sub Frame
38	SP	Sliding Platform

RESTRICTED

PREFACE

1. This Illustrated Spare Parts List has been prepared for the purpose of identifying any component, part or assembly of parts likely to be required as replacements. All concerned will use the Cat Sec. / Part No., NSN and DCAN and designations given in this list when demanding spare part or when referring in correspondence to any of the equipment. All demands for items listed herein must be submitted to appropriate authority in accordance with standing instruction.
2. The Cat Sec. / Part No. (when quoted initially) and Designation of all 'P' marked items quoted in the list will be supercede by NSN and codified designation respectively as soon as such items will be codified.
3. When demanding spare parts the following particulars must be quoted:
 - (a). Relevant Section / Sub-section of Catalogue of Ordnance Stores (i.e. COS) or Catalogue of Engineer Stores (i.e. COES) or Catalogue of Mechanical Transport Stores (i.e. CMTS) or Catalogue of Clothing (i.e. COC).
 - (NOTE - The above mentioned Catalogues belong to Army only. Navy and Air Force to mention their respective Catalogues under which the equipment/items are provided by them)
 - (b). Cat Sec. / Part No. or NSN or DCAN of spare parts along with their designation.
 - (c). Designation and Cat Sec. / Part No. or NSN or DCAN of the main equipment.
4. Certain items included in this ISPL have not been marked 'P' (Provided) by concerned MAG since they are not considered to be provisioned for maintenance of the equipment. But User Unit / EME workshop may demand certain non 'P' items which they consider essential for maintenance purpose.
5. All amendment to this list will be forwarded to all concerned by the concerned AHSP / department primarily responsible for providing the equipment. It is essential that this list should be carefully amended and date of each amendment entered.
6. Queries relating to this ISPL should be referred to Controller / HOE of the concerned office by whom this ISPL has been published. The name and address of the publisher is shown on cover page / cover leaf of this ISPL.

RESTRICTED

This page is intentionally left blank.

RESTRICTED

(xxiv)

CONTENTS

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
	SECTION - A MODULAR BRIDGE SYSTEM		1
1.	MODULAR BRIDGE SYSTEM - VIEW 1	PLATE - I	2
	SECTION - B GENERAL ASSEMBLY OF BRIDGE SUPERSTRUCTURE		5
1.	GENERAL ASSEMBLY OF BRIDGE SUPERSTRUCTURE	PLATE - I	6
	SUB - SECTION - 1 BRIDGE CENTRE MODULE ASSEMBLY		9
1.	BRIDGE CENTRE MODULE ASSEMBLY	PLATE - II	10
2.	BRIDGE CENTRE MODULE ASSEMBLY - VIEW 1	PLATE - III	12
3.	BRIDGE CENTRE MODULE ASSEMBLY - VIEW 2	PLATE - III (CONTINUED)	14
4.	BRIDGE CENTRE MODULE ASSEMBLY - VIEW 3	PLATE - III (CONTINUED)	16
5.	BRIDGE CENTRE MODULE ASSEMBLY - VIEW 4	PLATE - III (CONTINUED)	18
6.	BRIDGE CENTRE MODULE ASSEMBLY - VIEW 5	PLATE - III (CONTINUED)	20
7.	CURB ASSY (BCM)	PLATE - IV	22
8.	CURB ASSY (BCM) - VIEW 1	PLATE - V	24
9.	GUIDE BEAK MALE ASSEMBLY (BCM)	PLATE -VI	26
10.	GUIDE BEAK MALE ASSEMBLY (BCM) - VIEW 1	PLATE -VII	28
11.	SUPPORT ROLLER ASSEMBLY (BCM)	PLATE - VIII	30
12.	SUPPORT ROLLER ASSEMBLY (BCM) - VIEW 1	PLATE - IX	32
13.	GUIDE ROLLER ASSEMBLY (BCM)	PLATE - X	34
14.	GUIDE ROLLER ASSEMBLY (BCM)- VIEW 1	PLATE - XI	36
15.	BRIDGE TO BRIDGE LOCKING MECHANISM (BCM)	PLATE - XII	38

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
16.	BRIDGE TO BRIDGE LOCKING MECHANISM (BCM) - VIEW 1	PLATE - XIII	40
17.	BRIDGE TO BRIDGE LOCKING MECHANISM (BCM) - VIEW 2	PLATE - XIII (CONTINUED)	42
18.	BRIDGE TO BRIDGE LOCKING MECHANISM (BCM) - VIEW 3	PLATE - XIII (CONTINUED)	44
19.	ASSEMBLY CONNECTING SHAFT (BRIDGE TO BRIDGE LOCKING MECHANISM)	PLATE-XIV	46
20.	ASSEMBLY CONNECTING SHAFT (BRIDGE TO BRIDGE LOCKING MECHANISM) - VIEW 1	PLATE-XV	48
21.	ASSY CONNECTING SHAFT WITH BEARING (BRIDGE TO BRIDGE LOCKING MECHANISM)	PLATE-XVI	50
22.	ASSY CONNECTING SHAFT WITH BEARING (BRIDGE TO BRIDGE LOCKING MECHANISM) - VIEW 1	PLATE-XVII	52
	SUB - SECTION - 2 BRIDGE END MODULE ASSEMBLY		55
1.	BRIDGE END MODULE ASSY	PLATE-XVIII	56
2.	BRIDGE END MODULE ASSY - VIEW 1	PLATE-XIX	58
3.	BRIDGE END MODULE ASSY - VIEW 2	PLATE-XIX (CONTINUED)	60
4.	BRIDGE END MODULE ASSY - VIEW 3	PLATE-XIX (CONTINUED)	62
5.	BRIDGE END MODULE ASSY - VIEW 4	PLATE-XIX (CONTINUED)	64
6.	BRIDGE END MODULE ASSY - VIEW 5	PLATE-XIX (CONTINUED)	66
7.	BRIDGE END MODULE ASSY - VIEW 6	PLATE-XIX (CONTINUED)	68
8.	BRIDGE END MODULE ASSY - VIEW 7	PLATE-XIX (CONTINUED)	70
9.	BRIDGE END MODULE ASSY - VIEW 8	PLATE-XIX (CONTINUED)	72
10.	FLAP ASSEMBLY (BEM)	PLATE-XX	74
11.	FLAP ASSEMBLY (BEM) - VIEW 1	PLATE - XXI	76
12.	FLAP ASSEMBLY (BEM) - VIEW 2	PLATE - XXII	78

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
13.	SUPPORT ROLLER ASSEMBLY (FLAP ASSEMBLY)	PLATE-XXIII	80
14.	SUPPORT ROLLER ASSEMBLY (FLAP ASSEMBLY) - VIEW 1	PLATE-XXIV	82
15.	GUIDE ROLLER ASSY (FLAP ASSEMBLY)	PLATE-XXV	84
16.	GUIDE ROLLER ASSY (FLAP ASSEMBLY) - VIEW 1	PLATE-XXVI	86
17.	GUIDE ROLLER ASSY (BEM)	PLATE-XXVII	88
18.	GUIDE ROLLER ASSY (BEM) - VIEW 1	PLATE-XXVIII	90
19.	CURB ASSY-1 (BEM)	PLATE-XXIX	92
20.	CURB ASSY-1 (BEM)- VIEW 1	PLATE-XXX	94
21.	CURB ASSY-2 (BEM)	PLATE-XXXI	96
22.	CURB ASSY-2 (BEM) - VIEW 1	PLATE-XXXII	98
23.	BRIDGE END SUPPORT ASSY-1 (BEM)	PLATE-XXXIII	100
24.	BRIDGE END SUPPORT ASSY-1 (BEM) - VIEW 1	PLATE-XXXIV	102
25.	PIN ASSY (BRIDGE END SUPPORT ASSY-1)	PLATE-XXXV	104
26.	PIN ASSY (BRIDGE END SUPPORT ASSY-1) - VIEW 1	PLATE-XXXVI	106
27.	BRIDGE END SUPPORT ASSY-2 (BEM)	PLATE-XXXVII	108
28.	BRIDGE END SUPPORT ASSY-2 (BEM) - VIEW 1	PLATE-XXXVIII	110
29.	PIN ASSY (BRIDGE END SUPPORT ASSY-2)	PLATE-XXXIX	112
30.	PIN ASSY (BRIDGE END SUPPORT ASSY-2) - VIEW 1	PLATE-XL	114
31.	SUPPORT ROLLER ASSEMBLY (BEM)	PLATE-XLI	116
32.	SUPPORT ROLLER ASSEMBLY (BEM) - VIEW 1	PLATE-XLII	118
33.	BRIDGE TO BRIDGE LOCKING MECHANISM (BEM)	PLATE-XLIII	120
34.	BRIDGE TO BRIDGE LOCKING MECHANISM (BEM) - VIEW 1	PLATE-XLIV	122
35.	BRIDGE TO BRIDGE LOCKING MECHANISM (BEM) - VIEW 2	PLATE-XLIV (CONTINUED)	124

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
36.	BRIDGE TO BRIDGE LOCKING MECHANISM (BEM) - VIEW 3	PLATE-XLIV (CONTINUED)	126
37.	ASSEMBLY CONNECTING SHAFT (BRIDGE TO BRIDGE LOCKING MECHANISM)	PLATE-XLV	128
38.	ASSEMBLY CONNECTING SHAFT (BRIDGE TO BRIDGE LOCKING MECHANISM) - VIEW 1	PLATE-XLVI	130
39.	ASSY CONNECTING SHAFT WITH BEARING (BRIDGE TO BRIDGE LOCKING MECHANISM)	PLATE- XLVII	132
40.	ASSY CONNECTING SHAFT WITH BEARING (BRIDGE TO BRIDGE LOCKING MECHANISM) - VIEW 1	PLATE- XLVIII	134
41.	PIN ASSY (BEM)	PLATE- XLIX	136
42.	PIN ASSY (BEM) - VIEW 1	PLATE- L	138
43.	RAMP ROLLER ASSEMBLY (BEM)	PLATE-LI	140
44.	RAMP ROLLER ASSEMBLY (BEM) - VIEW 1	PLATE-LII	142
	SUB - SECTION - 3 RAMP ASSEMBLY		145
1.	RAMP ASSY	PLATE-LIII	146
2.	RAMP ASSY - VIEW 1	PLATE-LIV	148
3.	RAMP LOCK BOX ASSY (RAMP ASSY)	PLATE-LV	150
4.	RAMP LOCK BOX ASSY (RAMP ASSY) - VIEW 1	PLATE-LVI	152
	SUB - SECTION - 4 HAND WHEEL ASSEMBLY		155
1.	HAND WHEEL ASSY	PLATE-LVII	156
2.	HAND WHEEL ASSY - VIEW 1	PLATE-LVIII	158
	SUB - SECTION - 5 BRIDGE TO NOSE LOCKING PIN ASSEMBLY		161
1.	BRIDGE TO NOSE LOCKING PIN ASSY	PLATE-LIX	162
2.	BRIDGE TO NOSE LOCKING PIN ASSY - VIEW 1	PLATE-LX	164

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
	SUB - SECTION - 6 RAMP LOCK ARRANGEMENT		167
1.	RAMP LOCK ARRANGEMENT	PLATE-LXI	168
2.	RAMP LOCK ARRANGEMENT- VIEW 1	PLATE-LXII	170
3.	SCREW ROD ASSEMBLY (RAMP LOCK ARRANGEMENT)	PLATE-LXIII	172
4.	SCREW ROD ASSEMBLY (RAMP LOCK ARRANGEMENT) - VIEW 1	PLATE-LXIV	174
	SECTION - C GENERAL ASSEMBLY OF NOSE SUPER STRUCTURE		177
1.	GA - NOSE SUPER STRUCTURE	PLATE - I	178
	SUB - SECTION - 1 NOSE CENTRE MODULE ASSEMBLY		181
1.	NOSE CENTRE MODULE ASSY	PLATE - II	182
2.	NOSE CENTRE MODULE ASSY- VIEW 1	PLATE - III	184
3.	NOSE CENTRE MODULE ASSY- VIEW 1 (CONTINUED)	PLATE - III (CONTINUED)	186
4.	NOSE CENTRE MODULE ASSY- VIEW 2	PLATE - III (CONTINUED)	188
5.	NOSE CENTRE MODULE ASSY- VIEW 3	PLATE - III (CONTINUED)	190
6.	ROLLER ASSY (NCM)	PLATE - IV	192
7.	ROLLER ASSY (NCM) - VIEW 1	PLATE - V	194
	SUB - SECTION - 2 NOSE END MODULE ASSEMBLY		197
1.	NOSE END MODULE ASSY	PLATE - VI	198
2.	NOSE END MODULE ASSY - VIEW 1	PLATE - VII	200
3.	NOSE END MODULE ASSY - VIEW 1 (CONTINUED)	PLATE - VII (CONTINUED)	202
4.	NOSE END MODULE ASSY - VIEW 2	PLATE - VII (CONTINUED)	204
5.	NOSE END MODULE ASSY - VIEW 3	PLATE - VII (CONTINUED)	206
6.	NOSE END MODULE ASSY - VIEW 4	PLATE - VII (CONTINUED)	208

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
7.	NOSE EXTENSION ASSY (NEM)	PLATE - VIII	210
8.	NOSE EXTENSION ASSY (NEM)- VIEW 1	PLATE - IX	212
9.	ROLLER ASSY (NEM)	PLATE - X	214
10.	ROLLER ASSY (NEM) - VIEW 1	PLATE - XI	216
	SUB - SECTION - 3 BANK SEAT BEAM ASSEMBLY		219
1.	BANK SEAT BEAM ASSY	PLATE - XII	220
2.	BANK SEAT BEAM ASSY - VIEW 1	PLATE - XIII	222
3.	BANK SEAT BEAM ASSY - VIEW 2	PLATE - XIII (CONTINUED)	224
4.	VERTICAL STRUCTURE ASSY (BSB)	PLATE - XIV	226
5.	VERTICAL STRUCTURE ASSY (BSB) - VIEW 1	PLATE - XV	228
6.	VERTICAL STRUCTURE ASSY (BSB) - VIEW 2	PLATE - XV (CONTINUED)	230
7.	VERTICAL STRUCTURE ASSY (BSB) - VIEW 3	PLATE - XV (CONTINUED)	232
8.	TURN BUCKLE (BSB)	PLATE - XVI	234
9.	TURN BUCKLE (BSB) - VIEW 1	PLATE - XVII	236
	SUB - SECTION - 4 CRANK LEVER ASSEMBLY		239
1.	CRANK LEVER ASSY	PLATE - XVIII	240
2.	CRANK LEVER ASSY- VIEW 1	PLATE - XIX	242
	SECTION - D GENERAL ASSEMBLY OF LAUNCHING SYSTEM		245
1.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM	PLATE - I	246
2.	MAJOR ASSEMBLY OF LAUNCHING SYSTEM	PLATE - II	248
3.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 1	PLATE - III	250
4.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 2	PLATE - III (CONTINUED)	252

RESTRICTED

(xxx)

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
5.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 3	PLATE - III (CONTINUED)	254
6.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM -- VIEW 4	PLATE - III (CONTINUED)	256
7.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 5	PLATE - III (CONTINUED)	258
8.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 6	PLATE - III (CONTINUED)	260
9.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 7	PLATE - III (CONTINUED)	262
10.	GENERAL ASSEMBLY OF LAUNCHING SYSTEM - VIEW 8	PLATE - III (CONTINUED)	264
11.	BSB EXTENSION ASSY (LAUNCHING SYSTEM)	PLATE - IV	266
12.	BSB EXTENSION ASSY (LAUNCHING SYSTEM) - VIEW 1	PLATE - V	268
13.	PTO SHAFT ASSY (LAUNCHING SYSTEM)	PLATE - VI	270
14.	PTO SHAFT ASSY (LAUNCHING SYSTEM) - VIEW 1	PLATE - VII	272
15.	APU MAINTENANCE PLATFORM (LAUNCHING SYSTEM)	PLATE - VIII	274
16.	APU MAINTENANCE PLATFORM (LAUNCHING SYSTEM) - VIEW 1	PLATE - IX	276
17.	SUBFRAME ASSY (LAUNCHING SYSTEM)	PLATE - X	278
18.	SUBFRAME ASSY (LAUNCHING SYSTEM) - VIEW 1	PLATE - XI	280
19.	SUBFRAME ASSY (LAUNCHING SYSTEM) - VIEW 2	PLATE - XI (CONTINUED)	282
20.	SUBFRAME ASSY (LAUNCHING SYSTEM) - VIEW 3	PLATE - XI (CONTINUED)	284
21.	SUBFRAME ASSY (LAUNCHING SYSTEM) - VIEW 4	PLATE - XI (CONTINUED)	286
22.	SUBFRAME ASSY (LAUNCHING SYSTEM) - VIEW 5	PLATE - XI (CONTINUED)	288
23.	OUTRIGGER EXTENSION ASSY (SUBFRAME ASSY)	PLATE - XII	290
24.	OUTRIGGER EXTENSION ASSY (SUBFRAME ASSY) - VIEW 1	PLATE - XIII	292
25.	PUMP FIXING ASSY (SUBFRAME ASSY)	PLATE - XIV	294

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
26.	PUMP FIXING ASSY (SUBFRAME ASSY)- VIEW 1	PLATE - XV	296
27.	LOCK ASSY FOR SLIDING PLATFORM ASSY - 1 (SUBFRAME ASSY)	PLATE - XVI	298
28.	LOCK ASSY FOR SLIDING PLATFORM ASSY - 1 (SUBFRAME ASSY)- VIEW 1	PLATE - XVII	300
29.	LOCK ASSY FOR SLIDING PLATFORM ASSY - 2 (SUBFRAME ASSY)	PLATE - XVIII	302
30.	LOCK ASSY FOR SLIDING PLATFORM ASSY - 2 (SUBFRAME ASSY) - VIEW 1	PLATE - XIX	304
31.	ELEPHANT FOOT ASSY (SUBFRAME ASSY)	PLATE - XX	306
32.	ELEPHANT FOOT ASSY (SUBFRAME ASSY) - VIEW 1	PLATE - XXI	308
33.	SLIDING PLATFORM ASSY (LAUNCHING SYSTEM)	PLATE - XXII	310
34.	SLIDING PLATFORM ASSY (LAUNCHING SYSTEM) - VIEW 1	PLATE - XXIII	312
35.	SLIDING PLATFORM ASSY (LAUNCHING SYSTEM) - VIEW 2	PLATE - XXIII (CONTINUED)	314
36.	SLIDING PLATFORM ASSY (LAUNCHING SYSTEM) - VIEW 3	PLATE - XXIII (CONTINUED)	316
37.	HORIZONTAL ROLLER ASSY - 1 (SLIDING PLATFORM ASSY)	PLATE - XXIV	318
38.	HORIZONTAL ROLLER ASSY - 1 (SLIDING PLATFORM ASSY) - VIEW 1	PLATE - XXV	320
39.	HORIZONTAL ROLLER ASSY - 2 (SLIDING PLATFORM ASSY)	PLATE - XXVI	322
40.	HORIZONTAL ROLLER ASSY - 2 (SLIDING PLATFORM ASSY) - VIEW 1	PLATE-XXVII	324
41.	ROLLER ASSY-REAR (SLIDING PLATFORM ASSY)	PLATE-XXVIII	326
42.	ROLLER ASSY-REAR (SLIDING PLATFORM ASSY) - VIEW 1	PLATE-XXIX	328
43.	ROLLER ASSY-MIDDLE (SLIDING PLATFORM ASSY)	PLATE-XXX	330
44.	ROLLER ASSY-MIDDLE (SLIDING PLATFORM ASSY) - VIEW 1	PLATE-XXXI	332
45.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM)	PLATE-XXXII	334

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
46.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 1	PLATE-XXXIII	336
47.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 2	PLATE-XXXIII (CONTINUED)	338
48.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 3	PLATE-XXXIII (CONTINUED)	340
49.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 4	PLATE-XXXIII (CONTINUED)	342
50.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 5	PLATE-XXXIII (CONTINUED)	344
51.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 6	PLATE-XXXIII (CONTINUED)	346
52.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 7	PLATE-XXXIII (CONTINUED)	348
53.	LAUNCHING PLATFORM ASSEMBLY (LAUNCHING SYSTEM) - VIEW 8	PLATE-XXXIII (CONTINUED)	350
54.	NOSE SUPPORT ROLLER ASSY (LAUNCHING PLATFORM ASSEMBLY)	PLATE-XXXIV	352
55.	NOSE SUPPORT ROLLER ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE-XXXV	354
56.	ROLLER ASSEMBLY (NOSE SUPPORT ROLLER ASSY)	PLATE-XXXVI	356
57.	ROLLER ASSEMBLY (NOSE SUPPORT ROLLER ASSY) - VIEW 1	PLATE-XXXVII	358
58.	NOSE SUPPORT RAIL ASSY (LAUNCHING PLATFORM ASSEMBLY)	PLATE-XXXVIII	360
59.	NOSE SUPPORT RAIL ASSY (LAUNCHING PLATFORM ASSEMBLY)- VIEW 1	PLATE-XXXIX	362
60.	FRICTION LOCKING ASSY (LAUNCHING PLATFORM ASSEMBLY)	PLATE - XL	364
61.	FRICTION LOCKING ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE - XLI	366
62.	HANDLE ASSY (LAUNCHING PLATFORM ASSEMBLY)	PLATE - XLII	368
63.	HANDLE ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE - XLIII	370
64.	HANDLE ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 2	PLATE - XLIII (CONTINUED)	372

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
65.	NOSE PUSHING ASSY (LAUNCHING PLATFORM ASSEMBLY)	PLATE - XLIV	374
66.	NOSE PUSHING ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE - XLV	376
67.	NOSE PUSHING ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 2	PLATE - XLV (CONTINUED)	378
68.	NOSE PUSHING ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 3	PLATE - XLV (CONTINUED)	380
69.	BEARING FOR NOSE PUSHING (NOSE PUSHING ASSY)	PLATE - XLVI	382
70.	BEARING FOR NOSE PUSHING (NOSE PUSHING ASSY)- VIEW 1	PLATE - XLVII	384
71.	NOSE INITIAL PUSH ASSY (LAUNCHING PLATFORM ASSEMBLY)	PLATE - XLVIII	386
72.	NOSE INITIAL PUSH ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE - XLIX	388
73.	NOSE INITIAL PUSH ASSY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1 (CONTINUED)	PLATE - XLIX (CONTINUED)	390
74.	PULLEY BRACKET (LAUNCHING PLATFORM ASSEMBLY)	PLATE - L	392
75.	PULLEY BRACKET (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE- LI	394
76.	BRIDGE PUSHING ASSEMBLY (LAUNCHING PLATFORM ASSEMBLY)	PLATE- LII	396
77.	BRIDGE PUSHING ASSEMBLY (LAUNCHING PLATFORM ASSEMBLY) - VIEW 1	PLATE- LIII	398
78.	HOOK TILTING ASSY (BRIDGE PUSHING ASSEMBLY)	PLATE- LIV	400
79.	HOOK TILTING ASSY (BRIDGE PUSHING ASSEMBLY) - VIEW 1	PLATE- LV	402
80.	LIFTING BEAM ASSY (LAUNCHING SYSTEM)	PLATE - LVI	404
81.	LIFTING BEAM ASSY (LAUNCHING SYSTEM) - VIEW 1	PLATE - LVII	406
LIST OF APPENDIX			
1.	LIST OF CARRIED SPARES	APPENDIX A	411
2.	LIST OF STANDARD ACCESSORIES	APPENDIX B	415

RESTRICTED

RESTRICTED

SR. NO.	INSPECTION	PLATE REFERENCE	PAGE NO.
3.	LIST OF CARRIED TOOL	APPENDIX C	417
4.	LIST OF SPECIAL MAINTENANCE TOOL	APPENDIX D	419
5.	LIST OF SPARES FOR TWO YEARS MAINTENANCE AND ONE OVERHAUL	APPENDIX E	423
6.	LIST OF SUPPLIES FOR PROPRIETARY ITEMS	APPENDIX F	507
7.	NUMERICAL INDEX OF PARTS (FIRM'S CODE)	APPENDIX G	531

RESTRICTED