switch

about

author Andrew Donnellan <ajd@linux.ibm.com> 2020-08-20 14:45:12 +1000 Michael Ellerman <mpe@ellerman.id.au> 2020-10-06 23:22:27 +1100 bd59380c5ba4147dcbaad3e582b55ccfd120b764 (patch) committer commit 3c4e5103b502d8ff8c271b3ef20185c3f8178d40

36c3adbb2fa42749c3d38cfc4d4d0b7e096bb7b (diff) linux-bd59380c5ba4147dcbaad3e582b55ccfd120b764.tar.gz parent download

## diff options context: 3 include mode: unified

## powerpc/rtas: Restrict RTAS requests from userspace

A number of userspace utilities depend on making calls to RTAS to retrieve information and update various things

The existing API through which we expose RTAS to userspace exposes more RTAS functionality than we actually need, through the sys\_rtas syscall, which allows root (or anyone with CAP\_SYS\_ADMIN) to make any RTAS call they want with arbitrary arguments.

Many RTAS calls take the address of a buffer as an argument, and it's up to Many RTAS calls take the address or a buffer as an argument, and it's up to the caller to specify the physical address of the buffer as an argument. We allocate a buffer (the "RMO buffer") in the Real Memory Area that RTAS can access, and then expose the physical address and size of this buffer in /proc/powerpc/tras/rmo\_buffer. Userspace is expected to read this address, poke at the buffer using /dev/mem, and pass an address in the RMO buffer to poke at the bu the RTAS call.

However, there's nothing stopping the caller from specifying whatever address they want in the RTAS call, and it's easy to construct a series of RTAS calls that can overwrite arbitrary bytes (even without /dev/mem

Additionally, there are some RTAS calls that do potentially dangerous things and for which there are no legitimate userspace use cases

In the past, this would not have been a particularly big deal as it was assumed that root could modify all system state freely, but with Secure Boot and lockdown we need to care about this.

We can't fundamentally change the ABI at this point, however we can address this by implementing a filter that checks RTAS calls against a list of permitted calls and forces the caller to use addresses within the RMO

The list is based off the list of calls that are used by the librtas userspace library, and has been tested with a number of existing userspace RTAS utilities. For compatibility with any applications we are not aware of that require other calls, the filter can be turned off at build time.

Cc: stable@vger.kernel.org
Reported-by: Daniel Axtens <dja@axtens.net>
Signed-off-by: Michael Ellerman <mpe@ellerman.id.au>
Link: https://lore.kernel.org/r/20200820044512.7543-1-ajd@linux.ibm.com

-rw-r--r-- arch/powerpc/Kconfig

```
-rw-r--r-- arch/powerpc/kernel/rtas.c 153
2 files changed, 166 insertions, 0 deletions
diff --qit a/arch/powerpc/Kconfig b/arch/powerpc/Kconfig
index fe0e6b317c26..6c76caa950e16 100644
--- a/arch/powerpc/Kconfig
+++ b/arch/powerpc/Kconfig
00 -1004,6 +1004,19 @0 config PPC_SECVAR_SYSFS
read/write operations on these variables. Say Y if you have
secure boot enabled and want to expose variables to userspace.
+config PPC_RTAS_FILTER
+ bool "Enable filtering of RTAS syscalls"
           default y
depends on PPC_RTAS
           The RTAS syscall API has security issues that could be used to compromise system integrity. This option enforces restrictions on the
              RTAS calls and arguments passed by userspace programs to mitigate
              Say Y unless you know what you are doing and the filter is causing
          -git a/arch/powerpc/kernel/rtas.c b/arch/powerpc/kernel/rtas.c
index 806d554ce3577..954f41676f692 100644
---- a/arch/powerpc/kernel/rtas.c
+++ b/arch/powerpc/kernel/rtas.c
@@ -992,6 +992,147 @@ struct pseries_errorlog *get_pseries_errorlog(struct rtas_error_log *log,
           return NULL:
```

```
+#ifdef CONFIG PPC RTAS FILTER
     * The sys_rtas syscall, as originally designed, allows root to pass
* arbitrary physical addresses to RTAS calls. A number of RTAS calls
* can be abused to write to arbitrary memory and do other things that
* are potentially harmful to system integrity, and thus should only
* be used inside the kernel and not exposed to userspace.
       * All known legitimate users of the sys_rtas syscall will only ever
* pass addresses that fall within the RMO buffer, and use a known
* subset of RTAS calls.
+ *

* Accordingly, we filter RTAS requests to check that the call is

+ * permitted, and that provided pointers fall within the RMO buffer.

+ * The rtas_filters list contains an entry for each permitted call,

+ * with the indexes of the parameters which are expected to contain

+ * addresses and sizes of buffers allocated inside the RMO buffer.
```

```
+struct rtas_filter {
+     const char *name;
+     int token;
            /* Indexes into the args buffer, -1 if not used */
           /* Indexes int
int buf_idx1;
int size_idx1;
int buf_idx2;
int size_idx2;
           int fixed size;
+static bool in_rmo_buf(u32 base, u32 end)
           return base >= rtas_rmo_buf &&
base < (rtas_rmo_buf + RTAS_RMOBUF_MAX) &&
base <= end &&
                      base <= end &&
end >= rtas_rmo_buf &&
end < (rtas_rmo_buf + RTAS_RMOBUF_MAX);</pre>
 +
+static bool block_rtas_call(int token, int nargs,
+ struct rtas_args *args)
           int i;
            for (i = 0; i < ARRAY_SIZE(rtas_filters); i++)
                      struct rtas_filter *f = &rtas_filters[i];
u32 base, size, end;
                      if (token != f->token)
                                 continue;
                      if (f->buf_idxl != -1) (
    base = be32_to_cpu(args->args[f->buf_idxl]);
    if (f->size_idxl != -1)
        size = be32_to_cpu(args->args[f->size_idxl]);
    else if (f->fixed_size)
        size = f->fixed_size;
    else
                                 else
                                            size = 1;
                                 end = base + size - 1;
                                 if (f->buf_idx2 != -1) {
    base = be32_to_cpu(args->args[f->buf_idx2]);
    if (f->size_idx2 != -1)
        size = be32_to_cpu(args->args[f->size_idx2]);
    else if (f->fixed_size)
        size = f->fixed_size;
    else
                                 else
                                 size = 1;
end = base + size - 1;
                                   * Special case for ibm, configure-connector where the * address can be 0 \ensuremath{^{*/}}
                                 if (!strcmp(f->name, "ibm,configure-connector") &&
base == 0)
    return false;
                                 return false;
 +err:
           return true:
 +}
 +#else
 +static bool block_rtas_call(int token, int nargs,
                                      struct rtas args *args)
 + {
            return false;
 +#endif /* CONFIG PPC RTAS FILTER */
```

generated by cgit (git 2.34.1) at 2022-12-18 22:16:14 +0000