SPEEDY - PWR - PINOUT

14 PIN - AMP CONNECTOR

PIN	FUNCTION	COMMENTS	NOTES	NOTES2
1	ECU - OUT		TO ECU	
2	IGNITION COILS - OUT		TO COIL PACKS	
3	FUEL PUMP - OUT		TO FUEL PUMP	
4	RADIATOR FAN 1 - OUT		TO FAN 1	
5	RADIATOR FAN 2 - OUT		TO FAN 2	
6	ENGINE SENSOR 12V - OUT		TO 12V ENGINE SENSORS	
7	IMMOB - NEG TRIGGER		TO IMMOBILISER OR SWITCH TO GND	
8	FUEL PUMP - TRIGGER		ECU TRIGGER	
9	FAN - TRIGGER		USE ECU OR FAN SWITCH	
10	12V - IN		TO BATT	
11	12V - IN		TO BATT	
12	12V - IN		TO BATT	
13	12V - IN		TO BATT	
14	IGN2 - IN		IGN SWITCH - POSITION 2	

MATERIALS

QUANTITY	PRODUCT2	PLACEMENT	NOTES	LINK
X4	MICRO RELAY	M1-M4		https://www.aliexpress.com/item/1005006685907372.html
X4	STANDARD FUSE HOLDER	F1-F6		https://www.aliexpress.com/item/4000541087990.html
X1	TYCO AMPSEAL 776164-1 ANGLE	J1		https://www.aliexpress.com/item/1005006327573526.html
X4	SS14 DIODE	D1-D4		https://www.aliexpress.com/item/1005007021941662.html