## SPEEDY - PWR - PINOUT

### 12 PIN - AMP CONNECTOR

| PIN | FUNCTION | COMMENTS | NOTES | NOTES2 |
|---|---|---|---|---|
| 1 | ECU - OUT | | TO ECU | |
| 2 | IGNITION COILS - OUT | | TO COIL PACKS | |
| 3 | FUEL PUMP - OUT | | TO FUEL PUMP | |
| 4 | RADIATOR FAN 1 - OUT | | TO FAN 1 | |
| 5 | RADIATOR FAN 2 - OUT | | TO FAN 2 | |
| 6 | ENGINE SENSOR 12V - OUT | | TO 12V ENGINE SENSORS | |
| 7 | IMMOB - NEG TRIGGER | | TO IMMOBILISER OR SWITCH TO GND | |
| 8 | FUEL PUMP - TRIGGER | | ECU TRIGGER | |
| 9 | FAN - TRIGGER | | USE ECU OR FAN SWITCH | |
| 10 | 12V - IN | | TO BATT | |
| 11 | 12V - IN | | TO BATT | |
| 12 | 12V - IN | | TO BATT | |
| 13 | 12V - IN | | TO BATT | |
| 14 | IGN2 - IN | | IGN SWITCH - POSITION 2 | |

### MATERIALS

| QUANTITY | PRODUCT2 | PLACEMENT | NOTES | LINK |
|---|---|---|---|---|
| X4 | MICRO RELAY | M1-M4 | | https://www.aliexpress.com/item/1005006685907372.html |
| X4 | STANDARD FUSE HOLDER | F1-F6 | | https://www.aliexpress.com/item/4000541087990.html |
| X1 | TYCO AMPSEAL 776164-1 ANGLE | J1 | | https://www.aliexpress.com/item/1005006327573526.html |
| X4 | SS14 DIODE | D1-D4 | | https://www.aliexpress.com/item/1005007021941662.html |