DI88X-0

9. Black screen appears when "MAP", "Menu" or "DESTINATION" switch pressed.





NG

Replace or repair wire harness or connector.

OK

2 Check the display signal circuit (see page DI-270).

NG

Replace or repair wire harness or connector.

OK

Replace the multi -display.